Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VINABTY CLU-4997S

VINABTY CLU-4997S Replacement Remote Control User Manual

For Hitachi UltraVision LCD Flat Panel HDTVs

1. Introduction

Thank you for choosing the VINABTY CLU-4997S Replacement Remote Control. This remote is designed to function as a direct replacement for your original Hitachi UltraVision LCD Flat Panel HDTV remote, requiring no programming. Simply insert batteries, and it is ready for use.

This manual provides instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your remote control.

2. Compatible TV Models

The CLU-4997S remote control is compatible with the following Hitachi UltraVision LCD Flat Panel HDTV models:

- L32S504
- L42S504
- L46S603
- L46S604
- L55S603
- L42S503
- HL02567

3. Setup: Battery Installation

The CLU-4997S remote control requires two AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

The remote control is now ready for use with your compatible Hitachi TV. No additional programming is required.

Figure 1: Back view of the remote control with the battery compartment.

4. Operating the Remote Control

This remote control provides full functionality for your Hitachi UltraVision LCD Flat Panel HDTV. Below is a general overview of common buttons and their functions:

Figure 2: Front view of the CLU-4997S remote control.

- **Power (Red Button):** Turns the TV on or off.
- **TV/DVD/PVR/CBL/AVR:** Selects the device to control (if your TV supports universal remote functions for other devices).
- **Number Buttons (0-9):** Directly enter channel numbers.
- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes the TV channel up or down.
- **MUTE:** Mutes or unmutes the TV audio.
- **INPUT:** Cycles through available input sources (HDMI, AV, Component, etc.).
- **MENU:** Opens the TV's main menu.
- **GUIDE:** Displays the electronic program guide (if available).
- **SELECT (Center Button):** Confirms selections within menus.
- **Arrow Buttons (Up/Down/Left/Right):** Navigate through menus and options.
- **EXIT:** Exits the current menu or function.
- **C.C. (Closed Caption):** Toggles closed captions on or off.
- **INFO:** Displays information about the current program or input.

Point the remote control directly at the infrared receiver on your Hitachi TV for optimal response. The maximum effective range is approximately 33 feet (10 meters).

Figure 3: Example of remote control in use.

5. Maintenance

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries.
- **Battery Disposal:** Dispose of used batteries according to local regulations. Do not dispose of batteries in household waste.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which can cause damage. Store in a cool, dry place.
- **Avoid Damage:** Do not drop the remote, expose it to extreme temperatures, or immerse it in water.

6. Troubleshooting

If you experience issues with your remote control, refer to the following troubleshooting tips:

- **Remote not working:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA batteries.
  - Check for any obstructions between the remote control and the TV's infrared receiver.
  - Ensure you are within the effective operating range (approximately 33 feet).
- **Buttons not responding:**
  - Clean the remote control surface, especially around the buttons, to remove any dirt or debris that might be obstructing them.
  - If only specific buttons are not working, the remote may be damaged.
- **TV not responding to specific functions:**
  - Verify that the function is supported by your specific Hitachi TV model.
  - Some advanced functions might require the original TV remote or specific TV settings.

If the issue persists after trying these steps, please refer to the support information provided in this manual.

7. Specifications

Figure 4: Remote control dimensions.

Feature	Detail
Model Name	CLU-4997S
Brand	VINABTY
Connectivity Technology	Infrared (IR)
Compatible Devices	Hitachi UltraVision LCD Flat Panel HDTVs
Power Source	2 x AAA Batteries (not included)
Maximum Range	33 feet (10 meters)
Color	Black
Item Weight	1.9 ounces (approx. 54 grams)
Dimensions (L x W x H)	5" x 1.9" x 0.5" (approx. 12.7 cm x 4.8 cm x 1.3 cm)
Special Feature	Ergonomic design

8. Warranty and Support

This VINABTY remote control is designed for reliable performance. For any issues not covered in the troubleshooting section, or for warranty inquiries, please contact the retailer or manufacturer directly. Please retain your proof of purchase for warranty claims.

© 2023 VINABTY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09DYBVW6J

More documents and user manuals: **https://manuals.plus/**