

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Moukey](#) /

› [Moukey 41" Acoustic Guitar MK3000 Instruction Manual](#)

Moukey MK3000

Moukey 41" Acoustic Guitar MK3000 Instruction Manual

Brand: Moukey | Model: MK3000

1. INTRODUCTION

Thank you for choosing the Moukey 41" Acoustic Guitar. This full-size acoustic guitar is designed for beginners, adults, and teens, offering a comfortable playing experience and a rich, vibrant tone. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new instrument, ensuring a rewarding musical journey.



Image: The Moukey 41" Acoustic Guitar, a full-size instrument with a black finish, designed for beginners.

2. WHAT'S IN THE Box

Your Moukey Acoustic Guitar package includes everything you need to start playing:

- Moukey 41" Acoustic Guitar (Black)
- Chord Poster
- 3mm Padded Gig Bag
- Tuner
- Strap
- Capo
- Extra Steel Strings
- Picks
- Allen Wrench (for truss rod adjustment, if needed)

Complete Beginner Kit

Come with all accessories you need

- Guitar bag



- Guitar chord poster



- Tuner



- Strap



- Pickguard



- Extra strings



- Capo



- Allen Wrench



- Pick

Image: A visual representation of the complete beginner kit, including the black acoustic guitar, gig bag, chord poster, tuner, strap, capo, extra strings, picks, and an Allen wrench.

3. SETUP

3.1. Initial Inspection

Upon unboxing, carefully remove the guitar and all accessories from the packaging. Inspect the guitar for any visible damage. The guitar comes pre-strung, but new strings may require stretching and frequent tuning initially.

3.2. Tuning Your Guitar

Use the included clip-on tuner to accurately tune your guitar. The Moukey guitar is constructed with 1:14 enclosed copper tuning machines for fine and smooth tuning.

1. Clip the tuner onto the headstock of your guitar.
2. Pluck each string individually. The tuner display will show the note being played.
3. Adjust the corresponding tuning peg until the tuner indicates the correct pitch (E-A-D-G-B-E, from thickest to thinnest string). The display will typically turn green when the string is in tune.
4. Repeat for all six strings. New strings may go out of tune quickly; retune as needed until they stabilize.

Faster tuning design

Uses 1:14 gears to make tuning easier and more enjoyable



Image: Detailed view of the guitar's headstock, highlighting the 1:14 enclosed copper tuning machines for precise tuning.

3.3. Attaching the Strap

Your guitar features two strap pegs for easy attachment of the included strap. Secure one end of the strap to the peg at the base of the guitar body and the other end to the peg near the neck joint.

3.4. Using the Chord Poster

The ultimate beginner-friendly guitar chord poster shows the most commonly used chords, enabling starters to memorize the fretboard and play chords on the first day. Keep it handy for quick reference.




Image: A person playing the Moukey acoustic guitar with the included chord poster visible, demonstrating its use for learning.

4. OPERATING YOUR GUITAR

4.1. Playing Comfort and Design

The Moukey 41" acoustic guitar features a cutaway design, making it easy for beginners to reach higher frets. The smooth fingerboard and non-scratching frets ensure comfortable playability for extended periods. Precise position marks at the 3rd, 5th, 7th, 9th, 12th, 15th, and 17th frets on the neck and top of the fingerboard assist in convenient learning.




Image: A person playing the Moukey acoustic guitar, highlighting the comfortable design and cutaway body.

4.2. Tone and Sound Quality

The dreadnought body provides a full and vibrant tone, suitable for all styles of music. The quality basswood

body and Okoume neck contribute to its resonant sound. The thin, glossy lacquer finish not only enhances the guitar's appearance but also allows the natural grain of the wood to resonate, producing a clear sound.

Better quality

Better sound and craftsmanship
than any other in its class

The thin, wing-like glossy lacquer finish not only reflects the original grain of the wood, but also sounds every hint of detail.



Image: A close-up of the Moukey acoustic guitar's body, showcasing its glossy finish and craftsmanship.

4.3. Using the Capo

The included capo allows you to change the pitch of the open strings, enabling you to play in different keys without changing your finger positions. Place the capo firmly behind the desired fret.

4.4. Playing with Picks

Experiment with the various picks provided to find the thickness and material that best suits your playing style and desired tone.

4.5. Official Product Video

Video: An official overview of the Moukey 41" Acoustic Guitar, demonstrating its features and sound for beginners.

5. MAINTENANCE

5.1. Cleaning

Regularly wipe down your guitar with a soft, dry cloth to remove dust and fingerprints. For a deeper clean, use a guitar-specific cleaning solution and a microfiber cloth. Avoid abrasive materials that could scratch the finish.

5.2. String Replacement

Over time, guitar strings will wear out and lose their tone. Replace them with the included extra steel strings or a new set of your preference. Ensure proper stringing technique to maintain tuning stability and guitar health. The hard bridge saddle and bone nut are designed to support string tension effectively.


5.3. Storage

When not in use, store your guitar in the provided 3mm padded gig bag to protect it from dust, scratches, and minor impacts. Avoid extreme temperatures and humidity, which can damage the wood.

Reliable guitar bag



Load up everything you love about music, put the trusty one on your back and go!



- Music playing compartment

Image: The Moukey acoustic guitar safely stored in its padded gig bag, ready for transport or protection.

6. TROUBLESHOOTING

6.1. Tuning Instability

- **New Strings:** New strings will stretch significantly during the first few days of playing. Tune frequently until they settle.
- **Improper Winding:** Ensure strings are properly wound around the tuning pegs. Too few or too many

wraps can cause slippage.

- **Environmental Factors:** Extreme changes in temperature or humidity can affect wood and string tension. Keep your guitar in a stable environment.

6.2. Buzzing Strings

- **Fretting Technique:** Ensure you are pressing down firmly on the strings just behind the fret.
- **Truss Rod Adjustment:** If buzzing persists, the neck relief might need adjustment. Use the included Allen wrench for minor adjustments, or consult a professional.
- **Worn Frets:** Over time, frets can wear down. This is less common for new guitars but can cause buzzing.

7. SPECIFICATIONS

Feature	Detail
Item Weight	6.98 pounds
Product Dimensions	15.75 x 4.25 x 41 inches
Item Model Number	MK3000
Back Material	Basswood
Body Material	Basswood
Color Name	Black
Fretboard Material	Okoume wood
Scale Length	25.5 inches
String Material	Alloy Steel
Top Material	Okoume, Basswood
Neck Material Type	Mahogany
Number of Strings	6
Guitar Bridge System	Hard Tail
Size	41 inch
Proficiency Level	Beginner
Hand Orientation	Right

8. WARRANTY AND SUPPORT

Moukey is committed to providing high-quality audio products and accessories. Your Moukey 41" Acoustic Guitar comes with a comprehensive warranty and support:

- **Warranty:** Enjoy up to a 24-month warranty on your product.
- **Return Policy:** A 30-day free return policy is available for your convenience.
- **Customer Service:** 24/7 services are available, including phone chat and email assistance, for any questions or support needs.



Image: Moukey Customer Care details, outlining 24/7 services, warranty information, and return policy.