

## Avenlur SW001

# Avenlur Modern Outdoor Backyard Playset Instruction Manual

Model: SW001

Brand: Avenlur

[Introduction](#)

[Safety Information](#)  
[Troubleshooting](#)

[Components](#)  
[Specifications](#)

[Setup](#)  
[Warranty](#)

[Operating](#)  
[Support](#)

[Maintenance](#)

## 1. INTRODUCTION

---

This manual provides essential instructions for the assembly, safe operation, and maintenance of your Avenlur Modern Outdoor Backyard Playset, Model SW001. Designed for children aged 3 to 11 years, this playset offers a variety of activities including swings, a rock wall, a clubhouse fort, a ladder, and a wavy slide. Please read all instructions carefully before assembly and use to ensure the safety of all users.



Image 1.1: Overview of the Avenlur Modern Outdoor Backyard Playset.

## 2. SAFETY INFORMATION

---

The safety of children is paramount. Adhere to the following guidelines:

- **Age Range:** This playset is intended for children aged 3 to 11 years.
- **Weight Limit:** Maximum individual user weight is 110 lbs (50 kg). The playset can accommodate up to 7 children simultaneously, provided individual weight limits are observed.
- **Adult Supervision:** Constant adult supervision is required during use.
- **Installation:** Ensure the playset is installed on level ground and secured as per assembly instructions, including digging holes and pouring concrete for stability.
- **Clearance:** Maintain a safe perimeter around the playset, free from obstacles, fences, or other structures.
- **Materials:** The playset is constructed from 100% Pine wood with non-toxic paints and sealants.
- **Safety Features:** Utilize sturdy handles provided near the ladder and the small edge on the slide for enhanced safety.
- **Inspection:** Regularly inspect all components for wear, damage, or loose connections. Refer to the

Maintenance section for details.



Image 2.1: The Consumer Product Safety Commission (CPSC) provides guidelines for playset safety.

### 3. COMPONENTS LIST

---

The Avenlur Modern Outdoor Backyard Playset includes the following main components:

- Clubhouse Fort with windows
- 6-foot Wavy Slide
- 2 Belt Swings with rope chains
- Rock Wall with climbing holds
- Ladder
- Space for a sand pit (sand not included)
- All necessary hardware (bolts, screws, etc.)



Image 3.1: The clubhouse fort features built-in windows for ventilation and supervision.

## 4. SETUP AND ASSEMBLY INSTRUCTIONS

---

Assembly of the Avenlur playset requires careful attention to detail. The wood components are pre-cut, pre-drilled, and pre-stained for convenience.

1. **Site Preparation:** Choose a level area in your backyard, ensuring adequate clearance around the playset for safe use.
2. **Foundation:** Dig 6 holes (4 for the main playhouse and 2 for the A-frame) approximately 8 inches deep. These posts must be set in concrete to ensure the stability and safety of the structure. It is crucial to ensure the posts are square and level during this process.
3. **Frame Assembly:** Begin by assembling the main fort structure. Attach the pre-drilled wooden panels using the provided hardware.
4. **A-Frame Installation:** The A-frame for the swings should be attached to the main structure. This step

may require two adults for safe lifting and securing.

5. **Component Attachment:** Install the ladder, rock wall, and wavy slide to their designated positions. Ensure all connections are tight and secure.
6. **Swing Installation:** Attach the belt swings to the swing beam using the provided hardware. Verify that the swings hang freely and do not interfere with each other or the playset structure.
7. **Final Inspection:** After assembly, perform a thorough inspection of all bolts, nuts, and connections to ensure they are securely fastened. Check for any sharp edges or protruding hardware.



Image 4.1: The ladder provides access to the fort. Ensure it is securely attached during assembly.



Image 4.2: Sturdy handles are provided for climbing and entering the fort.

## 5. OPERATING INSTRUCTIONS

---

The Avenlur playset offers multiple activity zones for children to enjoy:

- **Swings:** The playset includes two belt swings. Children should sit centered on the swing seat and hold onto the chains firmly. Ensure adequate space is maintained between children swinging.
- **Slide:** Children should slide down feet first, one at a time. The wavy design and small edge provide a fun and secure descent.
- **Rock Wall & Ladder:** Use the rock wall and ladder for climbing to the fort. Encourage children to use both hands and feet for stability.
- **Clubhouse Fort:** The fort provides an elevated play space. Children can use the windows for observation and imaginative play.



Image 5.1: Children enjoying the belt swings. Always ensure proper grip and seating.



Image 5.2: The wavy slide provides an exciting descent. Always slide feet first.

## 6. MAINTENANCE

---

Regular maintenance ensures the longevity and safety of your playset.

- **Monthly Inspection:** Check all nuts, bolts, and screws for tightness. Tighten as necessary. Inspect all wooden components for splinters, cracks, or rot. Sand down splinters and replace severely damaged parts.
- **Hardware:** All hinges are covered with a rust-free coating. However, regularly check for any signs of rust or corrosion on metal parts and address them promptly.
- **Swings:** Inspect swing chains, ropes, and seats for wear or damage. Replace worn components immediately.
- **Cleaning:** Clean the playset periodically with mild soap and water. Avoid harsh chemicals that could damage the wood finish or non-toxic sealants.
- **Weather Protection:** While the wood finishes are designed to withstand outdoor elements, consider

applying a wood sealant annually to protect against weathering and prolong the life of the playset.

- **Grounding:** Ensure the concrete foundation remains stable and the posts are firmly anchored. Re-level if necessary.

## 7. TROUBLESHOOTING

---

Below are common issues and their potential solutions:

Problem	Possible Cause	Solution
Playset feels wobbly after assembly.	Inadequate foundation or loose connections.	Ensure all posts are properly set in concrete and that all bolts and nuts are tightened. Re-check ground leveling.
Missing parts or hardware.	Packaging error or lost during unpacking.	Contact Avenlur customer support with your model number and a description of the missing items.
Slide is not slippery enough.	Surface residue or material characteristic.	Clean the slide surface thoroughly. Ensure children are wearing appropriate clothing for sliding.
Wood shows signs of wear or damage.	Exposure to elements or heavy use.	Sand down splinters. For significant damage, contact support for replacement parts or repair advice. Apply wood sealant annually.

## 8. SPECIFICATIONS

---

- **Model Number:** SW001
- **Brand:** Avenlur
- **Material:** Pine Wood
- **Item Dimensions (D x W x H):** 100.1" x 198.5" x 98.8"
- **Item Weight:** 110 Pounds
- **Age Range:** 3 - 11 Years
- **Maximum Individual User Weight:** 110 lbs (50 kg)
- **GTIN/UPC:** 650327419827

## 9. WARRANTY INFORMATION

---

The Avenlur Modern Outdoor Backyard Playset (Model SW001) comes with a **2-year manufacturer's**

**warranty.** This warranty covers defects in materials and workmanship under normal use and service. Please retain your proof of purchase for warranty claims. For specific details regarding coverage and how to make a claim, please contact Avenlur customer support.

## 10. CUSTOMER SUPPORT

---

For any questions, assistance with assembly, missing parts, or warranty claims, please contact Avenlur customer support. Our team is available to help ensure your satisfaction with the product.

**Contact Information:** Please refer to the Avenlur official website or your purchase documentation for the most current contact details.

Your browser does not support the video tag.

Video 10.1: This video highlights the quality and craftsmanship behind Avenlur products, demonstrating the attention to detail in manufacturing.