

[Manuals.plus](#) /

› [CosmoLiving by Cosmopolitan](#) /

› CosmoLiving Astor Dining Table, White Marble Top with Gold Legs - Instruction Manual

CosmoLiving by Cosmopolitan DA5014002CL

CosmoLiving Astor Dining Table Instruction Manual

Model: DA5014002CL

INTRODUCTION

This manual provides essential information for the assembly, operation, maintenance, and care of your CosmoLiving Astor Dining Table. Please read these instructions carefully before assembly and use to ensure proper function and longevity of your product.

The CosmoLiving Astor Dining Table features a modern design with a faux marble top and a sturdy metal base with geometric trestle-style legs. It is designed to comfortably seat 4 people and can also serve as a desk for a home office.

SAFETY INFORMATION

- Always follow assembly instructions carefully.
- Ensure all connections are secure before use.
- Do not exceed the maximum weight limit of 112 lbs.
- Keep small parts away from children during assembly.
- This table is intended for indoor residential use only.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Tabletop (Faux Marble)
- Legs (Metal, Gold Finish)
- Hardware Pack (Screws, bolts, etc.)
- Assembly Instructions

SETUP AND ASSEMBLY

Minimal assembly is required for the CosmoLiving Astor Dining Table. Two people are recommended for assembly to ensure stability and ease of handling, especially when lifting the tabletop. A wrench is the recommended tool for assembly; it is not included in the package.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches.
2. **Attach Legs to Tabletop:** Align the metal legs with the pre-drilled holes on the underside of the tabletop. Secure them using the provided hardware (screws, bolts) and a wrench. Do not overtighten.
3. **Tighten All Connections:** Once all legs are attached, gently tighten all screws and bolts to ensure the table is stable.
4. **Position the Table:** With assistance, carefully lift and place the table in its desired location. Avoid dragging the table to prevent damage to the legs or flooring.





Figure 1: Table Dimensions Diagram. The table measures 64 inches in length, 36 inches in width, and 30 inches in height.



Product Dimensions

64in (W) x 36in (D) x 30in (H)
Weight Limit: 112 lbs.

Figure 2: Product Dimensions with Scale. This image illustrates the table's dimensions (64"W x 36"D x 30"H) relative to an average adult height.

Your browser does not support the video tag.

Video 1: Unboxing and Assembly Overview. This video provides a general guide to unboxing and assembling a modern dining table, demonstrating the typical steps involved.

OPERATION

The CosmoLiving Astor Dining Table is designed for versatile use in your home. It comfortably seats up to 4 individuals, making it suitable for dining, family meals, or as a functional workspace.

- **Dining:** Ideal for daily meals and entertaining small groups.
- **Workspace:** Can be utilized as a spacious desk for computers and office supplies.
- **Weight Capacity:** The table has a maximum weight recommendation of 112 pounds. Avoid placing excessively heavy items on the tabletop.



Figure 3: Dining Table in Use. The table is shown in a kitchen setting, demonstrating its capacity for dining.

Your browser does not support the video tag.

Video 2: Product Overview. This video provides a general overview of the CosmoLiving Astor Dining Table, highlighting its design and features.

MAINTENANCE AND CARE

Proper care will help maintain the appearance and extend the life of your dining table.

- **Cleaning:** Wipe the table surface with a damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the faux marble finish.
- **Stain Resistance:** The table is **not** stain resistant. Promptly clean up spills to prevent staining.
- **Scratch Prevention:** The faux marble top can scratch easily. Use placemats, coasters, and protective pads under dishes and other objects to prevent scratches. Avoid sliding heavy or sharp objects across the surface.
- **Heat Protection:** Avoid placing hot items directly on the tabletop. Always use heat-resistant mats or trivets.
- **Leg Care:** Periodically check and tighten all leg connections to ensure stability.

TROUBLESHOOTING

If you encounter any issues with your CosmoLiving Astor Dining Table, refer to the following common solutions:

Problem	Possible Cause	Solution
Table is wobbly or unstable.	Loose connections; uneven floor.	Check and tighten all screws and bolts. Adjust foot pads if present, or place shims under legs on uneven surfaces.
Scratches appear on the tabletop.	Contact with sharp objects; lack of protective measures.	Use placemats, coasters, and avoid sliding items. Minor scratches may be reduced with specialized furniture polish, but prevention is key as the surface scratches easily.
Tabletop appears damaged upon arrival.	Shipping damage.	Inspect package upon delivery. If damage is noted, document with photos and contact the retailer immediately for assistance.
Stains on the faux marble top.	Spills not cleaned promptly; non-stain resistant material.	Clean spills immediately with a damp cloth. For persistent stains, consult a professional furniture cleaning guide for faux marble.

SPECIFICATIONS

Feature	Detail
Brand	CosmoLiving by Cosmopolitan
Model Name	Astor
Model Number	DA5014002CL
Product Dimensions (L x W x H)	64" x 36" x 30"
Item Weight	60 Pounds
Maximum Weight Recommendation	112 Pounds
Frame Material	Wood (Tabletop), Alloy Steel (Base)
Top Material Type	Faux Marble
Color	White (Top), Gold (Legs)
Shape	Rectangular
Seating Capacity	4
Assembly Required	Yes
Recommended People for Assembly	2
Tools Recommended for Assembly	Wrench (not included)
Product Care Instructions	Wipe with Damp Cloth

Feature	Detail
Stain Resistant	No

WARRANTY

The CosmoLiving Astor Dining Table comes with a **1-year limited warranty** from the manufacturer. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For specific details regarding warranty coverage and claims, refer to the documentation included with your product or contact the manufacturer directly.

CUSTOMER SUPPORT

For any questions, concerns, or assistance with your CosmoLiving Astor Dining Table, please contact the retailer from whom you purchased the product. They will be able to provide support or direct you to the appropriate manufacturer contact.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question