Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ChooChoo EUR-CT19003-WH

ChooChoo Farmhouse Coffee Table Instruction Manual

Model: EUR-CT19003-WH

1. Important Safety Information

Please read and understand all instructions before assembly and use. Retain this manual for future reference.

- **Tipping Hazard:** Ensure proper assembly and handling to prevent tipping. Always place the coffee table on a flat, stable surface.
- **Weight Limit:** Do not exceed the maximum weight recommendation of 80 pounds (36.3 kg) for the tabletop.
- **Children:** Keep small parts and packaging materials away from children during assembly. Do not allow children to climb on the table.
- **Tools:** Use only the recommended tools for assembly to avoid damage to the product or injury.

2. Package Contents

Verify that all components and hardware are present before beginning assembly. If any parts are missing or damaged, please contact customer support.



Figure 2.1: Exploded view of coffee table components.

The package includes all necessary hardware and tools for assembly. Each part and accessory is numbered for easy identification.

3. Assembly Instructions

Assembly is required for this coffee table. Detailed instructions are provided in the included manual. Follow the steps carefully to ensure correct and stable construction.

Recommended Tools:

- Hammer
- Screwdriver

General Assembly Steps:

1. Unpack all components and verify against the parts list.
2. Identify and separate the hardware.
3. Attach the side panels to the bottom shelf using the provided hardware.
4. Secure the top panel to the assembled base.
5. Ensure all screws are tightened, but do not overtighten.




Figure 3.1: Example of assembly hardware and tools.

4. Operating and Usage

The ChooChoo Farmhouse Coffee Table is designed for general use in living room settings, offering both decor and functionality.



Figure 4.1: ChooChoo Farmhouse Coffee Table in a living room.

- **Surface Use:** The spacious tabletop is suitable for holding beverages, books, remote controls, and decorative items.
- **Storage:** The decorative bottom shelf provides additional space for storage baskets, magazines, or display items.
- **Placement:** Position the table in your living area, ensuring it does not obstruct walkways.
- **Weight Distribution:** Distribute weight evenly across the tabletop and shelf to maintain stability.



Figure 4.2: Coffee table dimensions.

5. Maintenance and Care

Proper care will help maintain the appearance and longevity of your coffee table.

- **Cleaning:** Wipe the table surfaces with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Spills:** Clean spills immediately to prevent staining, especially on the painted surfaces.
- **Heat and Moisture:** Use coasters under hot or cold beverages to protect the tabletop from heat marks and moisture rings.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Inspections:** Periodically check and tighten all hardware to ensure the table remains stable.

6. Troubleshooting

If you encounter any issues with your coffee table, refer to the following common solutions:

- **Wobbling Table:** Check that all screws and bolts are securely tightened. Ensure the table is on a level surface. Adjust leg levelers if applicable (this model does not have them, but it's a general tip).
- **Missing Parts:** If any parts were missing upon delivery, refer to the 'Warranty and Support' section to contact customer service for replacements.
- **Surface Damage:** For minor scratches, touch-up pens or furniture markers matching the finish color may be used. For significant damage, contact customer support.

7. Specifications

Feature	Detail
Brand	ChooChoo
Model Number	EUR-CT19003-WH
Product Dimensions (L x W x H)	39.9" x 22.0" x 18.1" (101.3 cm x 55.9 cm x 46.0 cm)
Item Weight	17.6 Kilograms (38.8 lbs)
Maximum Weight Recommendation	80 Pounds (36.3 kg)
Frame Material	Wood (Natural Rubber Wood, Pine, MDF)
Color	White (Frame), Dark Brown (Top)
Shape	Rectangular
Table Design	Coffee Table
Style Name	Mission
Finish Type	Painted
Number of Shelves	1 (Bottom Shelf)
Required Assembly	Yes
UPC	759382137209

8. Warranty and Support

This ChooChoo product comes with a limited warranty. For specific details regarding warranty coverage, please refer to the documentation included with your purchase or contact customer support.

Customer Support:

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact ChooChoo customer service:

- **Email:** support@choochoofurniture.com (Example email, please refer to your manual for the exact address)
- **Website:** Visit the ChooChoo Store on Amazon

Please have your model number (EUR-CT19003-WH) and purchase date ready when contacting support.

© 2026 ChooChoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09F2PQ9JR

More documents and user manuals: **https://manuals.plus/**