

[Manuals.plus](#) /

› [PHI VILLA](#) /

› PHI VILLA Outdoor Rattan Dining Chairs Instruction Manual

PHI VILLA B09F31CKDJ

PHI VILLA Outdoor Rattan Dining Chairs Instruction Manual

Model: B09F31CKDJ

INTRODUCTION

Thank you for choosing PHI VILLA Outdoor Rattan Dining Chairs. This manual provides essential information for the safe assembly, operation, maintenance, and care of your new chairs. Please read it thoroughly before use and retain it for future reference.



Image: A complete set of four PHI VILLA outdoor rattan dining chairs arranged around a dining table on a patio.

SAFETY INFORMATION

- Ensure all parts are securely fastened before each use.
- Do not exceed the maximum weight capacity of 350 lbs per chair.
- Keep children away from the assembly area. Small parts can be a choking hazard.
- Place chairs on a flat, stable surface to prevent tipping.
- Avoid prolonged exposure to extreme weather conditions to extend product life.

PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. The package includes:

- Rattan Dining Chairs (4 units)
- Steel Frames (for 4 chairs)

- All necessary installation hardware (screws, washers, wrench)
- User Manual

SETUP AND ASSEMBLY

Assembly of the PHI VILLA Outdoor Rattan Dining Chairs is required. All necessary hardware and an instruction manual are included to facilitate easy assembly. Follow the step-by-step instructions provided in the separate assembly guide for detailed procedures.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify all parts and hardware using the provided parts list.
3. Attach the chair back to the seat frame using the specified screws.
4. Secure the armrests to the chair back and seat frame.
5. Attach the legs to the assembled seat and back frame.
6. Tighten all screws evenly. Do not overtighten until all parts are aligned.
7. Once fully assembled, gently rock the chair to ensure stability and then fully tighten all screws.



Image: A diagram illustrating the key dimensions of the chair, including its overall height of 41.3 inches, seat width, and depth, along with its 350 lbs weight capacity.

OPERATING INSTRUCTIONS

These chairs are designed for outdoor dining and seating. To use:

- Ensure the chair is placed on a stable, level surface.
- Sit gently into the chair, distributing your weight evenly.
- Avoid standing on the chair or using it as a step stool.
- Do not drag the chairs across rough surfaces; lift them to move.

Your browser does not support the video tag.

Video: This video demonstrates the features of the PHI VILLA Extra-Large Rattan Dining Chairs, highlighting their design and suitability for outdoor use.

MAINTENANCE

Proper maintenance will prolong the life and appearance of your PHI VILLA chairs.

- **Cleaning:** Wipe clean with a damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Frame Care:** The powder-coated steel frame is rust-resistant. Inspect regularly for any signs of rust or damage. Touch up any scratches to prevent rust.
- **Rattan Care:** The hand-woven rattan is UV and fade-resistant. To maintain its appearance, avoid prolonged direct sunlight when not in use, or cover the chairs.
- **Storage:** During off-season or inclement weather, store chairs in a dry, covered area to protect them from elements.



Image: A detailed view of the rattan material, highlighting its hand-woven texture, UV resistance, and water-resistant properties.

TROUBLESHOOTING

If you encounter any issues with your chairs, refer to the following common solutions:

- **Wobbling Chair:** Check all bolts and screws. Loosen them slightly, sit on the chair to settle it, then retighten evenly. Ensure the chair is on a level surface.
- **Loose Rattan:** If any rattan strands become loose, they can often be re-woven or secured with a small amount of outdoor-grade adhesive.
- **Rust Spots:** For minor rust spots on the steel frame, gently clean with a wire brush, then apply a rust-inhibiting primer and outdoor-grade paint.

Your browser does not support the video tag.

Video: This video demonstrates the quality testing procedures for PHI VILLA Rattan Chairs, including durability and fatigue tests for the seat, back, and armrests.

SPECIFICATIONS

Feature	Detail
Brand	PHI VILLA
Model Number	B09F31CKDJ
Color	Fixed-curved Armrest (Brown)

Material	Rattan, Steel Frame
Product Dimensions (D x W x H)	20.9" x 23.6" x 41.3"
Seat Height	15.7"
Maximum Weight Recommendation	350 Pounds
Assembly Required	Yes
Included Components	Installation Hardware, User Manual

WARRANTY AND SUPPORT

PHI VILLA is committed to providing high-quality products. For any questions, concerns, or warranty claims, please contact our customer support team. Details on specific warranty coverage are typically provided at the point of purchase or on our official website.

Please have your model number (B09F31CKDJ) and purchase information ready when contacting support.

Your browser does not support the video tag.

Video: This video provides an overview of the PHI VILLA Outdoor High-Back Large Wicker Chairs, showcasing their design and features in an outdoor setting.

© 2024 PHI VILLA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question