

[Manuals.plus](#) /

› [Sunbeam](#) /

› Sunbeam Microplush Queen Electric Heated Blanket Model 2152776 User Manual

Sunbeam 2152776

Sunbeam Microplush Queen Electric Heated Blanket

Model: 2152776

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Read all instructions before using this blanket.
2. Do not use with an infant, a child, an invalid, or any person insensitive to heat.
3. Do not use with a person who cannot operate the controls properly.
4. Do not use with an animal.
5. Do not use this blanket over, under, or around a waterbed.
6. Do not use this blanket if it is wet.
7. Do not use this blanket in conjunction with another heating pad or blanket.
8. Do not use this blanket if the cord or plug is damaged.
9. Do not use an extension cord or power strip with this blanket. Plug directly into a wall outlet.
10. Always disconnect the controller from the wall outlet before washing.
11. This blanket is approved by a 3rd party (UL or ETK Intertek) to comply with industry safety standards.

PRODUCT FEATURES

The Sunbeam Microplush Electric Heated Blanket is designed to provide warmth and comfort with advanced features:

- **Luxurious Microplush Fabric:** Ultra-soft 100% polyester material for enhanced comfort.
- **ThermoFine Technology:** Automatically adjusts for consistent heat control.
- **10 Heat Settings:** Allows for personalized warmth levels.
- **Two Digital Controllers:** Independent control for each side of the Queen-sized blanket.
- **10-Hour Auto-Off:** Automatically shuts off after 10 hours for safety and peace of mind.
- **Preheat Setting:** Warms up cold sheets before bedtime.
- **Machine Washable:** Easy to clean and maintain.



Image: Sunbeam Microplush Queen Electric Heated Blanket in Garnet color, unfolded on a bed, showcasing its soft texture and rich hue.

SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove the blanket and controllers from the packaging. Retain packaging for storage if desired.
2. **Position the Blanket:** Place the heated blanket on your bed with the label at the foot of the bed. Ensure the blanket is spread evenly and smoothly, avoiding any folds, creases, or bunching. The heating wires should not be compressed.

3. **Connect Controllers:** For Queen size blankets, there are two controllers. Locate the connector on the blanket at the foot end. Firmly plug each controller cord into its respective connector on the blanket. Ensure a secure connection.
4. **Plug into Power:** Plug the power cord of each controller directly into a 120V AC wall outlet. Do not use extension cords, power strips, or surge protectors.

OPERATING INSTRUCTIONS

1. **Turning On:** Press the 'Power' button on the digital controller. The display will illuminate, showing the current heat setting.
2. **Adjusting Heat Settings:** Use the '+' or '-' buttons to select your desired heat level from 1 to 10. Setting 1 is the lowest heat, and 10 is the highest.
3. **Preheat Function:** To preheat your bed, turn on the blanket to your desired heat setting approximately 15-30 minutes before use.
4. **Auto-Off Feature:** The blanket is designed to automatically shut off after 10 hours of continuous operation. To restart, simply press the 'Power' button again.
5. **Using Two Controllers:** For Queen size blankets, each controller operates its respective side of the blanket independently. Adjust each controller to suit individual preferences.
6. **Turning Off:** Press the 'Power' button again to turn off the blanket. The display will turn off. For extended periods of non-use, unplug the controllers from the wall outlet.

CARE AND MAINTENANCE

Proper care ensures the longevity and performance of your heated blanket.

1. **Before Washing:** Always disconnect the power cords from the wall outlet and then detach the controllers from the blanket. Ensure all cords are completely removed.
2. **Machine Washing:** Machine wash the blanket in cold water on a gentle or delicate cycle. Do not bleach.
3. **Rinsing:** Rinse in cold water on a normal cycle.
4. **Drying:** Tumble dry on low heat for 5-10 minutes. Remove while still damp and gently stretch to original size. Drape over a clothesline or shower rod to finish drying. Do not iron. Do not dry clean.
5. **Storage:** When not in use, store the blanket in its original bag or a breathable container in a cool, dry place. Avoid tightly folding or creasing the blanket, as this can damage the internal wiring.
6. **Controller Cleaning:** Wipe controllers with a damp cloth. Do not immerse controllers in water.

TROUBLESHOOTING

If your heated blanket is not operating correctly, please refer to the following common issues and solutions:

- **Blanket Not Heating:**
 - Ensure the power cord is securely plugged into a functional wall outlet.
 - Verify that the controller cord is firmly connected to the blanket.
 - Check if the controller is turned on and a heat setting is selected.

- Unplug the blanket from the wall outlet for 5 minutes, then plug it back in to reset the system.
- **Controller Display Not Working:**
 - Confirm the blanket is plugged into a live wall outlet.
 - Ensure the controller is securely connected to the blanket.
- **Blanket Feels Too Hot or Not Hot Enough:**
 - Adjust the heat setting using the '+' or '-' buttons on the controller.
 - Allow 15-30 minutes for the blanket to reach the desired temperature.
- **Error Codes:** If an error code appears on the controller display, unplug the blanket from the wall outlet for 5 minutes, then plug it back in. If the error persists, contact customer support.

SPECIFICATIONS

Model Number	2152776
Size	Queen (90"L x 84"W)
Material	100% Polyester Microplush
Color	Garnet
Heat Settings	10
Auto-Off Timer	10 Hours
Controllers	Two Digital Controllers
Safety Certification	UL or ETK Intertek Approved

WARRANTY AND SUPPORT

This Sunbeam Microplush Electric Heated Blanket is covered by a **5-year limited manufacturer's warranty**.

For warranty claims, technical assistance, or further inquiries, please:

- Visit the official Sunbeam website for detailed warranty information and contact options.
- Refer to the contact information provided on your product packaging or warranty card.

Please have your model number (2152776) and proof of purchase available when contacting support.

