

[manuals.plus](#) /› [Osmo](#) /› [Osmo Liquid Wax Cleaner 3029 Clear - Instruction Manual](#)**Osmo 3029**

# Osmo Liquid Wax Cleaner 3029 Clear - Instruction Manual

Model: 3029 | Brand: Osmo

## 1. PRODUCT OVERVIEW

The Osmo Liquid Wax Cleaner 3029 Clear is a specialized 400 ml spray designed for the initial cleaning, occasional refreshing, and ongoing maintenance of wooden floors, furniture, and other wood surfaces treated with Osmo Polyx-Oil or similar conventional wood finishes. This cleaner is formulated with natural vegetable waxes, providing both cleaning and regeneration for the wood surface simultaneously. Its easy-to-use spray application ensures quick and economical coverage, treating approximately 850-1000 square feet per liter. The product dries within 30-40 minutes.





# Liquid Wax Cleaner Spray

For oiled and waxed wood and cork floors,  
furniture and other wood surfaces.

0.4 Liter (13.5 Fl. Oz.)



Safe for humans,  
animals and plants  
(when dry)



Substance for  
children's toys

Substance for  
children's toys  
according to DIN EN 71.3, test to perspiration and saliva

Image 1: Osmo Liquid Wax Cleaner 3029 Clear 400 ml Spray bottle. This image shows the product packaging, a white spray can with a yellow and black label, indicating its use for wood cleaning and maintenance.

## 2. SAFETY INFORMATION

Always read the label and product information before use. Keep out of reach of children and pets. Use in a well-ventilated area. Avoid contact with eyes and skin. In case of contact, rinse immediately with plenty of water. If swallowed, seek medical advice immediately and show this container or label. Wear appropriate protective gloves and eye/face protection during application. Do not mix with other cleaning agents.

## 3. SETUP AND PREPARATION

- **Surface Preparation:** Ensure the wooden surface is free from loose dirt and dust. Vacuum or sweep the area thoroughly before application.
- **Ventilation:** Open windows and doors to ensure adequate ventilation in the work area.
- **Test Area:** Always test the product on an inconspicuous area of the surface to be treated to ensure compatibility and desired results.
- **Shake Well:** Shake the spray can thoroughly before use to ensure proper mixing of ingredients.

## 4. OPERATING INSTRUCTIONS

1. **Application:** Spray the Osmo Liquid Wax Cleaner thinly and evenly onto the clean, dry wooden surface from a distance of approximately 20-30 cm.
2. **Spreading:** Immediately after spraying, spread the cleaner evenly with a lint-free cloth or Osmo Microfibre Pad, working along the wood grain.
3. **Wiping:** Wipe off any excess product to avoid streaks or uneven shine. Ensure the surface is uniformly covered.
4. **Drying Time:** Allow the surface to dry for approximately 30-40 minutes. Ensure good ventilation during the drying process.
5. **Repeat (if necessary):** For heavily soiled areas or for an intensified refresh, a second application may be performed after the first coat has completely dried.

**Note:** For best results, apply sparingly. Over-application can lead to a sticky surface or uneven finish.

## 5. MAINTENANCE AND CARE

Regular use of Osmo Liquid Wax Cleaner helps maintain the beauty and durability of your wooden surfaces. For routine cleaning between applications, use a damp cloth with water or a mild, pH-neutral wood cleaner. Avoid abrasive cleaners or harsh chemicals that can damage the wood finish. Reapply the Liquid Wax Cleaner as needed, typically every few months, depending on traffic and wear.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Streaks or uneven finish	Over-application or insufficient wiping.	Apply less product and wipe immediately and thoroughly with a clean, lint-free cloth. For existing streaks, reapply a small amount of cleaner to the affected area and wipe immediately.
Sticky surface after drying	Too much product applied, not enough ventilation during drying.	Ensure thin, even application and good ventilation. If already sticky, try wiping the surface with a cloth lightly dampened with mineral spirits (test in an inconspicuous area first) to remove excess wax, then reapply correctly.
Product not cleaning effectively	Surface too dirty, product not shaken well.	Ensure surface is thoroughly cleaned of loose dirt before application. Shake the can well before each use. For very stubborn dirt, a more intensive cleaning product may be required before using the wax cleaner.

## 7. PRODUCT SPECIFICATIONS

---

**Brand:** Osmo

**Model:** 3029 Clear

**Item Form:** Liquid, Spray

**Scent:** Natural, Wood

**Specific Uses:** Floors, Furniture

**Material Feature:** Natural vegetable waxes

**Volume:** 400 ml

**Coverage:** Approximately 850-1000 square feet per liter

**Drying Time:** 30-40 minutes

**Manufacturer:** OSMO

**ASIN:** B09F5Y7V48

**Date First Available:** October 31, 2018

## 8. STORAGE AND DISPOSAL

---

Store the product in a cool, dry place, away from direct sunlight and extreme temperatures. Keep the container tightly closed when not in use. Dispose of contents/container in accordance with local regulations. Do not empty into drains or watercourses.

## 9. CONTACT AND SUPPORT

---

For further assistance, questions, or technical support regarding your Osmo Liquid Wax Cleaner 3029 Clear, please visit the official Osmo website or contact their customer service department. Refer to the product packaging for specific contact details or visit [www.osmo.de/en/](http://www.osmo.de/en/) for more information.