

[Manuals.plus](#) /

› [Suright](#) /

› Suright LED Clip-On Book Reading Light (Model LD200-WH) - User Manual

## Suright LD200-WH

# Suright LED Clip-On Book Reading Light (Model LD200-WH) - User Manual

Model: LD200-WH | Brand: Suright

### INTRODUCTION

Thank you for choosing the Suright LED Clip-On Book Reading Light, Model LD200-WH. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.

### SAFETY INSTRUCTIONS

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Keep out of reach of children.
- Use only the provided USB cable for charging.
- Do not disassemble or attempt to repair the device yourself. Contact customer support if service is required.
- Avoid direct eye exposure to the LED light for prolonged periods.

### PACKAGE CONTENTS

Please check the package for the following items:

- 1 x Suright LED Clip-On Book Reading Light (Model LD200-WH)
- 1 x USB Charging Cable
- 1 x User Manual

### PRODUCT OVERVIEW

The Suright LED Clip-On Book Reading Light features a flexible gooseneck, a sturdy clip, and a touch-sensitive control panel for easy operation.

# Eye-protection Book Light

Emits natural and soft light, effectively protecting your eyes



*Image: The Suright LED Clip-On Book Reading Light providing illumination for reading.*

- **LED Panel:** Contains 9 LEDs for illumination.
- **Flexible Gooseneck:** Allows 360-degree adjustment of the light direction.
- **Clip:** Securely attaches the light to books, desks, or other surfaces. Features anti-skid pads.
- **Touch Control Button:** Located on the light head for power, color mode, and brightness adjustments.
- **USB Charging Port:** Located on the base for recharging the internal battery.

## SETUP

---

### 1. Charging the Battery

Before first use, fully charge the reading light. Connect the provided USB charging cable to the charging port on the base of the light and to a standard USB power source (e.g., phone charger, computer USB port, power bank).



Phone Charger



Car Charger



Laptop



Power Bank

# USB RECHARGEABLE BATTERY



•   
Red Light:  
Charging



•   
Green Light:  
Full Charged

*Image: USB charging port and indicator lights. A red light indicates charging, a green light indicates a full charge.*

- A **red indicator light** will illuminate during charging.
- The indicator light will turn **green** when the battery is fully charged.

## 2. Attaching the Light

The light features a strong clip with anti-skid pads to prevent damage and ensure stability.



*Image: The flexible gooseneck and adjustable clip, capable of opening up to 4cm (1.57 inches).*

- Open the clip and attach it to the edge of your book, desk, headboard, or any suitable surface.
- Ensure the clip is securely fastened to prevent the light from falling.

## OPERATING INSTRUCTIONS

---

### 1. Power On/Off and Changing Color Modes

The light features a single touch-sensitive button on the head for control.



# 9 LEDs BOOK LIGHT

3 COLOR LIGHTING MODES

Touch Sensitive Control

Short Tap To Change Modes



Warm Light-4 LEDs



White Light- 5 LEDs



Warm&White Light-9 LEDs

Image: Touch control for changing light modes.

1. **To Power On:** Short tap the touch control button. The light will turn on in the last used mode.
2. **To Change Color Mode:** Short tap the touch control button repeatedly to cycle through the 3 available color modes:
  - **Warm Light:** 4 LEDs (Yellowish tone, ideal for relaxing reading)
  - **White Light:** 5 LEDs (Cooler tone, suitable for focused tasks)
  - **Mixed Light:** 9 LEDs (Combination of warm and white, natural light effect)
3. **To Power Off:** Continue short tapping until the light turns off, or long press the button.

## 2. Adjusting Brightness (Stepless Dimming)

Each color mode offers stepless brightness adjustment from 20% to 100%.



# Stepless Dimmable Design






Tap and long touch  
to adjust brightness level



Warm White/Cool White/Natural Light Choosable



Stepless Adjustable Brightness For Each Color Mode



20%



100%

*Image: Long touch for stepless brightness adjustment.*

- While the light is on, **long press** the touch control button.
- The brightness will gradually increase or decrease. Release the button when the desired brightness level is reached.
- The light will remember your last brightness setting for each color mode.

## 3. Adjusting the Flexible Gooseneck

The 360-degree flexible gooseneck allows you to position the light precisely where needed.

# 9 Lampe de lecture à DEL

avec contrôle tactile sensible



3 Modes couleurs



Protection des yeux



Chargement USB



Gradation en continu

Image: The flexible gooseneck allows for 360-degree rotation and bending.

- Gently bend and twist the gooseneck to direct the light beam.
- Avoid excessive force or sharp bends to prevent damage.

## MAINTENANCE

- **Cleaning:** Wipe the light with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the light in a cool, dry place. Ensure the battery is partially charged before storage to prolong its lifespan.
- **Battery Care:** Recharge the battery regularly, even if not in frequent use, to maintain battery health.

## TROUBLESHOOTING

| Problem                                 | Possible Cause                | Solution                                                                                    |
|-----------------------------------------|-------------------------------|---------------------------------------------------------------------------------------------|
| Light does not turn on.                 | Battery is depleted.          | Charge the light using the USB cable.                                                       |
| Light flickers or dims unexpectedly.    | Low battery.                  | Recharge the light.                                                                         |
| Cannot change color mode or brightness. | Touch control not responding. | Ensure your finger is clean and dry. Try a short press for mode, long press for brightness. |
| Light does not charge.                  | Faulty cable or power source. | Try a different USB cable or power adapter. Ensure connections are secure.                  |

## SPECIFICATIONS

| Feature | Detail |
|---------|--------|
|---------|--------|

| Feature                | Detail                                          |
|------------------------|-------------------------------------------------|
| Model Number           | LD200-WH                                        |
| Light Source           | 9 LEDs (4 Warm, 5 Cool White)                   |
| Color Modes            | 3 (Warm, White, Mixed)                          |
| Brightness Adjustment  | Stepless Dimming (20%-100%)                     |
| Gooseneck Flexibility  | 360 Degrees                                     |
| Power Source           | USB Rechargeable Battery (1 CR2 included)       |
| Voltage                | 3.7 Volts                                       |
| Wattage                | 2.22 Watts                                      |
| Material               | Silicone                                        |
| Dimensions (L x W x H) | 33 x 3.9 x 3 cm (approx. 13 x 1.5 x 1.2 inches) |
| Weight                 | 55 Grams (approx. 1.94 ounces)                  |
| UPC/GTIN               | 650380363129                                    |





*Image: Product dimensions.*

## **WARRANTY AND SUPPORT**

---

Suright products are designed for reliability and performance. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Suright website. Please have your model number (LD200-WH) and purchase date available when contacting support.