

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Westinghouse](#) /
- › [Westinghouse Heated Throw Blanket \(Model WH-HSF50\), Charcoal, 50x60 inch - Instruction Manual](#)

Westinghouse WH-HSF50

Westinghouse Heated Throw Blanket

Model: WH-HSF50 | Size: 50x60 inch | Color: Charcoal

1. INTRODUCTION

Thank you for choosing the Westinghouse Heated Throw Blanket. This manual provides essential information for the safe and efficient use of your new electric blanket. Please read all instructions carefully before use and retain for future reference.



Image 1: Westinghouse Heated Throw Blanket, Charcoal, 50x60 inch.

2. IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of burns, electric shock, fire, or injury, this product must be used in accordance with the following instructions:

- Read all instructions before using this heated blanket.
- Do not use with an infant, child, incapacitated person, or anyone insensitive to heat.
- Do not use if the outer fabric is damaged or torn.
- Never use pins or other metallic objects with this blanket. They may damage the wiring.
- Do not use if wet.
- Always unplug the blanket when not in use.
- Do not use this blanket with a generator, power converter, or inverter.
- Keep the control unit away from open windows or direct sunlight to prevent overheating.
- This blanket is equipped with an overheat protection system for your safety. It is ETL and FCC certified.

3. SETUP

1. **Unpack:** Carefully remove the heated blanket from its packaging.
2. **Inspect:** Check the blanket and the control unit for any signs of damage. Do not use if damaged.
3. **Connect Controller:** Locate the connector on the blanket and firmly plug in the control unit. Ensure a secure connection.
4. **Power On:** Plug the power cord into a standard 120V AC electrical outlet.



Image 2: Digital Controller for the Heated Blanket.

4. OPERATING INSTRUCTIONS

Your Westinghouse Heated Throw Blanket features a user-friendly controller with multiple heat levels and timer settings.

4.1 Power On/Off

- Press the power button on the controller to turn the blanket on or off.

4.2 Heat Settings

- The blanket offers 6 heat levels. Use the '+' and '-' buttons to adjust the heat intensity to your preference.
- The current heat level will be displayed on the digital screen.

4.3 Timer Settings

- The blanket includes a timer function for automatic shut-off. Available settings are 2, 4, 8, and 10 hours.
- Press the 'TIME' button to cycle through the available timer options. The selected time will be displayed.
- The blanket will automatically turn off after the set time has elapsed. This feature is designed to complement manual shut-off.



Image 3: Blanket draped over a chair, illustrating versatile use and timer settings.

4.4 Fabric and Comfort

The blanket features a dual-sided design with ultra-soft flannel on one side and cozy sherpa fleece on the other, providing warmth and excellent insulation.

5. CARE AND MAINTENANCE

Proper care ensures the longevity and performance of your heated blanket.

5.1 Cleaning Instructions

1. **Disconnect:** Always turn off and unplug the blanket from the wall outlet.
2. **Detach Controller:** Carefully detach the control unit from the blanket.
3. **Machine Wash:** The blanket is machine washable. Use a cold wash cycle.
4. **Drying:** Tumble dry on low heat or line dry. Do not iron or dry-clean.



Image 4: Care instructions for machine washing the blanket.

6. TROUBLESHOOTING

If your heated blanket is not operating correctly, please refer to the following common issues and solutions:

- **Blanket not heating:** Ensure the control unit is securely connected to the blanket and the power cord is firmly plugged into a working electrical outlet. Check if the auto shut-off timer has expired.
- **Controller display not working:** Unplug the blanket from the wall outlet for a few minutes, then plug it back in. If the issue persists, ensure all connections are secure.
- **Uneven heating:** The blanket is designed for even heat distribution. If you experience uneven heating, ensure the blanket is laid flat and not bunched up.
- **Overheat protection activated:** If the blanket feels excessively hot or shuts off unexpectedly, the overheat protection system may have activated. Unplug the blanket and allow it to cool down before attempting to use it again.

If problems persist after following these steps, please contact customer support.

7. SPECIFICATIONS

Brand	Westinghouse
Model Name	WH-HSF50
Product Dimensions	50"L x 60"W
Material	Flannel, Polyester, Sherpa
Color	Charcoal
Heat Levels	6
Timer Settings	2, 4, 8, 10 Hours
Special Feature	Breathable, Overheat Protection
Product Care Instructions	Machine Wash
Item Weight	3.96 pounds



WARMING BLANKET

ULTRA SOFT AND SILKY FLANNEL



Machine Washable
Easy Care



Saves Energy by
Lowering Thermostat



Ultra Soft & Cozy

TECHNICAL SPECIFICATION:
ELECTRIC THROW
VOLTAGE: 120V AC
HERTZ: 60 HZ
WATTS: 100W



Image 5: Westinghouse Warming Blanket with technical specifications.

8. WARRANTY AND SUPPORT

Westinghouse provides a good after-sales guarantee for this product. For any issues, questions, or support needs, please refer to the contact information provided with your purchase or visit the official Westinghouse website.

Video 2: Overview of the Westinghouse Electric Throw Blanket.