

[Manuals.plus](#) /

› [Vssoplor](#) /

› Vssoplor Wireless Mouse MS001 Instruction Manual

Vssoplor MS001

Vssoplor Wireless Mouse MS001 Instruction Manual

Model: MS001

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Vssoplor Wireless Mouse MS001. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

2. PACKAGE CONTENTS

- 1 x Vssoplor Wireless Mouse
- 1 x USB Nano Receiver
- 1 x User Manual

3. SETUP GUIDE

3.1. Installing the Battery

1. Locate the battery compartment on the underside of the mouse.
2. Gently slide the battery cover open.
3. Insert one AA battery (not included) into the compartment, ensuring correct polarity (+/-).
4. Close the battery cover until it clicks securely into place.



Image: Underside of the mouse with the battery compartment and USB nano receiver slot.

3.2. Connecting the USB Nano Receiver

1. Remove the USB nano receiver from its storage slot on the underside of the mouse.
2. Plug the USB nano receiver into an available USB port on your computer or laptop.
3. The computer will automatically detect and install the necessary drivers. This process may take a few moments.
4. Turn on the mouse using the power switch located on the underside.



ERGONOMIC DESIGN

For comfortable hand-feeling

Image: USB nano receiver connected to a laptop, demonstrating wireless connectivity.
Your VssoPlor Wireless Mouse is now ready for use.

4. OPERATING INSTRUCTIONS

4.1. Basic Functions

- **Left Click:** Primary function for selecting items, opening files, etc.
- **Right Click:** Secondary function for context menus and additional options.
- **Scroll Wheel:** Roll up or down to navigate through documents and web pages. The scroll wheel also functions as a middle click button.



Image: Top view of the VssoPlor Wireless Mouse, highlighting its sleek design.

4.2. Silent Clicking

The VssoPlor Wireless Mouse features silent click buttons, designed to reduce noise during use. This allows for a quiet working environment, minimizing disturbance to others.



Image: Mouse with noiseless click feature, suitable for quiet environments.

4.3. Ergonomic Design

The mouse is designed with an ergonomic shape to provide a comfortable grip and reduce hand fatigue during extended use.



HIGH PRECISION
1600 DPI

Image: Ergonomic design of the mouse for comfortable hand-feeling.

4.4. Intelligent Sleep Mode

To conserve battery life, the mouse will automatically enter sleep mode after 5 minutes of inactivity. To wake the mouse, simply click any button. This feature helps extend the battery life up to 18 months.

5. MAINTENANCE

5.1. Cleaning

- Use a soft, dry cloth to clean the exterior of the mouse.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the surface.
- For the optical sensor, use a cotton swab lightly dampened with rubbing alcohol to gently clean the sensor area. Ensure the mouse is powered off before cleaning.

5.2. Battery Replacement

When the mouse performance degrades or it becomes unresponsive, it is likely time to replace the battery. Follow the steps in Section 3.1 to replace the AA battery.

5.3. Storage

When not in use for an extended period, it is recommended to turn off the mouse using the power switch and store the USB nano receiver in its designated slot on the underside of the mouse to prevent loss.

6. TROUBLESHOOTING

6.1. Mouse Not Responding

- **Check Battery:** Ensure the battery is correctly installed and has sufficient charge. Replace if necessary.
- **Power Switch:** Verify that the mouse is powered on.
- **Wake from Sleep:** If the mouse is in sleep mode, click any button to wake it up.

6.2. Connection Issues

- **Receiver Connection:** Ensure the USB nano receiver is securely plugged into a working USB port on your computer. Try a different USB port.
- **Distance:** The effective operating range is up to 10 meters (33 feet). Ensure the mouse is within this range and there are no significant obstructions.
- **Interference:** Other wireless devices operating on the 2.4GHz frequency might cause interference. Try moving the mouse or receiver away from other wireless devices.
- **Re-pairing:** In rare cases, the mouse and receiver might lose their connection. Re-plug the receiver and turn the mouse off and on.

6.3. Erratic Cursor Movement

- **Surface:** Ensure you are using the mouse on a suitable surface. Highly reflective or uneven surfaces can affect tracking. A mouse pad is recommended.
- **Sensor Cleanliness:** Clean the optical sensor on the underside of the mouse as described in Section 5.1.

7. SPECIFICATIONS

Feature	Detail
Model Number	MS001
Connectivity Technology	2.4G Wireless
Movement Detection	Optical
DPI	1600 DPI (Fixed)
Operating Range	Up to 10 meters (33 feet)
Battery Type	1 x AA Battery (not included)
Battery Life	Up to 18 months (depending on usage)
Product Dimensions	0.79 x 1.18 x 0.5 inches
Item Weight	2.89 ounces
Compatibility	Windows 7/8/10/XP, Vista, Mac OS X 10.4 and above



Image: Top view of the mouse and receiver, illustrating compact design.

8. WARRANTY AND SUPPORT

8.1. Warranty Information

VssoPlor products typically come with a manufacturer's warranty. For specific warranty terms and conditions, please refer to the product packaging or contact the seller directly. Keep your purchase receipt as proof of purchase for warranty claims.

8.2. Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact VssoPlor customer support through the retailer where you purchased the product or visit the official VssoPlor website for contact information.

