

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [SYNLETT](#) /

› [SYNLETT Wireless Call Button F007W User Manual](#)

SYNLETT F007W

SYNLETT Wireless Call Button F007W User Manual

Model: F007W

1. INTRODUCTION

The SYNLETT Wireless Call Button F007W is an accessory designed to work with a compatible SYNLETT central monitoring unit (e.g., Q034G-F007). It allows individuals to signal caregivers or service staff for assistance remotely with a simple press of the button. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 2 x Call Buttons (F007W)
- 2 x 12V 23A Batteries
- 2 x Call Button Mounting Brackets
- 2 x Lanyard Straps
- 2 x Double-Sided Adhesive Tapes



Image 2.1: The package includes two call buttons, two batteries, two mounting brackets, two lanyards, and two adhesive tapes.

3. SETUP

3.1. Call Button Battery Installation

The call button requires a 12V 23A battery (included). Follow these steps to install the battery:

1. Locate the small slot on the side of the call button.
2. Carefully insert a mini flathead screwdriver into the slot at a 45-degree angle.
3. Gently twist the screwdriver to pry open the call button cover.
4. Place the 12V 23A battery into the battery compartment, ensuring correct polarity.
5. Align the cover with the base, ensuring the lanyard post (if applicable) is correctly positioned.
6. Snap the cover back into place, applying gentle pressure until it clicks securely.



Image 3.1: Two SYNLETT Wireless Call Buttons, one with an attached lanyard, ready for battery installation.

Video 3.1: Instructions on how to remove the call button cover and place the battery. This video demonstrates the process of opening the call button casing, inserting the battery, and securely closing it.

3.2. Mounting Options

The call button offers versatile mounting options:

- **Wall Mount:** Use the provided mounting bracket and screws to fix the button to a wall, such as bedside or in a bathroom.
- **Adhesive Mount:** Affix the button to most smooth and clean surfaces using the included double-sided adhesive tapes.
- **Wearable Pendant:** Attach the lanyard strap to the call button to wear it around the neck for easy access.

Call Button



Image 3.2: Visual representation of the various mounting methods for the call button, including lanyard, screw-in wall mount, and adhesive patch mounting.

3.3. Pairing with Central Monitoring Unit

The call button (F007W) MUST be paired to a SYNLETT central monitoring unit (e.g., Q034G-F007) before it can function properly. Refer to your central monitoring unit's manual for specific pairing instructions.

Generally, the process involves:

1. Ensure the central monitoring unit is powered on and in 'unlocked' mode.
2. Activate the pairing mode on the central monitoring unit (usually by long-pressing a 'REPLACE/ADD' button until a melodic tone is heard).
3. Quickly press the call button you wish to pair. The monitoring unit should acknowledge the pairing (e.g., display a number or emit a beep).
4. Exit pairing mode on the central monitoring unit (usually by pressing a 'CLEAR' or 'REPLACE/ADD' button again).

3.4. Pairing SYNLETT Wireless Motion Sensor (Optional Accessory)

If you are using a SYNLETT wireless motion sensor as an additional component, it also needs to be paired with the central monitoring unit. Ensure the motion sensor has its batteries installed and its antenna fully extended for optimal signal range.

Video 3.3: This video demonstrates how to program a SYNLETT wireless motion sensor to the central monitoring unit. It covers battery installation for the motion sensor, extending its antenna, and the pairing sequence with the main unit.

3.5. Connecting Two Monitoring Units (Optional)

For extended coverage or dual monitoring, two SYNLETT central monitoring units can be connected and paired to the same call buttons. Ensure both units are powered and in 'unlocked' mode before initiating the pairing process for each call button with both units.

Video 3.4: This video provides instructions on how to connect and pair two SYNLETT central monitoring units together, allowing them to respond to the same call buttons.

4. OPERATING INSTRUCTIONS

4.1. Making a Call

To signal for assistance, simply press the 'CALL' button on the F007W unit. The central monitoring unit will receive the signal and display the corresponding number, often accompanied by an audible alert.

4.2. Clearing Calls with a Clear Call Button (Accessory)

If you have a SYNLETT clear call button (e.g., F007A), you can remotely clear all active calls on the central monitoring unit. This accessory must also be paired with the monitoring unit.

Video 4.1: This video demonstrates the functionality of the SYNLETT clear call button, showing how it can be used to remotely clear calls on the central monitoring unit after being paired.

5. MAINTENANCE

- **Cleaning:** Wipe the call button with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Battery Replacement:** Replace the 12V 23A battery when the LED indicator on the call button no longer lights up or the signal strength diminishes. Refer to Section 3.1 for battery installation.
- **Storage:** Store the device in a cool, dry place when not in use for extended periods.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Call button not responding	Low or dead battery	Replace the 12V 23A battery (see Section 3.1).
Call button not responding	Not paired with monitoring unit	Ensure the call button is correctly paired with the central monitoring unit (see Section 3.3).
Intermittent signal	Distance or obstructions	Reduce distance between call button and monitoring unit. Remove obstructions like thick walls or metal objects.
Monitoring unit not receiving calls	Monitoring unit is in 'locked' mode	Switch the monitoring unit to 'unlocked' mode.

Problem	Possible Cause	Solution
---------	----------------	----------

7. SPECIFICATIONS

Feature	Specification
Model Number	F007W
Brand	SYNLETT
Voltage	12 Volts (DC)
Control Method	Touch
Mounting Type	Wall Mount
UPC	768564518606
Item Weight	3.52 ounces
Product Dimensions	2.17 x 2.17 x 0.83 inches
Batteries Required	2 x 12V batteries (included)
Special Features	Push Call Button

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your SYNLETT central monitoring unit or visit the official SYNLETT website. Keep your purchase receipt for warranty claims.