

Glacier Bay Dunning Single-Handle Pull-Out Laundry Faucet

Glacier Bay Dunning Single-Handle Pull-Out Laundry Faucet User Manual

Model: Dunning Single-Handle Pull-Out Laundry Faucet (d670335c-0b0b-4252-b3c1-632ead6380c7)

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Glacier Bay Dunning Single-Handle Pull-Out Laundry Faucet. Please read this manual thoroughly before installation and retain it for future reference. Proper installation and care will ensure optimal performance and longevity of your faucet.

2. SAFETY INFORMATION

- Always turn off the main water supply before beginning any installation or repair work.
- Wear appropriate personal protective equipment, such as safety glasses, during installation.
- Ensure all local plumbing and building codes are followed.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Do not overtighten connections, as this may cause damage to the faucet or plumbing.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation. If any parts are missing or damaged, contact customer service.

- Faucet Body with Pull-Out Spray Head
- Mounting Hardware (washer, nut, screws)
- Hot and Cold Water Supply Lines (pre-attached or separate)
- Deck Plate (optional, for 3-hole sinks)
- Weight for Pull-Out Hose
- Installation Instructions



Figure 1: Overview of the Glacier Bay Dunning Single-Handle Pull-Out Laundry Faucet. This image displays the faucet body, single handle, and the pull-out spray head in its docked position, all in a polished chrome finish.

4. TOOLS REQUIRED

The following tools are typically required for installation:

- Adjustable Wrench
- Phillips Head Screwdriver
- Basin Wrench (optional, for tight spaces)
- Plumber's Putty or Silicone Sealant
- Flashlight
- Bucket and Towel

5. SETUP AND INSTALLATION

5.1 Prepare the Sink Area

1. Turn off the hot and cold water supply valves under the sink. If no shut-off valves are present, turn off the main water supply to the house.
2. Remove the old faucet, if applicable. Clean the sink surface thoroughly.

5.2 Install the Faucet

1. If your sink has three holes, place the deck plate (if included) over the sink holes. Apply a thin bead of plumber's putty or silicone sealant around the base of the deck plate to create a watertight seal.
2. Insert the faucet body through the center hole of the sink (and deck plate, if used). Ensure the faucet is oriented correctly.
3. From underneath the sink, secure the faucet using the provided mounting washer and nut. Hand-tighten first, then use a basin wrench or adjustable wrench to tighten securely. Do not overtighten.
4. Connect the hot and cold water supply lines from the faucet to the corresponding hot and cold water supply valves. Hand-tighten, then use an adjustable wrench for a final quarter-turn.
5. Install the hose weight onto the pull-out hose, typically about 6 inches from the bottom of the spray head connection. This weight helps the spray head retract properly.



Figure 2: Close-up view of the faucet base and single handle. This image highlights the polished chrome finish and the design of the handle, which controls both water temperature and flow.

5.3 Test the Faucet

1. Slowly turn on the hot and cold water supply valves.
2. Check all connections for leaks. If leaks are present, tighten the connections slightly until the leak stops.
3. Remove the spray head and turn on the faucet to flush out any debris from the supply lines. Let the water run for approximately one minute.
4. Reattach the spray head.

6. OPERATING INSTRUCTIONS

6.1 Water Flow and Temperature Control

- The single handle controls both water flow and temperature.

- To turn on the water and control flow, lift the handle upwards. The further you lift, the greater the water flow.
- To adjust water temperature, move the handle left for hot water and right for cold water.

6.2 Dual Spray Function

- The pull-out spray head features a dual spray function.
- To switch between stream and spray modes, press the button located on the spray head.
- After use, gently guide the spray head back into the faucet spout until it docks securely.

7. MAINTENANCE

7.1 Cleaning the Faucet

- Clean the faucet regularly with a soft cloth and mild soap.
- Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the chrome finish.
- Rinse thoroughly with water and dry with a soft cloth to prevent water spots.

7.2 Aerator Maintenance

- If water flow decreases, the aerator may be clogged.
- Unscrew the aerator from the tip of the spray head.
- Rinse any debris from the screen and reassemble.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed supply valves.	Clean aerator; fully open supply valves.
Leaks from Faucet Base	Loose mounting nut; improper sealant application.	Tighten mounting nut; reapply plumber's putty/sealant.
Leaks from Supply Line Connections	Loose connections; damaged O-rings.	Tighten connections; replace O-rings if damaged.
Spray Head Does Not Retract Fully	Hose weight improperly positioned or obstructed.	Adjust hose weight position; clear any obstructions under the sink.

9. SPECIFICATIONS

Feature	Detail
Brand	Glacier Bay
Model Name	Dunning Single-Handle Pull-Out Laundry Faucet
Model Number	d670335c-0b0b-4252-b3c1-632ead6380c7
Finish Type	Chrome

Feature	Detail
Material	Metal
Number of Handles	1 (Single-Handle)
Mounting Type	Deck Mount, Single Hole
Special Feature	Dual Function Spray Head (Stream/Spray)
Spout Design	Pull-out
Item Weight	3.85 Pounds
UPC	019934827904
ASIN	B09FBZ7NDS

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or visit the official Glacier Bay website. Keep your proof of purchase for warranty claims.

Customer Service: Please contact Glacier Bay customer support for assistance with parts, installation, or general inquiries.

- *Website:* [www.glacierbay.com](#) (example, actual URL may vary)
- *Phone:* Refer to product packaging or website for regional contact numbers.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question