

[Manuals.plus](#) /

› [Owigift](#) /

› Owigift Dryer Repair Kit Instruction Manual for Maytag MEDB400VQ0 and Compatible Models

Owigift MEDB400VQ0

Owigift Dryer Repair Kit Instruction Manual

For Maytag MEDB400VQ0 and Compatible Models

1. INTRODUCTION

This instruction manual provides essential information for the installation and maintenance of the Owigift Dryer Repair Kit. This kit is designed to address common issues in compatible Maytag, Whirlpool, and Kenmore dryers, such as loud noises, drum not spinning, or failure to start. Please read this manual thoroughly before attempting any repairs.

2. PRODUCT COMPONENTS

The Owigift Dryer Repair Kit includes the following components:

- **Four (4) Drum Support Rollers:** These rollers support the dryer drum, allowing it to rotate smoothly.
- **One (1) Drive Belt:** This belt connects the motor to the dryer drum, enabling its rotation.
- **One (1) Idler Pulley Assembly:** This component maintains tension on the drive belt, ensuring proper operation.
- **Various Washers and Retaining Clips:** Small parts necessary for securing the rollers and pulley.



Figure 1: Owigift Dryer Repair Kit components including drum rollers, idler pulley, and drive belt. This image displays the complete Owigift Dryer Repair Kit. It includes four black and red drum support rollers, a white idler pulley with its bracket, a black drive belt, and various small washers and retaining clips.



Figure 2: Close-up of the idler pulley and small retaining parts from the dryer repair kit. A detailed view of the white idler pulley, along with several triangular and circular retaining clips and washers, essential for securing components during installation.



Figure 3: Close-up of a single black and red drum support roller. This image shows a single drum support roller, featuring a black rubber wheel and a red plastic inner ring with a metal bearing.

3. COMPATIBILITY

This repair kit is compatible with various Maytag, Whirlpool, and Kenmore dryer models, including but not limited to:

- Maytag: MEDB400VQ0, MEDB200VQ0, MEDX700AXL0, MEDB850WQ0, MEDB855DC0, MEDB850YW2, MEDB850YW1, MEDB850YW0, MEDB850YG2, MEDB850YG1, MEDB850YG0, MEDB850WR1
- Whirlpool and Kenmore models with 27" and 29" widths.

It is crucial to verify your dryer's model number against the product description to ensure compatibility before proceeding with any repairs. The idler pulley's bolt size is a key factor for compatibility, while pulley height may vary without affecting function.

Video 1: How to confirm dryer compatibility. This video demonstrates a two-step process to confirm if the dryer repair kit is compatible with your appliance. It guides users on how to identify if their dryer belongs to Whirlpool, Maytag, or Kenmore, and then to confirm if its width is 27 or 29 inches, ensuring proper fitment of the 4392067 repair kit.

4. SAFETY INFORMATION

WARNING: Always disconnect power to the dryer before performing any maintenance or repair. Failure to do so can result in serious injury or electrical shock.

- Wear appropriate personal protective equipment (PPE), such as gloves and safety glasses.

- Ensure the work area is well-lit and clear of obstructions.
- Keep children and pets away from the work area.
- If you are unsure about any step, consult a qualified appliance technician.

5. INSTALLATION/REPLACEMENT GUIDE

The following steps outline a general procedure for replacing dryer components. Specific disassembly steps may vary by model. Refer to your dryer's service manual for detailed instructions.

5.1. Preparation

1. **Disconnect Power:** Unplug the dryer from the electrical outlet. For gas dryers, also turn off the gas supply.
2. **Access Panels:** Carefully remove the top and front panels of the dryer to gain access to the internal components. This often involves removing screws and disengaging clips. Take photos of wiring connections before disconnecting them.
3. **Remove Lint Filter and Housing:** Extract the lint filter and its housing to clear the path to the drum.

5.2. Replacing the Drive Belt and Idler Pulley

4. **Locate Components:** Identify the existing drive belt, idler pulley, and drum support rollers.
5. **Release Belt Tension:** The idler pulley applies tension to the drive belt. Push the idler pulley to release tension on the belt and carefully remove the old belt from the motor pulley and idler pulley.
6. **Remove Old Idler Pulley:** Detach the old idler pulley assembly from its mounting bracket.
7. **Install New Idler Pulley:** Mount the new idler pulley assembly, ensuring it is securely fastened.
8. **Install New Drive Belt:** Route the new drive belt around the dryer drum and the motor pulley, then around the new idler pulley. Ensure the belt is properly aligned in the grooves.

5.3. Replacing Drum Support Rollers

9. **Access Rollers:** The drum support rollers are typically located at the front and/or rear of the dryer drum. You may need to remove the drum to access all rollers.
10. **Remove Old Rollers:** Carefully remove the retaining clips and washers holding the old rollers in place, then slide the rollers off their shafts.
11. **Install New Rollers:** Slide the new drum support rollers onto their shafts. Secure them with the new washers and retaining clips provided in the kit. Ensure they spin freely.

5.4. Reassembly and Testing

12. **Reinstall Drum (if removed):** Carefully place the dryer drum back into position, ensuring the drive belt is correctly seated.
13. **Reinstall Lint Filter Housing and Panels:** Reattach the lint filter housing, then the front and top panels. Reconnect any wiring that was disconnected.
14. **Reconnect Power:** Plug the dryer back into the electrical outlet and turn on the gas supply if applicable.
15. **Test Operation:** Run a short cycle to ensure the dryer operates smoothly and quietly. Listen for any unusual noises.

Video 2: BlueStars Dryer Repair Kit Overview. This video provides an overview of the BlueStars dryer repair kit,

highlighting its components and their purpose in resolving common dryer issues like loud noise or a non-spinning drum. It showcases the drum support rollers, drive belt, and idler pulley, emphasizing their quality and function.

6. MAINTENANCE TIPS

- Regularly clean the lint filter after each load to prevent blockages and reduce strain on dryer components.
- Inspect the dryer vent periodically for lint buildup and clear any obstructions.
- Check the drive belt for signs of wear, cracks, or fraying. Replace if necessary.
- Listen for unusual noises during operation, which may indicate worn rollers or a failing idler pulley.

7. TROUBLESHOOTING COMMON ISSUES

Problem	Possible Cause	Solution
Loud Squealing/Thumping Noise	Worn drum rollers or idler pulley.	Replace drum rollers and/or idler pulley.
Drum Not Spinning	Broken or stretched drive belt.	Replace the drive belt.
Dryer Not Starting	Faulty door switch, thermal fuse, or motor.	Check door switch, thermal fuse, and motor. This kit addresses mechanical issues, not electrical.

8. SPECIFICATIONS

- **Brand:** Owigift
- **ASIN:** B09FDDKM4W
- **Date First Available:** September 3, 2021
- **Kit Contents:** Drum Rollers, Drive Belt, Idler Pulley, Washers, Retaining Clips

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact the seller directly. Keep your purchase receipt for any warranty claims.

