

[Manuals.plus](#) /

› [A-MIND](#) /

› A-MIND Touch Screen Digitizer Replacement for Alcatel 1T 10 8082 and Alcatel Onetouch Pixi 3 (10) 8082 - Installation Manual

A-MIND 1T 10 8082, Onetouch Pixi 3 (10) 8082

A-MIND Touch Screen Digitizer Replacement

MODELS: **ALCATEL 1T 10 8082, ALCATEL ONETOUCH PIXI 3 (10) 8082**

Introduction

This document serves as an instruction manual for the A-MIND Touch Screen Digitizer Replacement for Alcatel 1T 10 8082 and Alcatel Onetouch Pixi 3 (10) 8082 tablets. This product is a replacement touch screen digitizer only; the LCD display is not included. Professional installation is highly recommended due to the specialized tools and expertise required for separating and installing the touch screen.

Package Contents

Please verify that all items listed below are included in your package:

- 1x Touch Screen Replacement for Alcatel 1T 10 8082 / Alcatel Onetouch Pixi 3 (10) 8082
- 1x Opening Tools Kit (includes strong suction cup, triangle opening tools, card pin, spudger)
- 1x Adhesive Tape

If any items are missing or damaged, please contact customer service immediately.

Important Pre-Installation Warnings

- **Professional Installation Recommended:** Replacing a touch screen digitizer requires specific tools and technical knowledge. If you lack experience in repairing electronic equipment, it is strongly advised to seek assistance from a professional repair center. Attempting self-repair without proper expertise may lead to further damage to your device or the replacement part.
- **Damage During Installation:** Any damage incurred to the screen during the installation process is not covered under warranty.
- **Battery Disconnection:** Before beginning any installation steps, ensure the tablet's battery is disconnected to prevent electrical damage.

- **Pre-Adhesive Testing:** It is crucial to connect and thoroughly test the new screen's functionality before applying any adhesive. Once adhesive is applied, returns or refunds for functional issues may not be accepted.
- **Fragile Component:** The screen is made of glass. Handle it with extreme care during unpacking and installation to prevent breakage.

Product Overview

The A-MIND Touch Screen Digitizer is designed for precise fit and function with the specified Alcatel tablet models. Below are images illustrating the product and its components.



Image 1: Front view of two A-MIND touch screen digitizers, highlighting the flex cable connections.




Image 2: Angled perspective of the touch screen digitizer, displaying its overall form factor.




Image 3: Direct front view of the touch screen digitizer, with the flex cable visible at the top.



Image 4: Detailed close-up of the flex cable and connector, essential for tablet integration.

Installation Guide

As this product is a touch screen digitizer only, its installation requires the separation of the old touch screen from the LCD and the subsequent installation of the new digitizer using specialized equipment. Due to the complexity and precision required, we strongly recommend having this procedure performed by a professional repair center.

General Steps (for professional reference):

1. Carefully disassemble the tablet and disconnect the battery.
2. Using appropriate tools and heat, separate the damaged touch screen digitizer from the LCD display.
3. Clean any residual adhesive from the LCD and tablet frame.
4. Connect the new A-MIND touch screen digitizer's flex cable to the tablet's motherboard.
5. Reconnect the battery and power on the tablet to perform a thorough test of the new screen's touch functionality.
6. If the screen functions correctly, disconnect the battery again.
7. Apply the provided adhesive tape or a suitable adhesive to secure the new digitizer to the tablet frame.
8. Carefully reassemble the tablet.

The following video provides a visual overview of the product itself, demonstrating its appearance and handling. It is not a step-by-step installation guide but can be useful for product identification.

Your browser does not support the video tag.

Video 1: Product showcase of the A-MIND Touch Screen Digitizer for Alcatel Pixi 3 1T (10) 8082. This video demonstrates the physical product and its protective films, not the installation process.

Testing the New Screen

After connecting the new touch screen digitizer but before permanently adhering it, perform the following tests:

- Power on the tablet.
- Check for any display issues (e.g., dead pixels, lines, discoloration).
- Test touch functionality across the entire screen. Ensure all areas respond accurately to touch input.
- Verify multi-touch gestures if applicable.

If any issues are detected during testing, do not proceed with full installation. Disconnect the screen and contact customer support.

Specifications

Model Number	Screen Replacement For Alcatel 1T 10 8082, Alcatel Onetouch Pixi 3 (10) 8082
Size	7.0 inch
Manufacturer	A-MIND
Color	Black
Item Weight	8.4 ounces
Package Dimensions	10.83 x 8.54 x 1.26 inches

Warranty and Support

Warranty: We provide a 6-month warranty for this product. The warranty covers functional defects, provided the screen has no man-made or physical damage. If the screen fails to work normally within this period, a new replacement can be exchanged.

Customer Support: If you encounter any problems with your order or the product, please do not hesitate to contact our customer service team. We are committed to providing assistance within 24 hours.