



Manuals.plus /

› [Luomo](#) /

› [Luomo STK-7007F Wireless Game Controller User Manual](#)

Luomo STK-7007F

Luomo STK-7007F Wireless Game Controller User Manual

Model: STK-7007F | Brand: Luomo

[Introduction](#) [Setup](#) [Operation](#) [Features](#) [Specifications & Support](#) [Maintenance](#) [Troubleshooting](#) [Warranty](#)

1. INTRODUCTION

Thank you for purchasing the Luomo STK-7007F Wireless Game Controller. This manual provides detailed instructions on how to set up, operate, and maintain your new device. Please read this manual thoroughly before use to ensure optimal performance and longevity of the product.

The STK-7007F is a durable wireless game controller designed for seamless connection to your mobile devices, offering a comfortable and immersive gaming experience without the clutter of wires. Its compact and portable design makes it ideal for gaming in various environments, from your living room to your bedroom.



Image: The Luomo STK-7007F Wireless Game Controller in its compact, collapsed state, showcasing its black finish and button layout.

2. SETUP GUIDE

2.1. Unboxing and Initial Charge

- Carefully remove the game controller and all accessories from the packaging.
- Inspect the controller for any visible damage.
- Before first use, fully charge the controller using the provided USB charging cable. Connect the cable to the controller's charging port and a compatible USB power source (e.g., computer USB port, USB wall adapter).
- The charging indicator light will typically show the charging status and turn off or change color when fully charged. Charging time is approximately 1.5 hours.

2.2. Connecting to Your Device (Bluetooth Pairing)

1. Ensure the controller is sufficiently charged.
2. Turn on the controller by pressing and holding the **HOME** button (or power button, if separate) until the indicator lights begin to flash, indicating it's in pairing mode.



Image: A close-up view of the left side of the controller, highlighting the HOME button and the responsive joystick, which is crucial for precise in-game movements.

3. On your mobile device (smartphone or tablet), navigate to the Bluetooth settings.
4. Enable Bluetooth and search for available devices.
5. Select "STK-7007F" or a similar name from the list of found devices.
6. Once connected, the controller's indicator light will typically become solid, indicating a successful pairing.
7. **Note:** This controller is compatible with Android 4.4 and above, and iOS 7.1 and above. It is **not compatible** with iOS 13.4 and above.

3. OPERATING INSTRUCTIONS

3.1. Basic Controls

The STK-7007F features standard game controller layouts for intuitive gameplay.

- **Left Analog Stick:** Used for character movement or camera control.

- **D-Pad (Directional Pad):** For precise directional input, often used in menus or for specific actions.
- **Right Analog Stick:** Typically for camera control or aiming.
- **Action Buttons (A, B, X, Y):** Used for in-game actions such as jumping, attacking, interacting, etc.
- **Shoulder Buttons (L1/L2, R1/R2):** For various actions like shooting, aiming, or special abilities.
- **HOME Button:** Powers on/off the controller, or returns to the device's home screen.
- **MODE Button:** May switch between different operating modes (e.g., Android, iOS, PC if applicable). Refer to specific game instructions for optimal mode.
- **RESET Button:** A small button, usually recessed, used to reset the controller in case of malfunction or connection issues. Use a thin object like a paperclip to press it.



Image: A multi-panel view showcasing the controller's key components: the action buttons (A, B, X, Y), the textured grip for comfort, the responsive analog joystick, and the precise D-pad.

3.2. In-Game Use

Once connected, most compatible games will automatically recognize the controller. Some games may require you to enable controller support in their settings. For optimal performance, ensure your device's operating system and game applications are up to date.

Precision Shake Rod
Precise and unmistakable walking position, faster and more fun with mobile game.

Fast Response
There is no delay, create faster response times

Launch skills together
At the same time sending trick, kill a step faster.

Image: This image illustrates key gaming advantages: "Precision Shake Rod" for accurate movement, "Fast Response" for minimal delay, and the ability to "Launch skills together" for enhanced gameplay.

4. KEY FEATURES

- **Wireless Connectivity:** Utilizes Bluetooth for a stable and clutter-free connection to your devices.
- **Ergonomic Design:** Features a unique horn-shape grip design for comfortable extended gaming sessions, preventing hand fatigue.



Image: A visual comparison demonstrating the comfort provided by the controller's ergonomic grip design versus a standard flat grip, emphasizing reduced hand fatigue during long playtimes.

- **Stretchable Section:** Designed to accommodate most mobile phones, with a maximum stretch distance of 16 cm (6.3 inches).
- **Long Standby Time:** Equipped with a built-in 300mAh battery, allowing for extended periods of happy gaming.
- **Durable Material:** Constructed from environmentally friendly ABS material, ensuring durability, wear resistance, and long-term use.
- **Anti-slip Texture:** The controller features an anti-slip texture on its grips for secure handling during intense gaming.
- **Cooling Design:** Incorporates a cooling design to help dissipate heat from the device, enhancing performance and comfort.





Image: This image highlights three design elements: the anti-slip texture on the controller's surface, the internal cooling design with airflow indicators, and the anti-slip strip that secures the phone in place.

5. PRODUCT SPECIFICATIONS

13cm/5.12in



19cm/7.48in

Image: The Luomo STK-7007F controller with its dimensions clearly marked: 19cm (7.48 inches) in length and 13cm (5.12 inches) in width.

Attribute	Value
Model	STK-7007F
Brand	Luomo
Color	Black
Material	ABS
Dimensions (L x W x H)	19 x 13 x 4.5 cm (7.48 x 5.12 x 1.77 inches)
Product Weight	247 grams
Connectivity	Wireless (Bluetooth)
Battery Capacity	300mAh
Charging Voltage	4.8-5.2V
Working Time	Up to 12 hours
Charging Time	Approximately 1.5 hours
Compatible Mobile OS	Android 4.4 and above, iOS 7.1 and above (Not compatible with iOS 13.4 and above)
Other Functions	Stretchable design for mobile phone accommodation

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the controller. For stubborn dirt, slightly dampen the cloth with water. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the controller regularly, even if not in use for extended periods.
- **Avoid Drops:** Protect the controller from drops and impacts, which can damage internal components.
- **Liquid Exposure:** Do not expose the controller to water or other liquids.

7. TROUBLESHOOTING



Image: A detailed view of the controller's right grip, showcasing its textured surface for enhanced hold and the small, recessed RESET button, used for factory resetting the device.

Problem	Possible Cause	Solution
Controller does not turn on.	Low battery.	Charge the controller for at least 1.5 hours.
Cannot pair with device.	Bluetooth not enabled on device; controller not in pairing mode; device OS not compatible.	Ensure Bluetooth is enabled on your device. Put the controller into pairing mode (flashing lights). Check device compatibility (Android 4.4+, iOS 7.1+, not iOS 13.4+). Forget previous pairings on your device and try again.
Controller disconnects frequently.	Low battery; interference; too far from device.	Charge the controller. Move closer to your device. Avoid strong electromagnetic interference.
Buttons/joysticks not responding.	Software glitch; physical damage.	Press the RESET button on the controller. Restart your mobile device. Ensure the game supports controllers. If issues persist, contact customer support.

8. WARRANTY AND SUPPORT

Luomo products are manufactured to the highest quality standards. For information regarding warranty coverage, please refer to the warranty card included with your product or visit the official Luomo website.

If you encounter any issues not covered in this manual or require further assistance, please contact Luomo customer support through the retailer where you purchased the product or via the contact information provided on the official Luomo website.

Please retain your proof of purchase for warranty claims.