

Sona STC 1319DC

SONA STC 1319DC 8-inch Remote High Velocity Fan User Manual

Model: STC 1319DC

1. INTRODUCTION

Thank you for purchasing the SONA STC 1319DC 8-inch Remote High Velocity Fan. This fan is designed to provide efficient air circulation with its energy-saving DC motor and versatile oscillation features. Please read this manual thoroughly before use to ensure proper operation and maintenance.

2. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using this fan.
- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
- Always unplug the fan from the power outlet when not in use, when moving the fan from one location to another, and before cleaning.
- Do not insert fingers or any other objects through the grille when the fan is operating.
- Do not use this fan near windows, in a bathroom, or in any wet area.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

3. PACKAGE CONTENTS

Please check the package for the following items:

- SONA STC 1319DC 8-inch High Velocity Fan

- Remote Control
- User Manual

4. PRODUCT FEATURES

The SONA STC 1319DC fan is equipped with advanced features for optimal performance and user convenience:

- **Energy Saving DC Motor:** Provides powerful airflow with low electricity consumption.
- **6 Speed Selection:** Choose from gentle breezes to strong airflow for various scenarios.
- **Soft Touch Control:** Intuitive control panel for easy operation.
- **Up-Down and Left-Right Oscillation:** Ensures wide air distribution for enhanced air circulation.
- **Remote Control:** Convenient operation from a distance.
- **7 Hours Timer:** Set the fan to automatically turn off after a specified duration.
- **Removable Fan Guard:** For easy cleaning and maintenance.

Bring in the light of life

8" Remote High Velocity Fan **STC 1319DC**



Energy Saving
DC Motor ($\approx 20\text{dB}$)



22W



6 Speeds
Selection



3D Oscillation




Soft Touch
Control

Figure 4.1: Overview of the SONA STC 1319DC fan, showcasing its compact design and key features like remote control and energy-saving DC motor.

Stronger wind

while **saving energy and electricity**



DC Motor (22W)

Figure 4.2: Illustration of the energy-saving DC motor (22W) which provides strong wind while consuming less electricity.

Delivering wind as far as 8m

Great for **study room** or **bed room**



Figure 4.3: The fan effectively delivers air up to 8 meters, suitable for various room sizes like study rooms or bedrooms.

Various breezes

for **different scenarios**





Figure 4.4: The control panel allows selection of 6 speeds for different scenarios: Speeds 1-2 for gentle ventilation, Speeds 3-4 for mild cooling, and Speeds 5-6 for strong breezes.

Oscillating

Vertically and Horizontally



Greater Air Circulation

Figure 4.5: The fan features both vertical and horizontal oscillation, providing greater air circulation throughout the room.

Product Features



Remote controlled



Removable fan guard




Soft touch control



7 hours timer

Figure 4.6: A visual summary of key features including remote control, removable fan guard, soft touch control, and 7-hour timer.



The advertisement features a central image of a silver DC motor fan with a long threaded shaft. Above the fan, a green banner with a leaf icon reads "GREEN Efficiency". To the right, the SONA logo is displayed with the tagline "YOUR TRUSTED CHOICE SINCE 1994". Large blue letters "DC" are positioned behind the fan, with "MOTOR FAN" written below them. Below the fan, the text "GO GREEN SAVE ENERGY" is shown above five green leaves. At the bottom, a dark blue box contains the text "STC 1319DC SAVES: \$40.68*" in large white font, with a smaller line of text below it: "Approximate annual amount saved, exclusive of GST. Base on 10 hours daily usage and SP Group Electricity Tariff's 29.74 cents/kWh."

GREEN Efficiency

SONA
YOUR TRUSTED CHOICE SINCE 1994

DC

MOTOR FAN

**GO GREEN
SAVE ENERGY**

STC 1319DC SAVES:
\$40.68*

Approximate annual amount saved, exclusive of GST. Base on 10 hours daily usage and SP Group Electricity Tariff's 29.74 cents/kWh.

Figure 4.7: Information on the energy efficiency of the DC motor, highlighting potential annual savings.

5. SETUP AND PLACEMENT

The SONA STC 1319DC fan requires no assembly. Simply follow these steps for initial setup:

1. **Unpack:** Carefully remove the fan and all packaging materials from the box.
2. **Placement:** Place the fan on a firm, level surface. Ensure there is adequate space around the fan for proper air circulation and oscillation. Avoid placing it near curtains or other objects that could obstruct airflow or get caught in the fan blades.
3. **Power Connection:** Plug the power cord into a standard electrical outlet.

6. OPERATING INSTRUCTIONS

The fan can be operated using the soft touch controls on the unit or the included remote control.

6.1 Control Panel / Remote Control Functions

- **Power Button** (): Press to turn the fan ON or OFF.
- **Speed Button** (⇌): Press repeatedly to cycle through the 6 speed settings (1 to 6).
- **Horizontal Oscillation Button** (↔): Press to activate or deactivate horizontal (left-right) oscillation.
- **Vertical Oscillation Button** (↑↓): Press to activate or deactivate vertical (up-down) oscillation.
- **Timer Button** (): Press repeatedly to set the auto-off timer for 1, 2, 3, 4, 5, 6, or 7 hours. The corresponding indicator light will illuminate.

6.2 Remote Control Battery Installation

The remote control requires batteries (not included). Open the battery compartment on the back of the remote, insert the batteries according to the polarity indicators, and close the compartment.

7. MAINTENANCE AND CLEANING

Regular cleaning will help maintain the fan's performance and extend its lifespan.

1. **Disconnect Power:** Always unplug the fan from the power outlet before cleaning.
2. **Exterior Cleaning:** Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners or solvents.
3. **Grille Cleaning:** The front grille is removable for easier cleaning of the fan blades. Gently twist or unclip the grille as per the design to remove it. Use a soft brush or vacuum cleaner to remove dust from the blades and grilles. Ensure all parts are dry before reassembling.
4. **Storage:** If storing the fan for an extended period, cover it to protect it from dust and store it in a cool, dry place.

8. TROUBLESHOOTING

If you encounter any issues with your fan, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply.	Check if the power cord is securely plugged into a working outlet.
Weak airflow.	Fan blades or grilles are dirty.	Clean the fan blades and grilles as described in the Maintenance section.
Fan is noisy.	Loose parts or dust accumulation.	Ensure all parts are securely fastened. Clean the fan thoroughly. If noise persists, contact customer support.
Remote control not working.	Dead batteries or obstruction.	Replace batteries in the remote control. Ensure there is no obstruction between the remote and the fan's sensor.

9. SPECIFICATIONS

Feature	Specification
---------	---------------

Feature	Specification
Model	STC 1319DC
Fan Size	8 inches
Motor Type	DC Motor
Speed Settings	6 Speeds
Oscillation	Up-Down and Left-Right
Control Type	Remote Control, Soft Touch Panel
Timer	Up to 7 hours
Power Source	Corded Electric
Item Weight	3.4 Kilograms
Form Factor	Table Fan
Included Components	Remote
Color	White

10. WARRANTY AND SUPPORT

Warranty: This SONA STC 1319DC fan comes with a **5 Years Warranty on the Motor** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects in the motor under normal use conditions.

Customer Support: For any questions, technical assistance, or warranty claims, please contact SONA customer service. Refer to the product packaging or the official SONA website for contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question