
[Manuals.plus](#) /

› [Kymate](#) /

› Kymate BCA2 Replacement Belt Clip Instruction Manual for Midland Radios

Kymate BCA2

Kymate BCA2 Replacement Belt Clip Instruction Manual

For Midland X-Talker, LXT, and GXT Series Radios

1. PRODUCT OVERVIEW

The Kymate BCA2 is a replacement belt clip designed for use with various Midland two-way radios. This clip provides a secure and convenient method for carrying your radio on a belt, pocket, or other suitable location, ensuring easy access during use.



Image 1.1: Front view of the Kymate BCA2 replacement belt clip, showing its smooth, black surface and ribbed top section.

2. COMPATIBILITY

This BCA2 replacement belt clip is compatible with the following Midland radio models:

- Midland X-Talker T70 Series: T71, T73, T75, T77, T79
- Midland LXT Series: LXT600, LXT630, LXT633VP3, LXT600VP4, LXT630VP3
- Midland GXT Series: GXT1000, GXT1030, GXT1050, GXT1000X3VP4, GXT1030VP4, GXT1050VP4, GXT1000VP4
- Other compatible models: T290VP4, T295VP4, T75VP3, T77VP5

3. FEATURES

- **Durable Construction:** Made from high-quality Acrylonitrile Butadiene Styrene (ABS) for long-lasting use.
- **Secure Attachment:** Designed to securely hold your radio.

- **Easy to Use:** Simple clip mechanism for quick attachment and removal.
- **Lightweight:** Weighs approximately 8 grams, adding minimal bulk to your radio.

4. SETUP AND INSTALLATION

To attach the BCA2 belt clip to your compatible Midland radio, follow these steps:

1. Locate the belt clip attachment slot on the back of your Midland radio.
2. Align the top tabs of the BCA2 belt clip with the corresponding slots on the radio.
3. Slide the belt clip downwards until it clicks securely into place. Ensure it is firmly attached and does not wobble.



Image 4.1: Rear view of the BCA2 belt clip, highlighting the sliding attachment mechanism.

To remove the belt clip, push the release tab (if present on your radio model) and slide the clip upwards to detach it.

5. OPERATING INSTRUCTIONS

Once the BCA2 belt clip is securely attached to your radio, you can use it to carry your device conveniently.

- **Attaching to a Belt:** Slide the belt clip over your belt or waistband until it is firmly in place.
- **Attaching to a Pocket:** The clip can also be used to secure the radio to a pocket edge.
- **Secure Placement:** Always ensure the radio is securely clipped to prevent accidental drops.



Image 5.1: Angled view of the BCA2 belt clip, illustrating the spring-loaded clip mechanism.

6. MAINTENANCE

To ensure the longevity and proper function of your Kymate BCA2 belt clip:

- **Cleaning:** Wipe the clip with a soft, damp cloth to remove dust or dirt. Avoid harsh chemicals.
- **Inspection:** Periodically check the clip for any signs of wear, cracks, or damage.
- **Storage:** Store the clip in a cool, dry place when not in use.

7. TROUBLESHOOTING

If you encounter issues with your BCA2 belt clip, consider the following:

- **Clip not attaching securely:**
 - Ensure the clip is fully slid into the radio's attachment slot until it clicks.
 - Verify that your radio model is listed in the compatibility section.
 - Inspect the clip and radio's attachment points for any obstructions or damage.
- **Clip feels loose:**
 - Re-attach the clip, ensuring a firm connection.
 - If the clip is damaged or worn, consider replacing it.

8. SPECIFICATIONS

Model	BCA2
Brand	Kymate
Material	Acrylonitrile Butadiene Styrene (ABS)
Color	Black
Item Weight	Approximately 8 Grams
Closure Type	Clip

9. WARRANTY AND SUPPORT

For warranty information or product support, please refer to the retailer or manufacturer's official website where the product was purchased. Keep your purchase receipt for any warranty claims.