

AGARO MHR100

AGARO MHR100 Facial Hair Remover User Manual

Model: MHR100

1. INTRODUCTION

The AGARO MHR100 Facial Hair Remover is designed for instant and painless removal of unwanted facial hair. Featuring a 3D floating head and stainless steel blades, it provides a smooth finish for areas such as the upper lip, chin, and cheeks. Its compact design makes it ideal for on-the-go use.

This manual provides essential information for the safe and effective operation, maintenance, and care of your AGARO MHR100 Facial Hair Remover.

2. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the device. Keep this manual for future reference.

- This device is intended for facial hair removal only. Do not use it for any other purpose.
- Keep the device out of reach of children.
- Do not use the device on irritated, damaged, or infected skin. Consult a dermatologist if you have any skin conditions.
- Ensure your hands are dry when handling the device, especially when inserting or removing the battery.
- Do not immerse the main body of the device in water. The blade head is washable, but the battery compartment should remain dry.
- If the device malfunctions or is damaged, do not attempt to repair it yourself. Contact customer support.
- Use only the specified battery type (1 AA battery). Do not mix old and new batteries or different types of batteries.
- Remove the battery if the device will not be used for an extended period to prevent leakage.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your AGARO MHR100 Facial Hair Remover.

Advance Double Deck Blade



Figure 1: Product Components. This image illustrates the internal structure, highlighting the floating shaver head, the stainless steel blade for painless shaving, and the easy on/off switch. A cleaning brush is also shown as an included accessory.

- **Floating Shaver Head:** Adapts to facial contours for effective hair removal.
- **Stainless Steel Blade:** Designed for painless and precise hair trimming.
- **On/Off Switch:** For activating and deactivating the device.
- **Battery Compartment:** Located at the bottom for AA battery insertion.
- **Protective Cap:** Covers the shaver head when not in use.
- **Cleaning Brush:** Included for maintaining the blade head.

4. SETUP AND BATTERY INSTALLATION

The AGARO MHR100 operates on one AA battery (not included).

1. Remove the protective cap from the shaver head.

2. Gently twist and pull to remove the battery chamber from the bottom of the device.
3. Insert one new AA battery into the compartment, ensuring the positive (+) and negative (-) terminals align correctly as indicated inside the chamber.
4. Reinsert the battery chamber into the device and twist to secure it.
5. Replace the protective cap when not in use.



Figure 2: Battery Installation Steps. This image visually guides the user through removing the protective cap, detaching the battery chamber, inserting an AA battery (not included), and preparing the device for use.

1 AA Battery Operated

* Battery not included



Figure 3: AA Battery Placement. This image confirms that the device requires one AA battery for operation, which is not included in the package.

5. OPERATING INSTRUCTIONS

Follow these steps for effective and painless hair removal:

1. Ensure your skin is clean and dry before use. Avoid using creams or lotions that might clog the shaver head.
2. Remove the protective cap from the shaver head.
3. Slide the On/Off switch to the "On" position to activate the device.
4. Gently press the shaver head against your skin and move it in small, circular motions or against the direction of hair growth. Do not apply excessive pressure.
5. The device is designed to remove hair from areas such as the upper lip, chin, cheeks, and eyebrows. It can also be used for underarm, arm, and bikini areas.
6. After use, slide the On/Off switch to the "Off" position.

7. Replace the protective cap to protect the shaver head.



Figure 4: Applicable Areas for Hair Removal. This image demonstrates the versatility of the device for removing tiny body hair effectively and painlessly from multiple areas.



Figure 5: Using the Device for Smooth Skin. This image shows the device being used on the face to achieve smoother skin, ideal for makeup application.



Figure 6: Safe Blade Head Design. This image highlights the design of the blade head, which is safe to touch and engineered to prevent skin redness or scratches during use.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene of your device.

1. Ensure the device is turned off before cleaning.
2. Twist the shaver head counter-clockwise and lift it off the device.
3. Use the included cleaning brush to remove any accumulated hair from the blades and the inner part of the shaver head.
4. The detachable blade head is washable. You can rinse it under running water. Ensure it is completely dry before reattaching.
5. Do not rinse the main body of the device under water, only the detachable head.
6. Reattach the shaver head by aligning it and twisting clockwise until it clicks into place.

7. Store the device in a dry place with the protective cap on.



Figure 7: IPX7 Waterproof Feature. This image demonstrates that the device is IPX7 waterproof, allowing the detachable blade head to be safely cleaned under running water or used in humid conditions like a bath or shower.

7. TROUBLESHOOTING

If you encounter any issues with your AGARO MHR100, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Battery is dead or incorrectly inserted.	Check battery polarity. Replace with a new AA battery.
Device runs slowly or weakly.	Low battery power.	Replace the AA battery with a new one.

Problem	Possible Cause	Solution
Hair is not removed effectively.	Shaver head is clogged with hair or debris.	Clean the shaver head thoroughly using the cleaning brush and rinse under water as per maintenance instructions.
Skin irritation after use.	Excessive pressure applied or skin was not clean/dry.	Ensure skin is clean and dry. Use gentle, circular motions without applying too much pressure. If irritation persists, discontinue use.

8. SPECIFICATIONS

- **Model:** MHR100
- **Power Source:** 1 x AA Battery (not included)
- **Blade Material:** Stainless Steel
- **Head Type:** Rotary, 3D Floating Head
- **Water Resistance:** IPX7 (detachable head only)
- **Dimensions (LxWxH):** 11.8 x 2.5 x 11.8 cm
- **Item Weight:** 7 g
- **Included Components:** Cleaning Brush
- **Special Feature:** Hypoallergenic

9. WARRANTY AND SUPPORT

The AGARO MHR100 Facial Hair Remover comes with a 1-year warranty from the date of purchase.



Figure 8: 1 Year Warranty. This image confirms the product is covered by a one-year warranty.

For warranty claims, technical support, or any product-related inquiries, please contact AGARO customer service. Refer to the product packaging or the official AGARO website for contact details.

Manufacturer: Universal Corporation Limited, Shenzhen, Guangdong, China

Importer: Universal Corporation Limited Old Sikkim Commerce House 4/1A Middleton Street Kolkata 700071

© 2026 AGARO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question