

[Manuals.plus](#) /

> [TECLAST](#) /

> TECLAST Artpad Pro Tablet User Manual

TECLAST Artpad Pro

TECLAST Artpad Pro Tablet User Manual

Model: Artpad Pro

INTRODUCTION

This manual provides essential information for the setup, operation, and maintenance of your TECLAST Artpad Pro tablet. Please read this manual thoroughly before using your device to ensure proper functionality and to maximize your user experience.

The TECLAST Artpad Pro is a 12.7-inch tablet featuring a 2K display, powered by an Octa-Core Helio G99 processor. It supports Dual SIM 4G LTE connectivity, offers 8GB RAM and 256GB ROM, and is equipped with a 10000mAh battery with 30W fast charging. The tablet runs on Android 15 and includes a high-precision active stylus.

WHAT'S IN THE BOX

Verify that all items are present in the package:

- TECLAST Artpad Pro Tablet
- T-Pen Stylus
- 3 Replaceable Stylus Tips
- 30W Fast Charger
- Ejection Pin (for SIM/SD card tray)
- USB-C to USB-C Data Cable
- Warranty Card
- User Manual (this document)



Image: Contents of the TECLAST Artpad Pro package. Includes the tablet, T-Pen stylus, three replacement stylus tips, a 30W fast charger, an ejection pin, a USB-C cable, a warranty card, and the user manual.

SETUP

1. Charging the Tablet

Before first use, fully charge your tablet. Connect the provided 30W fast charger to the USB-C port on the tablet and plug it into a power outlet. The battery icon on the screen will indicate charging status.



Image: The TECLAST Artpad Pro tablet connected to its 30W fast charger, showing the charging indicator on the screen.

2. Powering On/Off

- **To Power On:** Press and hold the Power button located on the side of the tablet until the TECLAST logo appears.
- **To Power Off:** Press and hold the Power button, then select "Power off" from the options on the screen.
- **To Restart:** Press and hold the Power button, then select "Restart" from the options.

3. Initial Setup

Follow the on-screen prompts to complete the initial setup, including language selection, Wi-Fi connection, Google account login, and security settings.

4. Inserting SIM/MicroSD Card

The tablet supports dual 4G SIM cards and MicroSD card expansion. Use the provided ejection pin to open the SIM/MicroSD card tray. Insert the cards as indicated on the tray and gently push the tray back into the slot.

x3 Replaceable Pen Tips

Compatible with others tablet like ipad, samsung tablets that mit USI 2.0

4096-Level
True Pressure-Sensitive Writing

Global Palm Rejection
Smooth, Effortless Drawing

USI 2.0 Support
Universal Protocol

Image: A detailed view of the TECLAST Artpad Pro's SIM/MicroSD card tray, illustrating how to insert two SIM cards and one MicroSD card.

OPERATING INSTRUCTIONS

Display and Interaction

The Artpad Pro features a 12.7-inch 2K (2176x1600) Canvas display, offering an expanded viewing area compared to traditional 16:9 screens. This is ideal for reading, document viewing, and creative tasks.

+20%!

Comparé aux tablettes classiques 16:9, l'ArtPad Pro offre un grand écran plus d'espace pour tout ce que vous voulez faire! Le stylet s'attache magnétiquement en haut ou en bas – très pratique! Regardez des vidéos, prenez des notes, dessinez, composez de la musique et utilisez l'écran partagé pour travailler et vous amuser en même temps.



Image: A visual comparison highlighting the larger display area of the Artpad Pro's Canvas screen compared to a conventional 16:9 tablet display.

Using the T-Pen Stylus

The included T-Pen stylus offers 4096 levels of pressure sensitivity for precise writing and drawing. It also supports palm rejection, allowing you to rest your hand on the screen naturally while using the stylus.

- **Stylus Tips:** Three replaceable tips are provided. To replace, gently pull out the old tip and insert a new one.
- **Magnetic Attachment:** The stylus can be magnetically attached to the side of the tablet for convenient storage.

4096 niveaux de pression

Précision absolue avec 4096 points de pression, garantissant la fluidité de chaque trait, que vous écriviez rapidement ou que vous dessiniez.

Rejet de la paume de la main

Placez confortablement la paume de votre main sur l'écran. Ne craignez plus que vos doigts ou votre paume touchent l'écran.

A graphic showing the T-Pen stylus drawing a vibrant, multi-colored swirl on a tablet surface. The stylus is positioned vertically, and the swirl starts from the tip and spirals upwards.

A diagram showing how to change the stylus tip. It is labeled 'Extraire' (Remove) and 'Insérer' (Insert). A hand is shown pulling the old tip out and inserting a new one.

A diagram of the stylus with a green LED indicator at the bottom. A legend indicates: Green bar = Travail (Work), Red bar = Charge (Charge), and a right-pointing arrow = Pression prolongée -> Allumage (Prolonged pressure -> Power on).

An icon of a stylus tip inside a purple gift box, with the text 'x3 Remplaçable de la mine' (x3 Replaceable tip).

Image: A graphic detailing the T-Pen stylus's 4096 pressure sensitivity and palm rejection, including how to change the stylus tips.

Performance and Software

The tablet is powered by the MediaTek Helio G99 Octa-Core processor (2.2 GHz) and Mali-G57 MC2 GPU, ensuring smooth performance for various applications, from productivity to entertainment.

It runs on Android 15, offering an optimized user experience with enhanced privacy features. The tablet also integrates Google Gemini AI for intelligent assistance, image generation, content creation, and more.

Puissance intérieure, élégance extérieure

L'ArtPad Pro, équipé d'un MediaTek Helio G99 (2x A76 + 6x A55) et du GPU Mali-G57, combine multitâche fluide et grande autonomie — idéal pour dessiner, jouer ou profiter des médias. HyperEngine 2.0 garantit des performances fluides et un appareil bien refroidi.

MTK G99
Huit cœurs

2.2GHz
Fréquence maximale

Gravure 6nm
Performances élevées

Mali-G57 MC2
Performances élevées

950MHz
Fréquence de fonctionnement

400000+*
Fréquence de fonctionnement



Image: Technical specifications of the MediaTek Helio G99 processor and Mali-G57 MC2 GPU, highlighting their performance capabilities.

Connectivity

The Artpad Pro supports Dual SIM 4G LTE for mobile data and calls, dual-band Wi-Fi (2.4/5 GHz), and Bluetooth 5.2 for wireless accessories. It also features GPS/GLONASS/BDS/GALILEO for precise navigation.

Audio Features

Equipped with four AI-powered speakers, the tablet delivers immersive audio. You can select from various sound modes (Game, Cinema, Music) to optimize the audio experience for different content.



Image: A graphic representing the AI smart 4-speaker system and its optimized sound modes for various entertainment scenarios.

Camera and Facial Recognition

The tablet features a 13MP rear camera with autofocus and an 8MP front camera. The front camera supports facial recognition for secure unlocking.

Caméra IA avec reconnaissance faciale

L'appareil photo arrière 13MP avec autofocus et optimisation IA capture des images claires même en basse lumière (avec lumière d'appoint). La caméra frontale 8MP permet des appels vidéo nets et le déverrouillage facial.



Image: A visual representation of the tablet's camera capabilities, including the rear camera and the facial recognition feature in use.

Customizable SMART Button

The side SMART button can be programmed for single-click, double-click, or long-press actions, such as launching apps, navigating back, or activating E Ink mode.

Split Screen Functionality

To use the split screen feature:

1. Tap the square icon at the bottom of the screen to view running applications.
2. Tap the application icon in the task list of the displayed application. Select the applications to display simultaneously in split screen mode.
3. In split screen mode, you can adjust the display area by touching and holding the divider icon and dragging it left or right.

Écran partagé

Comment utiliser la fonction [Écran divisé] sur 2 écrans divisés ?

- 1, Appuyez sur l'icône carrée en bas de l'écran pour afficher les applications en cours d'exécution en arrière-plan.
2. Appuyez sur l'icône de l'application dans l'onglet des tâches de l'application affichée. [Sélectionnez les applications à afficher en même temps dans [Écran partagé].
- 3, Dans [Écran partagé], vous pouvez également modifier la zone d'affichage en touchant et en maintenant l'icône [-] dans l'écran partagé et en la déplaçant vers la gauche ou la droite.



Image: A step-by-step guide demonstrating how to activate and manage the split screen function on the tablet.

MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid using harsh chemicals or abrasive materials.

- **Software Updates:** Regularly check for and install system updates to ensure optimal performance and security. Go to Settings > System > System update.
- **Battery Care:** To prolong battery life, avoid exposing the tablet to extreme temperatures. Do not let the battery completely drain frequently.
- **Storage Management:** Periodically clear unnecessary files and applications to maintain sufficient storage space and system speed.

TROUBLESHOOTING

Problem	Solution
Tablet does not power on.	Ensure the tablet is fully charged. Connect the charger and wait a few minutes before attempting to power on again. If unresponsive, press and hold the power button for 10-15 seconds to force a restart.
Wi-Fi connection issues.	Restart the tablet and your Wi-Fi router. Check if other devices can connect to the Wi-Fi network. Forget the network on your tablet and reconnect.
Stylus is not responding.	Ensure the stylus is charged (if applicable, though this model's stylus is passive/active with pressure sensitivity, not necessarily requiring charging). Check if the stylus tip is securely in place or needs replacement. Test with a different application.
Slow performance.	Close unused applications. Clear cache and temporary files. Check for available system updates. Consider performing a factory reset if the issue persists (back up data first).
4G LTE not working.	Ensure the SIM card is correctly inserted and activated with your carrier. Check network settings in the tablet. Restart the tablet.

SPECIFICATIONS

Feature	Detail
Brand	TECLAST
Model Name	TECLAST Artpad Pro
Storage Capacity	256 GB
Screen Size	12.7 Inches
Max Display Resolution	2176 x 1600 Pixels
Operating System	Android 15
Color	Gray
Installed RAM Size	8 GB (as per current variant) / 20 GB (as per general spec)
Battery Life	12 hours

Feature	Detail
Battery Capacity	10000 mAh
Processor Speed	2.2 GHz
Processor Brand	MediaTek
Processor Model	Helio G99
Graphics Coprocessor	Mali-G57 MC2
Rear Camera Resolution	13 Megapixels
Front Camera Resolution	8 MP
Wireless Technology	4G LTE, Bluetooth 5.2, Wi-Fi (802.11a/b/g/n/ac)
Connectivity Hardware	USB-C, Dual SIM, Micro SD
GPS Functionality	GPS/GLONASS/BDS/GALILEO
Biometric Security	Facial Recognition
Item Weight	520 Grams
Dimensions (L x W x H)	27.9 x 21.1 x 0.7 cm
Special Features	Fast Charging, Stereo Speakers, Card Reader, USB OTG Support, Expandable Storage

WARRANTY AND SUPPORT

Your TECLAST Artpad Pro tablet comes with a **2-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use.

For technical assistance, troubleshooting, or warranty claims, please contact TECLAST customer support. TECLAST is committed to providing pre-sales and after-sales technical support.

You can find more information and contact details on the official TECLAST website or through your point of purchase.



Image: TECLAST support details, indicating 24-hour rapid response and a 2-year warranty.



© 2026 TECLAST. All rights reserved.