Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kircuit AC/DC Adapter

Kircuit AC/DC Adapter User Manual

For Samsung HW-K335 and HW-J7500R/ZA Soundbar Speakers

1. Introduction

This manual provides essential instructions for the safe and effective use of your Kircuit AC/DC Adapter. This power supply unit is designed as a replacement or backup for compatible Samsung soundbar speakers, specifically models HW-K335 and HW-J7500R/ZA. Please read this manual thoroughly before use to ensure proper operation and longevity of the product.



Image 1.1: The Kircuit AC/DC Adapter, showing the main power brick, the detachable power cord with a two-prong plug, and the output cable with a barrel connector.

2. Product Features

- **High-Quality Replacement:** A brand new, high-quality AC power charger designed for reliable performance.
- **Wide Input Voltage:** Supports an input voltage range of 100V-240V AC, making it suitable for various regions and travel.
- **Advanced Protection:** Built-in Dynamic IC, Charger IC, and power fuse ensure rapid charging and protection against overcharge.
- **Safety Protections:** Incorporates multiple safety features including short circuit protection, excess voltage protection, over temperature protection, and overcurrent protection.
- **Durable Design:** Features a power cable made of high-quality materials with thick insulation and abrasion resistance, designed to withstand high temperatures and provide a secure connection.




Image 2.1: Illustration detailing the built-in safety protections of the Kircuit adapter, including safeguards against short circuits, excess voltage, over temperature, and overcurrent.




Image 2.2: Visual representation of the durable design of the power cable, highlighting its high-quality materials, thick insulation, and abrasion resistance.

3. Specifications

Feature	Detail
Brand	Kircuit
Compatible Devices	Samsung HW-K335, HW-J7500R/ZA Soundbar Speakers
Input Voltage	100V-240V AC
Power Source	Corded Electric
Connector Type	Barrel Connector
Main Power Connector Type	2 Pin
Special Feature	Travel-friendly design
Safety Compliance	OE Specification Met




Image 3.1: The Kircuit AC/DC Adapter with key dimensions indicated, showing the power brick, output cable with barrel connector, and input cable with a two-prong plug. An anti-interference magnetic ring is visible on the output cable.

4. Setup Instructions

1. **Unpack the Adapter:** Carefully remove the Kircuit AC/DC Adapter and its power cord from the packaging.
2. **Connect Power Cord:** Insert the 2-pin end of the detachable power cord into the corresponding receptacle on the AC/DC adapter brick. Ensure it is firmly seated.
3. **Connect to Device:** Plug the barrel connector end of the adapter's output cable into the power input port of your Samsung HW-K335 or HW-J7500R/ZA soundbar speaker.
4. **Connect to Power Outlet:** Insert the 2-prong plug of the power cord into a standard 100V-240V AC wall outlet.
5. **Verify Connection:** Confirm that all connections are secure before powering on your soundbar.



Image 4.1: The Kircuit AC/DC Adapter connected to a wall outlet, demonstrating a typical setup for powering a compatible device.

5. Operating Instructions

Once the Kircuit AC/DC Adapter is correctly connected to your soundbar and a power outlet, the soundbar should receive power. Operate your soundbar as per its own manufacturer's instructions. The adapter functions automatically to provide the necessary power.

- Ensure the adapter is placed in a well-ventilated area to prevent overheating.

- Avoid placing heavy objects on the adapter or its cables.
- Do not expose the adapter to moisture or extreme temperatures.

6. Maintenance

The Kircuit AC/DC Adapter requires minimal maintenance. Follow these guidelines to ensure its continued performance:

- **Cleaning:** Disconnect the adapter from the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use for extended periods, store the adapter in a cool, dry place, away from direct sunlight and moisture.
- **Cable Care:** Avoid sharp bends or kinks in the cables. Do not pull on the cables to disconnect the adapter; always grasp the plug or connector.

7. Troubleshooting

If you encounter issues with your Kircuit AC/DC Adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power to soundbar	Adapter not properly connected to outlet or soundbar. Faulty outlet.	Ensure all connections are secure. Try plugging the adapter into a different, known-working outlet.
Adapter feels hot	Normal operation under load. Poor ventilation.	A warm adapter is normal. Ensure it is in a well-ventilated area and not covered. If excessively hot, disconnect immediately and contact support.
Soundbar not functioning correctly	Issue with the soundbar itself, not the adapter.	Refer to your soundbar's user manual for troubleshooting specific to the device.

8. Safety Information

Please observe the following safety precautions to prevent injury or damage to the product:

- Do not disassemble or modify the adapter. This can lead to electric shock, fire, or damage to the unit.
- Keep the adapter away from water, high humidity, and extreme temperatures.
- Do not use the adapter if the cables are damaged or frayed.
- Ensure the adapter is used with compatible devices only, as specified in this manual.
- Unplug the adapter during lightning storms or when unused for long periods.
- Keep out of reach of children.

9. Warranty and Support

For warranty information or technical support, please contact Kircuit customer service through your purchase platform or the official Kircuit website. Please have your product model and purchase details ready when contacting support.



Image 9.1: A Kircuit product box displayed on a desk, symbolizing the brand's commitment to quality and support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09FJS2YTN

More documents and user manuals: **https://manuals.plus/**