

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Hadisala](#) /

› [Hadisala Sports Wireless Earbuds \(Model IPX7\) User Manual](#)

Hadisala IPX7

Hadisala Sports Wireless Earbuds (Model IPX7) User Manual

Your comprehensive guide to setup, operation, and maintenance.

1. INTRODUCTION

Thank you for choosing the Hadisala Sports Wireless Earbuds. These earbuds are designed to provide a high-quality audio experience with features tailored for active lifestyles, including secure ear-hooks, IPX7 waterproofing, and extended battery life. This manual will guide you through the features and functions of your new earbuds.



Image 1.1: Hadisala Sports Wireless Earbuds in their charging case, displaying a digital battery percentage.

2. WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- Hadisala Sports Wireless Earbuds (Left and Right)
- Charging Case
- USB Type-C Charging Cable
- Multiple Sizes of Ear Tips (S, M, L)
- User Manual

3. PRODUCT OVERVIEW

The Hadisala Sports Wireless Earbuds are engineered for performance and comfort. Key features include:

- **Ergonomic Ear-Hooks:** Designed for a secure and comfortable fit during physical activity.
- **LED Display:** Digital display on the charging case shows battery percentage.
- **Deep Bass Audio:** Delivers rich sound quality with enhanced bass.
- **Built-in Microphone:** Enables clear hands-free communication.
- **IPX7 Waterproof Rating:** Resistant to sweat, water, and rain, suitable for workouts and outdoor use.
- **Bluetooth 5.1 Connectivity:** Provides stable and efficient wireless connection.
- **Extended Playtime:** Up to 50 hours total playtime with the charging case.
- **Smart Touch Controls:** Intuitive touch sensors for managing music and calls.



Image 3.1: Visual representation of the earbuds' key features including LED display, IPX7 waterproof, Bluetooth 5.1, one-step pairing, stable connectivity, Hi-Fi sound, volume control, ergonomic design, and voice assistant.

4. SETUP

4.1 Charging the Earbuds and Case

Before first use, fully charge both the earbuds and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated; the LED indicators on the earbuds will light up.
2. Connect the USB Type-C charging cable to the charging port on the case and plug the other end into a USB power adapter (not included).
3. The LED display on the charging case will show the current battery percentage. It will display '100' when fully charged.

A full charge provides up to 5 hours of playtime for the earbuds, with the charging case offering approximately 10

additional charges, totaling up to 50 hours of playtime.



Image 4.1: Close-up of the charging case with a USB Type-C cable connected, indicating charging.

4.2 Pairing with Your Device

The earbuds feature one-step auto-pairing for convenience.

1. Take both earbuds out of the charging case. They will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, etc.), go to the Bluetooth settings.
3. Search for available devices and select "U1 PRO" from the list.
4. Once connected, you will hear an audible confirmation, and the LED indicator on the earbuds will change.

The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

One-step Auto Pairing

- 1 Take out the earbuds from charging case
- 2 Search Bluetooth and connect "U1 PRO"



Image 4.2: Illustration of the one-step auto pairing process, showing earbuds connecting to a phone displaying "U1 PRO" in Bluetooth settings.

5. OPERATING INSTRUCTIONS

5.1 Wearing the Earbuds

For optimal sound quality and a secure fit, choose the correct ear tip size and adjust the ear-hooks.

1. Select the ear tips (S, M, L) that best fit your ear canal. A good seal is crucial for bass response and noise isolation.
2. Place the earbud into your ear, then gently hook the flexible ear-hook over the top of your ear.
3. Adjust the earbud and ear-hook until it feels snug and comfortable.

Ergonomics Design




Image 5.1: Depiction of the ergonomic design featuring elastic ear hooks and various sizes of replacement ear tips (S, M, L) for a customized fit.

5.2 Smart Touch Controls

The earbuds feature intuitive touch controls on each earbud. The functions may vary slightly between left and right earbuds.

Action	Function
Single Tap	Play/Pause music, Answer call
Double Tap (Left Earbud)	Previous Song
Double Tap (Right Earbud)	Next Song
Triple Tap (Left Earbud)	Volume Down
Triple Tap (Right Earbud)	Volume Up

Action	Function
Long Press (2 seconds)	Reject call, Activate Voice Assistant
Long Press (3 seconds)	Hang Up call



Image 5.2: Visual guide to the smart touch controls for various functions like answering calls, playing music, adjusting volume, and activating voice assistant.

5.3 IPX7 Waterproof Rating

The Hadisala Sports Wireless Earbuds are rated IPX7 waterproof, meaning they are resistant to sweat, splashes, and rain. This makes them ideal for intense workouts and outdoor activities. However, they are not designed for swimming or prolonged submersion in water.

IPX7 WATERPROOF

Resistant to sweat, water and rain



Image 5.3: Earbuds shown with water splashes, emphasizing their IPX7 waterproof capability for resistance against sweat and rain.

6. MAINTENANCE

To ensure the longevity and optimal performance of your Hadisala Sports Wireless Earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds, especially the ear tips and charging contacts, with a soft, dry, lint-free cloth. If necessary, use a slightly damp cloth for the ear tips, then dry thoroughly.
- **Storage:** When not in use, always store the earbuds in their charging case to protect them from dust, damage, and to keep them charged.
- **Avoid Extreme Conditions:** Do not expose the earbuds or charging case to extreme temperatures, direct sunlight for prolonged periods, or corrosive liquids.
- **Charging:** Use only the provided USB Type-C cable or a certified equivalent for charging.

7. TROUBLESHOOTING

If you encounter any issues with your earbuds, please refer to the following common solutions:

Problem	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on your device's Bluetooth. Forget "U1 PRO" from your device's Bluetooth list and re-pair.
Only one earbud working	Place both earbuds back into the charging case, close the lid, then take them out again to re-establish connection. Check battery levels.
Low volume or poor sound quality	Adjust volume on both earbuds and your device. Ensure ear tips provide a good seal. Clean ear tips and earbud mesh.
Earbuds not charging	Ensure charging cable is securely connected. Check if the charging case has power. Clean charging contacts on earbuds and case.
Earbuds falling out	Try different sizes of ear tips. Adjust the ear-hooks for a more secure fit.

8. SPECIFICATIONS

Feature	Detail
Model Name	IPX7
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth 5.1
Bluetooth Range	10 Meters
Water Resistance Level	IPX7 (Waterproof)
Battery Life (Total with Case)	50 Hours
Included Components	Charging Case
Control Type	Touch, Voice Control
Ear Placement	In Ear
Form Factor	In Ear
Material	Silicone
Item Weight	4.6 ounces
Manufacturer	Hadisala

9. OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video 9.1: An official product video showcasing the Hadisala Sports Wireless Earbuds, highlighting their IPX7 waterproof rating and other key features. This video provides a dynamic overview of the product's design and functionality.

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Hadisala website. Keep your proof of purchase for any warranty claims.

If you require further assistance, please contact Hadisala customer service through their official channels.

