

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [BLACK+DECKER](#) /

› [BLACK+DECKER TCM730-B5 Automatic Multi-Use Turkish Coffee Maker Instruction Manual](#)

## BLACK+DECKER TCM730-B5

# BLACK+DECKER TCM730-B5 Automatic Multi-Use Turkish Coffee Maker

Model: TCM730-B5

## IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all safety instructions before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the appliance is placed on a stable, level, heat-resistant surface.
- Do not immerse the main unit, cord, or plug in water or any other liquid.
- Keep the appliance out of reach of children and pets.
- Unplug the appliance from the power outlet when not in use and before cleaning.
- Do not operate the appliance with a damaged cord or plug, or if the appliance malfunctions or has been damaged in any manner.
- Use only accessories recommended by the manufacturer.
- Avoid contact with hot surfaces. Use handles or knobs.
- Do not use the appliance outdoors.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not use the appliance for anything other than its intended use.
- Exercise extreme caution when moving an appliance containing hot liquid.
- Ensure the coffee pot is correctly seated in the main unit before operation.

## PRODUCT OVERVIEW

The BLACK+DECKER TCM730-B5 is an automatic multi-use appliance designed for preparing Turkish coffee, milk-based drinks, and warming milk. It features Opti-Sense technology to prevent overflow and automatic shut-off for safety.

### Components

- **Main Unit:** Houses the heating element and control panel.
- **Coffee Pot:** 300ml capacity, non-stick, with dual spouts for easy pouring.
- **Measuring Spoon:** Dual-size for precise ingredient measurement.
- **Cleaning Brush:** Specifically designed for convenient cleaning of the coffee pot.



Image: The BLACK+DECKER TCM730-B5 Turkish Coffee Maker main unit, coffee pot, measuring spoon, and cleaning brush.



Image: Close-up of the coffee pot showing the minimum and maximum fill lines for coffee and milk.

## Control Panel

The control buttons are conveniently located on the top of the main unit.

- **Milk Warming Button:** For heating milk.
- **Milk Drinks Button:** For preparing coffee with milk, hot chocolate with milk, or Turkish coffee with milk.
- **Turkish Coffee Button:** For preparing traditional Turkish coffee.



Image: Top view of the appliance showing the control buttons for Milk Warming, Milk Drinks, and Turkish Coffee.

## SETUP

1. **Unpack:** Carefully remove all packaging materials and ensure all components are present.
2. **Initial Cleaning:** Before first use, wash the coffee pot and measuring spoon with warm soapy water. Rinse thoroughly and dry. Wipe the main unit with a damp cloth.

3. **Placement:** Place the main unit on a dry, stable, and heat-resistant surface, away from water sources and direct heat.
4. **Power Connection:** Plug the appliance into a suitable power outlet.

## OPERATING INSTRUCTIONS

---

### General Operation

1. Ensure the coffee pot is clean and dry before use.
2. Place the coffee pot securely into the main unit.
3. Add your desired ingredients (water, coffee, milk, sugar) to the coffee pot, observing the MIN/MAX fill lines.
4. Select the desired function by pressing the corresponding button on the control panel. The button will illuminate to indicate operation.
5. The appliance will automatically shut off and emit a whistle alert when the preparation is complete.
6. Carefully remove the coffee pot by its handle and pour the prepared beverage.

### Preparing Turkish Coffee

1. Add water to the coffee pot according to the desired number of cups (up to 300ml, which makes 4-5 cups).
2. Add Turkish coffee powder using the provided measuring spoon. A common ratio is one full spoon (approx. 8g) per cup. Add sugar to taste.
3. Stir the mixture gently.
4. Place the coffee pot into the main unit.
5. Press the **Turkish Coffee** button. The Opti-Sense technology will monitor the brewing process to prevent overflow.
6. Once complete, the appliance will beep and shut off. Carefully pour and serve.



Image: A hand adding coffee grounds into the coffee pot using the measuring spoon.



Image: A finger pressing the Turkish Coffee button on the control panel.

### Preparing Milk Drinks (Coffee with Milk, Hot Chocolate with Milk, Turkish Coffee with Milk)

1. Add milk to the coffee pot, observing the MIN/MAX fill lines for milk.
2. Add your desired ingredients, such as instant coffee, hot chocolate powder, or Turkish coffee powder, and sugar to taste.
3. Stir the mixture gently.
4. Place the coffee pot into the main unit.
5. Press the **Milk Drinks** button.
6. Once complete, the appliance will beep and shut off. Carefully pour and serve.

### Milk Warming

1. Add milk to the coffee pot, observing the MIN/MAX fill lines for milk.
2. Place the coffee pot into the main unit.
3. Press the **Milk Warming** button.
4. Once complete, the appliance will beep and shut off. Carefully pour the warmed milk.

Your browser does not support the video tag.

Video: A demonstration of the BLACK+DECKER TCM730-B5 Turkish Coffee Maker's features, including its power, capacity, dual spouts, various drink options, and safety features like auto shut-off and boil-dry protection.

## CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your appliance.

1. **Unplug:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Clean Coffee Pot:** Wash the non-stick coffee pot with warm soapy water using the provided cleaning brush. Rinse thoroughly and dry completely. Do not use abrasive cleaners or scouring pads that could damage the non-stick coating.
3. **Clean Main Unit:** Wipe the exterior of the main unit with a soft, damp cloth. Do not immerse the main unit in water.
4. **Sensor Cleaning:** If you experience issues with water level detection, gently wipe the optical sensor lens inside the main unit's coffee pot slot with a soft, dry cloth. Reconnect power and try again.
5. **Storage:** Store the appliance in a dry place when not in use.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outage; faulty outlet.	Check power connection; try a different outlet; ensure coffee pot is correctly seated.
Coffee/milk overflows.	Too much liquid added; Opti-Sense sensor obstructed.	Do not exceed MAX fill line; ensure Opti-Sense sensor is clean and unobstructed.
Water level sensor malfunction (detects too high/low).	Sensor lens inside the unit is dirty or obstructed.	Wipe the sensor lens inside the main unit's coffee pot slot with a soft, dry cloth. Reconnect power and try again.
Beverage is not hot enough.	Insufficient heating time; incorrect program selected.	Ensure the correct program is selected. If the issue persists, contact customer support.

## SPECIFICATIONS

Feature	Detail
Brand	BLACK+DECKER
Model Number	TCM730-B5
Color	White/Black

<b>Feature</b>	<b>Detail</b>
Capacity	300 ml
Power/Wattage	735 Watts
Voltage	240V
Material	Plastic
Auto Shut-off	Yes
Special Features	Milk Heater, Hot Chocolate Maker, Turkish Coffee Maker
Item Weight	1.35 Kilograms
Product Dimensions	23 x 23 x 23 cm



Image: Diagram showing the dimensions of the BLACK+DECKER TCM730-B5 Turkish Coffee Maker (23cm x 23cm x 23cm).

## WARRANTY AND SUPPORT

This BLACK+DECKER appliance comes with a 2-year warranty. For warranty claims, technical support, or service

inquiries, please refer to the contact information provided in your product packaging or visit the official BLACK+DECKER website.

Keep your purchase receipt as proof of purchase for warranty purposes.