

Microsoft 8X6-00019

Microsoft Surface Pro Slim Pen 2 with Signature Keyboard User Manual

Model: 8X6-00019

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Microsoft Surface Pro Slim Pen 2 with Signature Keyboard. Please read this manual thoroughly before using the product to ensure proper functionality and to prevent damage.

The Surface Pro Slim Pen 2 with Signature Keyboard offers a perfect combination of versatility, enhancing your productivity and creative workflow.

PRODUCT OVERVIEW

The Microsoft Surface Pro Slim Pen 2 with Signature Keyboard is designed to seamlessly integrate with your Surface Pro device, providing a comfortable typing experience and precise digital inking capabilities.



Image: Microsoft Surface Pro Slim Pen 2 with Signature Keyboard in Black. This image displays the full keyboard layout, including the integrated Surface Slim Pen 2 stored in its charging cradle above the function keys. The keyboard features a Japanese QWERTY layout with Alcantara material.

Key Features:

- **Keyboard:** Japanese keyboard layout, Alcantara material, independent key type, QWERTY arrangement.
- **Surface Slim Pen 2:** Side button, top button with eraser function, 4,096 levels of pressure sensitivity, rechargeable lithium-ion battery.
- **Compatibility:** Designed for Surface Pro 8 and Surface Pro X.
- **Additional Features:** Full array function keys (F1-F12), Windows key, dedicated media control and brightness adjustment keys, right-click key, integrated storage and charging for Surface Slim Pen 2.

SETUP

1. **Attachment:** Align the magnetic connector of the Signature Keyboard with the bottom edge of your Surface Pro device. The keyboard will snap into place.
2. **Initial Connection:** Once attached, the keyboard will automatically connect to your Surface Pro. No additional pairing is required for the keyboard.
3. **Surface Slim Pen 2 Charging:** The Surface Slim Pen 2 charges wirelessly when stored in the designated slot above the function keys on the Signature Keyboard. Ensure the pen is properly seated for charging.
4. **Software Updates:** Ensure your Surface Pro operating system is up to date to ensure optimal performance and compatibility with the keyboard and pen.

OPERATING INSTRUCTIONS

Keyboard Usage:

- **Typing:** Use the QWERTY layout for standard typing. The independent key design provides a comfortable and responsive typing experience.
- **Function Keys (F1-F12):** These keys provide quick access to various system functions.
- **Media Control Keys:** Dedicated keys for controlling media playback (play, pause, skip) and adjusting volume.
- **Brightness Adjustment Keys:** Use these keys to increase or decrease screen brightness.
- **Windows Key:** Opens the Start menu or performs Windows-specific shortcuts.
- **Right-Click Key:** Functions as a right-click for context menus.
- **Trackpad:** The integrated trackpad supports multi-touch gestures for navigation and interaction.

Surface Slim Pen 2 Usage:

- **Writing and Drawing:** Use the pen directly on the Surface Pro screen for natural writing and drawing. The 4,096 pressure levels allow for precise control.
- **Side Button:** Customizable button for quick access to shortcuts or specific functions within applications.
- **Top Button (Eraser Function):** Press the top button to activate the eraser function in compatible applications. Double-tap or long-press for additional customizable actions.
- **Charging:** Place the pen in the keyboard's charging slot when not in use to ensure it remains charged.

MAINTENANCE

- **Cleaning the Keyboard:** Gently wipe the Alcantara surface with a soft, lint-free cloth. For stubborn stains, use a slightly damp cloth with mild soap, then wipe dry immediately. Avoid harsh chemicals or abrasive materials.
- **Cleaning the Pen:** Wipe the Surface Slim Pen 2 with a soft, dry cloth.
- **Storage:** When not in use, keep the keyboard attached to your Surface Pro or store it in a clean, dry place away from extreme temperatures and direct sunlight.
- **Battery Care (Pen):** To prolong the life of the rechargeable lithium-ion battery in the pen, avoid fully discharging it frequently. Charge it regularly by placing it in the keyboard's slot.

TROUBLESHOOTING

Problem	Possible Cause / Solution
Keyboard not responding.	Ensure the keyboard is securely attached to the Surface Pro. Restart your Surface Pro. Check for any pending Windows updates.
Surface Slim Pen 2 not writing or responding.	Ensure the pen is charged by placing it in the keyboard's charging slot for a few minutes. Check Bluetooth settings on your Surface Pro to ensure the pen is connected (if applicable, though it usually connects automatically when charged via keyboard). Restart your Surface Pro.

Problem	Possible Cause / Solution
Keys are sticky or unresponsive.	Clean the keyboard surface as described in the Maintenance section. Avoid spilling liquids on the keyboard.

SPECIFICATIONS

- **Brand:** Microsoft
- **Model Number:** 8X6-00019
- **Color:** Black
- **Material:** Alcantara
- **Product Dimensions (W x H x D):** Approximately 28.7 cm x 20.8 cm x 0.9 cm
- **Product Weight:** Approximately 390 g
- **Number of Keys:** 104 (Japanese layout)
- **Connectivity:** Magnetic connection to Surface Pro (Keyboard), Wireless charging/connection (Pen)
- **Pen Pressure Levels:** 4,096
- **Pen Battery:** Rechargeable Lithium-ion
- **Compatible Devices:** Surface Pro 8, Surface Pro X, Surface Pro 9
- **Recommended Use:** Office, Laptop Accessory

WARRANTY AND SUPPORT

This product comes with a **1-year manufacturer's warranty** when purchased from an authorized retailer. Please retain your proof of purchase for warranty claims.


For technical support, troubleshooting assistance, or warranty service, please visit the official Microsoft support website or contact Microsoft customer service. Refer to the "Safety and Warranty Information" document included with your product for detailed contact information and warranty terms.






Online Support: support.microsoft.com

© 2024 Microsoft Corporation. All rights reserved.

Product specifications are subject to change without notice.

Related Documents - 8X6-00019

	<p>Microsoft ME-MPP303 Stylus Pen for Surface - User Manual & Specifications</p> <p>User manual and specifications for the Microsoft ME-MPP303 Stylus Pen, compatible with various Surface devices. Details include auto-sleep feature, material, and printing specifications.</p>
---	--

	<p>Microsoft Surface Pro 4 User Manual</p> <p>A comprehensive user guide for the Microsoft Surface Pro 4, covering setup, features, software, and troubleshooting.</p>
	<p>Microsoft Office Product Key Installation and Redemption Guide</p> <p>A comprehensive guide on how to enter, redeem, and troubleshoot Microsoft Office product keys for various versions, including Microsoft 365, Office 2021, 2019, 2016, 2013, and 2010.</p>
	<p>Microsoft Surface Pro Trackpad Gestures Guide</p> <p>Learn how to use the Microsoft Surface Pro trackpad with detailed gestures for navigation, scrolling, zooming, and accessing features. Includes information on Windows 10 end-of-support.</p>
	<p>Microsoft Surface Laptop Go Quick Start Guide</p> <p>Get started with your Microsoft Surface Laptop Go. This guide covers setup, Windows Hello, battery health, safety information, and warranty details.</p>
	<p>Microsoft Surface Charging Port Replacement Guide</p> <p>Detailed step-by-step instructions for replacing the charging port on a Microsoft Surface RT (1st Gen) tablet. Includes required tools, parts, and visual descriptions of each repair stage.</p>