

RYGHT R483560

RYGHT LUMO R483560 Portable Bluetooth Speaker User Manual

Model: R483560

1. INTRODUCTION

Thank you for choosing the RYGHT LUMO R483560 Portable Bluetooth Speaker. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.

2. SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures, direct sunlight, or open flames.
- Although the speaker is waterproof, do not submerge it in water for extended periods. Ensure charging port cover is securely closed before exposure to water.
- Do not attempt to disassemble, repair, or modify the speaker. This will void the warranty.
- Keep the speaker away from children and pets.
- Use only the provided charging cable or a certified equivalent.
- Avoid listening at high volume levels for prolonged periods to prevent hearing damage.

3. PACKAGE CONTENTS

Please check that all items are present in your package:

- RYGHT LUMO R483560 Portable Bluetooth Speaker
- Micro USB Charging Cable
- Jack Cable (AUX cable)
- User Manual (this document)

4. PRODUCT OVERVIEW

The RYGHT LUMO R483560 is a portable Bluetooth speaker designed for both indoor and outdoor use, featuring dynamic RGB LED lighting and powerful sound. Familiarize yourself with the speaker's components and controls.



Figure 1: Top view of the RYGHT LUMO R483560 speaker, highlighting the control panel. From left to right, buttons include volume down, LED light mode, power, play/pause/call, and volume up.

Control Buttons:

- **Power Button ():** Press and hold to power on/off.
- **Volume Down (-):** Press to decrease volume. Press and hold to go to the previous track.
- **Volume Up (+):** Press to increase volume. Press and hold to go to the next track.
- **Play/Pause/Call Button ():** Press to play/pause music. Press to answer/end calls. Press and hold to reject calls.
- **LED Light Mode Button (*):** Press to cycle through different LED light modes or turn them off.

5. SETUP

5.1. Charging the Speaker

1. Locate the Micro USB charging port on the speaker.
2. Connect the Micro USB cable to the speaker's charging port.
3. Connect the other end of the USB cable to a USB power adapter (not included) or a computer's USB port.
4. The LED indicator will show charging status (e.g., red for charging, off when fully charged). A full charge takes approximately 3-4 hours.

Note: For optimal battery life, fully charge the speaker before first use.

5.2. Power On/Off

- **To Power On:** Press and hold the Power button () for approximately 3 seconds until you hear an audible prompt and the LED lights activate.
- **To Power Off:** Press and hold the Power button () for approximately 3 seconds until you hear an audible prompt and the LED lights turn off.

5.3. Bluetooth Pairing

1. Ensure the speaker is powered on and within pairing mode (the LED indicator will flash, indicating it's ready to pair).
2. On your mobile device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for available Bluetooth devices. You should see "RYGHT LUMO" or "R483560" in the list.
4. Select "RYGHT LUMO" or "R483560" to connect.
5. Once successfully paired, you will hear a confirmation sound, and the LED indicator will stop flashing and remain solid.
6. The speaker will automatically attempt to reconnect to the last paired device when powered on.

5.4. AUX Input

For devices without Bluetooth, you can use the included 3.5mm Jack cable:

1. Connect one end of the 3.5mm Jack cable to the AUX input port on the speaker.
2. Connect the other end to the headphone jack of your audio device.
3. The speaker will automatically switch to AUX mode.

6. OPERATING INSTRUCTIONS

6.1. Music Playback

- **Play/Pause:** Press the Play/Pause/Call button () once.
- **Next Track:** Press and hold the Volume Up button (⏮).
- **Previous Track:** Press and hold the Volume Down button (⏭).
- **Volume Adjustment:** Press the Volume Up (⏮) or Volume Down (⏭) buttons to adjust the volume.

6.2. Call Management

With the built-in microphone, you can manage calls directly from the speaker when connected via Bluetooth.

- **Answer Call:** Press the Play/Pause/Call button () once when an incoming call rings.
- **End Call:** Press the Play/Pause/Call button () once during a call.
- **Reject Call:** Press and hold the Play/Pause/Call button () for 2 seconds when an incoming call rings.

6.3. LED Light Control

The RYGHT LUMO R483560 features dynamic RGB LED lights that synchronize with your music.



Figure 2: Comparison of the RYGHT LUMO R483560 speaker with its LED lights off (top half) and on (bottom half), showcasing the vibrant RGB illumination.

- **Change Light Mode:** Press the LED Light Mode button (✱) repeatedly to cycle through different light patterns and colors.
- **Turn Off Lights:** Continue pressing the LED Light Mode button (✱) until the lights turn off.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.
- **Battery Care:** To maintain battery health, charge the speaker at least once every three months if not used regularly.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker using the provided Micro USB cable.
Cannot pair via Bluetooth.	Bluetooth is off on your device; speaker is too far; speaker is already paired to another device.	Ensure Bluetooth is enabled on your device. Move the speaker closer to your device. Disconnect from other devices or restart the speaker.
No sound.	Volume is too low; device is not connected; incorrect input mode.	Increase volume on both the speaker and your connected device. Ensure successful Bluetooth pairing or AUX cable connection.
LED lights are not working.	LED lights are turned off.	Press the LED Light Mode button (✱) to activate or cycle through modes.

9. SPECIFICATIONS




Figure 3: Dimensions of the RYGH T LUMO R483560 speaker.

Model Name:	LUMO R483560
Brand:	RYGHT
Connectivity Technology:	Bluetooth, USB (for charging)
Wireless Communication Technology:	Bluetooth
Special Features:	Bluetooth, RGB LED Lights, Built-in Microphone, Waterproof
Speaker Type:	Outdoor (Portable)
Maximum Speaker Output Power:	10 Watts
Power Source:	Cable Electric (Rechargeable Battery)
Battery Life:	Up to 8 hours
Product Dimensions (L x W x H):	8 x 8 x 18 cm
Item Weight:	484 Grams
Color:	Black
Included Components:	User Manual, Micro USB Cable, Jack Cable

10. WARRANTY AND SUPPORT

The RYGHT LUMO R483560 Portable Bluetooth Speaker comes with a **2-year manufacturer's warranty** from the date of purchase.

This warranty covers manufacturing defects. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

For warranty claims or technical support, please refer to the contact information provided on the product packaging or the official RYGHT website. Please have your proof of purchase ready.

© 2023 RYGHT. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question