Vieta Pro VHP-BT299MB

Vieta Pro Way 2 Bluetooth 5.0 On-Ear Headphones User Manual

Model: VHP-BT299MB

1. Introduction

Thank you for choosing the Vieta Pro Way 2 Bluetooth 5.0 On-Ear Headphones. This manual provides essential information for the proper setup, operation, and maintenance of your headphones. Please read it carefully before use to ensure optimal performance and longevity of your device.

2. Key Features

- **Bluetooth 5.0 Connectivity:** For stable and efficient wireless audio streaming.
- **Integrated Microphone:** Enables hands-free calling.
- **FM Radio Function:** Listen to your favorite radio stations directly from the headphones.
- **Micro SD Card Slot:** Play music directly from a Micro SD card.
- **Aux-in Port:** For wired connection to devices without Bluetooth.
- **Extended Battery Life:** Up to 40 hours of playback on a single charge.
- **Comfortable On-Ear Design:** Designed for prolonged listening comfort.

3. Package Contents

Please check that all items are present in your package:

- Vieta Pro Way 2 On-Ear Headphones
- USB Charging Cable
- 3.5mm Audio Cable (Aux-in)
- User Manual



Image: Retail packaging of the Vieta Pro Way 2 headphones, showing included accessories and key features.

4. Controls and Ports Overview

Familiarize yourself with the buttons and ports on your headphones:



Image: Folded Vieta Pro Way 2 headphones, highlighting the control panel on the right earcup.

1. **Power Button / Multi-function Button:** Press and hold to power on/off. Short press for Play/Pause, Answer/End Call.
2. **Volume Up / Next Track:** Short press for Volume Up. Long press for Next Track.
3. **Volume Down / Previous Track:** Short press for Volume Down. Long press for Previous Track.
4. **Mode Button (M):** Short press to switch between Bluetooth, FM Radio, and Micro SD modes.
5. **Micro SD Card Slot:** Insert a Micro SD card for direct music playback.
6. **3.5mm Aux-in Port:** Connect an audio cable for wired listening.
7. **USB Charging Port:** Connect the USB cable to charge the headphones.
8. **LED Indicator:** Shows power, charging, and pairing status.
9. **Microphone:** For hands-free calls.

5. Setup Guide

5.1 Charging the Headphones

1. Connect the USB charging cable to the USB charging port on the headphones.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will illuminate during charging and turn off or change color once fully charged.
4. A full charge takes approximately 2-3 hours.

5.2 Powering On/Off

- **To Power On:** Press and hold the Power Button for approximately 3 seconds until the LED indicator flashes.
- **To Power Off:** Press and hold the Power Button for approximately 3 seconds until the LED indicator turns off.

5.3 Bluetooth Pairing

1. Ensure the headphones are powered off.
2. Press and hold the Power Button for about 5 seconds until the LED indicator flashes blue and red alternately, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "Vieta Pro Way 2" from the list of devices.
5. Once paired, the LED indicator will flash blue slowly.

6. Operating Instructions

6.1 Music Playback (Bluetooth Mode)

- **Play/Pause:** Short press the Power Button.
- **Next Track:** Long press the Volume Up button.
- **Previous Track:** Long press the Volume Down button.
- **Volume Adjustment:** Short press the Volume Up or Volume Down buttons.

6.2 Call Management

- **Answer/End Call:** Short press the Power Button.
- **Reject Call:** Long press the Power Button.
- **Redial Last Number:** Double-press the Power Button.

6.3 FM Radio Mode

1. Press the Mode (M) Button to switch to FM Radio mode.
2. Long press the Power Button to automatically scan and save available FM stations.
3. Short press the Volume Up/Down buttons to switch between saved stations.
4. For optimal reception, ensure you are in an area with good signal strength.

6.4 Micro SD Card Playback

1. Insert a Micro SD card (with MP3 files) into the Micro SD card slot.
2. Press the Mode (M) Button to switch to Micro SD mode.
3. Music will start playing automatically. Use the Volume Up/Down buttons for track control and the Power Button for Play/Pause.

6.5 Aux-in Mode (Wired Connection)

1. Connect one end of the 3.5mm audio cable to the Aux-in port on the headphones.
2. Connect the other end to the audio output of your device.
3. The headphones will automatically switch to Aux-in mode. Note that button controls on the headphones may not function in this mode; control playback from your connected device.

7. Care and Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use abrasive cleaners or solvents.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, charge the headphones regularly, even if not in frequent use. Avoid fully discharging the battery for extended periods.
- **Water Resistance:** The headphones are water-resistant, but not waterproof. Avoid submerging them in water or exposing them to heavy rain.

8. Troubleshooting

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully.
Cannot pair via Bluetooth.	Headphones not in pairing mode; device Bluetooth off; too far apart.	Ensure headphones are in pairing mode (flashing red/blue). Turn device Bluetooth on/off. Move headphones closer to device.
No sound.	Volume too low; incorrect mode; device not playing.	Increase headphone and device volume. Check if correct mode (Bluetooth, Aux, SD) is selected. Ensure audio is playing on the source device.
Poor FM radio reception.	Weak signal.	Move to an area with better signal strength.

9. Technical Specifications

- **Model:** VHP-BT299MB
- **Connectivity:** Bluetooth 5.0, 3.5mm Aux-in
- **Frequency Range:** 20 Hz - 20,000 Hz
- **Battery Composition:** Lithium Polymer
- **Battery Life:** Up to 40 hours
- **Microphone:** Integrated
- **Additional Features:** FM Radio, Micro SD Card Playback
- **Material:** Plastic
- **Weight:** Approximately 430 g
- **Water Resistance:** Water-resistant

10. Warranty and Support

For warranty information, technical support, or service inquiries, please refer to the official Vieta Pro website or contact your local retailer. Keep your proof of purchase for any warranty claims.

© 2023 Vieta Pro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question