

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [ZACME](#) /

› ZACME KMA0270 Food Processor Kneading Machine User Manual

## ZACME KMA0270

# ZACME KMA0270 Food Processor Kneading Machine User Manual

Model: KMA0270

## 1. INTRODUCTION

---

Thank you for choosing the ZACME KMA0270 Food Processor Kneading Machine. This appliance is designed to simplify your kitchen tasks, offering powerful performance and versatile functionality for mixing, kneading, and whisking. With its robust 1500W motor, 7-liter stainless steel bowl, and 11-speed control, it is engineered for efficiency and durability. This manual provides essential information for the safe and effective operation, maintenance, and care of your new food processor.

Key features include a high-tech LCD display with countdown and restart functions, a low noise level (typically 45dB, not exceeding 70dB), and a durable die-cast metal housing. The included attachments – a dough hook, stirrer, and whisk – are made from stainless steel, ensuring longevity and hygiene.

## 2. SAFETY INSTRUCTIONS

---

Please read all safety instructions carefully before using the appliance to prevent injury or damage.

- Always unplug the appliance from the power outlet before assembly, disassembly, cleaning, or when not in use.
- Do not immerse the motor unit, cord, or plug in water or any other liquid.
- Keep hands, hair, clothing, and utensils away from moving parts during operation to prevent injury.
- Ensure the appliance is placed on a stable, flat, and dry surface during use.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner. Contact customer support for assistance.
- Close supervision is necessary when any appliance is used by or near children.
- Do not use attachments not recommended or sold by the manufacturer, as this may cause fire, electric shock, or injury.
- Avoid contact with moving parts.
- Do not use the appliance outdoors.
- Never leave the appliance unattended while it is operating.

- Ensure the tilt head is securely locked down before operating the machine.

### 3. PRODUCT OVERVIEW

The ZACME KMA0270 Food Processor consists of a main motor unit, a stainless steel mixing bowl, and various attachments designed for specific culinary tasks.



This image displays the ZACME KMA0270 Food Processor in an athletic white finish, featuring its main unit, a 7-liter stainless steel mixing bowl, and the three primary attachments: a whisk, a flat beater, and a dough hook. The tilt-head design is visible, along with the speed control dial and LCD display.

#### Components:

- **Motor Unit:** The main body housing the 1500W motor, speed control dial, LCD display, and tilt-head mechanism. It features an ergonomic carry handle and anti-slip suction feet for stability.
- **7L Stainless Steel Bowl:** A large capacity bowl suitable for various batch sizes, from small to large.
- **Dough Hook:** Designed for kneading heavy mixtures such as bread dough, pizza dough, and pasta dough.
- **Stirrer (Flat Beater):** Ideal for medium-heavy mixtures like cake batter, cookie dough, frostings, and

mashed potatoes.

- **Whisk:** Perfect for incorporating air into light mixtures such as egg whites, cream, meringues, and light batters.
- **Splash Guard:** A transparent lid that prevents ingredients from splashing out of the bowl during operation and allows for easy addition of ingredients.



This collage highlights several functional features of the ZACME KMA0270 Food Processor, including its height-adjustable mixing head, the 11-speed control dial, an ergonomic carry handle for portability, the lift-lock mechanism for secure operation, a digital time display for monitoring, and anti-slip suction feet for stability during use.

#### 4. SETUP

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Clean:** Before first use, wash the mixing bowl, attachments (dough hook, stirrer, whisk), and splash guard in warm, soapy water. Rinse thoroughly and dry. Wipe the motor unit with a damp cloth.
3. **Placement:** Place the motor unit on a clean, dry, flat, and stable surface. Ensure there is adequate space around the appliance for ventilation and operation.
4. **Attach Bowl:** Place the stainless steel mixing bowl onto the base of the motor unit. Turn it clockwise until it locks securely into place.

5. **Install Attachment:** Ensure the appliance is unplugged. Lift the tilt head by pressing the head release button. Select the desired attachment (dough hook, stirrer, or whisk) and push it upwards onto the attachment shaft, then turn it slightly counter-clockwise until it locks into place.
6. **Lower Head:** Lower the tilt head until it clicks securely into the locked position.
7. **Connect Power:** Plug the power cord into a suitable electrical outlet. The LCD display will illuminate.

## 5. OPERATING INSTRUCTIONS

### 5.1 Speed Control and Usage

The ZACME KMA0270 features 11 distinct speed settings, allowing precise control over your mixing tasks. The speed dial is located on the side of the motor unit.



This image illustrates the recommended speed settings for various tasks with the ZACME KMA0270 Food Processor. Speeds 1-4 are suitable for mixing dough, speeds 5-7 for stirring and general mixing, and speeds 8-11 for whipping cream and whisking.

- **Speeds 1-4 (Low):** Ideal for heavy mixtures such as kneading bread dough, mixing thick batters, or mashing potatoes. Use the dough hook attachment.
- **Speeds 5-7 (Medium):** Suitable for general mixing tasks like combining ingredients, stirring salad, or

making cookie dough. Use the stirrer (flat beater) attachment.

- **Speeds 8-11 (High):** Best for light mixtures requiring aeration, such as whipping cream, beating egg whites, or making meringues. Use the whisk attachment.

To start, turn the speed dial to the desired setting. To stop, turn the dial back to '0'.

## 5.2 Using the LCD Display

The high-tech LCD display provides useful information and control over your mixing process. It features countdown, break, and restart functions. When the power is on, the display illuminates, making it easy to monitor even in low light conditions.

## 5.3 Capacity Guidelines

The 7-liter stainless steel bowl can handle a variety of quantities:

- **Dry Flour:** 200g to 1500g
- **Egg Whites:** 2 to 20 egg whites
- **Sour Cream/Liquid:** 0.1L to 2L

The transparent splash guard should be used to prevent ingredients from spilling out, and it includes an opening to add ingredients during operation.

## 5.4 Continuous Operation

The appliance is designed to work for up to 60 minutes at a time, maintaining a surface temperature below 35°C under normal operating conditions.

## 5.5 Optional Accessories

The ZACME KMA0270 supports various optional extension accessories, such as pasta makers, meat grinders, and juice extractors, which can be purchased separately to further enhance its functionality.

# Versatile Accessories Make More Tasty Food



Slicer



Noodle Maker 3in1



Noodle Maker Set



Meat Grinders



Juice Extractor



More



This image demonstrates the versatility of the ZACME KMA0270 Food Processor, showcasing various optional attachments that can be purchased separately, such as a slicer, noodle maker, meat grinder, and juice extractor, expanding its functionality beyond standard mixing tasks.

## 6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your ZACME KMA0270 Food Processor.

1. **Unplug:** Always unplug the appliance from the power outlet before cleaning.
2. **Motor Unit:** Wipe the exterior of the motor unit with a soft, damp cloth. Do not use abrasive cleaners or immerse the motor unit in water.
3. **Mixing Bowl and Attachments:** The stainless steel mixing bowl, dough hook, stirrer, whisk, and splash guard are dishwasher safe. Alternatively, they can be washed by hand in warm, soapy water, rinsed thoroughly, and dried immediately.
4. **Drying:** Ensure all parts are completely dry before reassembling or storing the appliance.
5. **Storage:** Store the appliance in a clean, dry place, away from direct sunlight and out of reach of children.

## 7. TROUBLESHOOTING

---

If you encounter any issues with your ZACME KMA0270 Food Processor, please refer to the following common troubleshooting steps:

- **Appliance Does Not Turn On:**

- Check if the power cord is securely plugged into a working electrical outlet.
- Ensure the speed dial is set to a position other than '0'.
- Verify that the tilt head is fully lowered and locked into place.

- **Attachments Not Mixing Properly:**

- Ensure the attachment is correctly installed and locked onto the shaft.
- Check that the mixing bowl is securely locked onto the base.
- Adjust the height of the attachment if necessary (refer to product overview for height adjustment feature).

- **Excessive Noise or Vibration:**

- Ensure the appliance is on a stable, flat surface.
- Verify that the mixing bowl and attachment are correctly installed and locked.
- If the noise is unusual or persistent, discontinue use and contact customer support.

- **Motor Stops During Operation:**

- The appliance may have an overload protection feature. Turn off the machine, unplug it, and allow it to cool down for at least 30 minutes before attempting to use it again. Reduce the load if the bowl was overfilled.

If the problem persists after following these steps, please contact ZACME customer support for further assistance.

## 8. SPECIFICATIONS

---

Detailed technical specifications for the ZACME KMA0270 Food Processor Kneading Machine:

# 1500W STRONG MOTOR

7.4QT Large Capacity

16.5 KG

16.34inch

18.11inch

12.2inch



Rated Voltage  
AC 220-240V



Rated Frequency  
50-60Hz



Max Noise  
70 DBA

This diagram provides key specifications of the ZACME KMA0270 Food Processor, including its dimensions (18.11 inches width, 12.2 inches depth, 16.34 inches height), 1500W motor power, 7.4 quart (7L) large capacity, rated voltage of AC 220-240V, rated frequency of 50-60Hz, and a maximum noise level of 70 dBA.

Feature	Specification
Brand	ZACME
Model Number	KMA0270
Power / Wattage	1500W
Volume Capacity	7 Litres (7.4 quarts)
Number of Speeds	11
Noise Level	≤45dB (Max 70dB)

Voltage	220-240 Volts
Frequency	50-60Hz
Material	Stainless Steel (Bowl & Attachments), Die-cast Metal (Housing)
Product Dimensions	30.99 x 46 x 41.5 cm (approx. 12.2 x 18.11 x 16.34 inches)
Item Weight	12.5 kg
Special Features	1500W powerful copper motor, Adjustable Speed Control, All Steel Gears, Key control timing function, LED light as power indicator, MM32F0010 Constant speed chip controlled, Tilt Head
Product Care Instructions	Dishwasher Safe (accessories)

## 9. SUPPORT AND WARRANTY

---

For any questions, concerns, or issues regarding your ZACME KMA0270 Food Processor, please do not hesitate to contact ZACME-EU customer support. They are available to provide assistance and ensure you have a satisfactory experience with your product.

Regarding warranty information, please refer to your purchase documentation or contact the retailer from whom you purchased the product. Specific warranty terms and conditions may vary by region and retailer.