

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SOMIC](#) /

› [SOMIC GS510 Gaming Headset User Manual](#)

SOMIC GS510 3.5MM Roze

SOMIC GS510 Gaming Headset User Manual

Model: GS510 3.5MM Roze

INTRODUCTION

Thank you for choosing the SOMIC GS510 Gaming Headset. This manual provides essential information for setting up, operating, and maintaining your headset to ensure optimal performance and longevity. Please read this manual thoroughly before use.

WHAT'S IN THE Box

- Cat Ear Headset X1
- Speaker Tags x 4 (2 pairs)
- Splitter cable x1
- User Manual



Image: The SOMIC GS510 Gaming Headset in pink, shown with its detachable 3.5mm audio cable, USB cable for LED lights, and a splitter cable.

PRODUCT OVERVIEW AND FEATURES

The SOMIC GS510 Gaming Headset is designed for an immersive audio experience across multiple platforms.

- Stereo Surrounding Sound:** Equipped with large 50mm driver units for superior sound quality and realistic gaming audio.
- Retractable Noise Cancelling Microphone:** An omnidirectional, sensitive microphone provides clear communication by reducing background noise.
- Magnetic Speaker Tags & LED Light Effect:** Features 2 pairs of detachable magnetic speaker tags for customization and breathing LED lights (USB powered).
- Wide Compatibility:** Connects via a 3.5mm plug, compatible with PC, PS4, PS5, Xbox One, Nintendo Switch, laptops, iPads, and iPhones.
- Long-Lasting Comfort:** Soft protein foam earmuffs and breathable ear pads ensure comfort during extended use.
- Easy Button Control:** Conveniently located volume and microphone mute controls on the headset.

STEREO SURROUND SOUND

50mm powerful drivers bring you immersive gaming experience.



Image: An exploded view illustrating the 50mm powerful drivers that deliver stereo surround sound for an immersive gaming experience.



Image: Detail of the headset's controls, including the microphone mute switch and volume controller for easy adjustments.

SETUP

Follow these steps to connect your SOMIC GS510 Gaming Headset to your device.

- 1. Connect the 3.5mm Audio Jack:** Plug the 3.5mm audio jack from the headset into the corresponding audio port on your PC, laptop, PS4, PS5, Xbox One controller (a Microsoft adapter may be required for older Xbox One controllers, not included), Nintendo Switch, or mobile phone.



Image: Visual guide demonstrating how to connect the headset to Nintendo Switch, Xbox One, PS4/PS5, PC, and smartphones using the 3.5mm jack.

- 2. Connect USB for LED Lights (Optional):** If you wish to activate the LED light effect on the headset, connect the USB plug to a USB port on your device (PC, laptop, console with USB port). Note that the LED light effect is only available when the USB is connected. The light color is fixed (white).
- 3. Using the Splitter Cable:** For PCs with separate audio input (microphone) and output (headphone) jacks, use the included splitter cable. Connect the headset's 3.5mm jack to the splitter, then plug the two splitter ends into the appropriate microphone and headphone ports on your computer.

OPERATING INSTRUCTIONS

Volume Control

Adjust the volume using the scroll wheel located on the left earcup of the headset. Rotate the wheel upwards to increase volume and downwards to decrease volume.

Microphone Usage

The headset features a retractable microphone.

- **Extend/Retract:** Gently pull the microphone out from the left earcup to extend it for use, and push it back in to retract it when not needed.
- **Mute/Unmute:** Use the microphone mute switch located near the volume control on the left earcup. Flip the switch to mute or unmute your microphone.
- **Positioning:** For optimal voice clarity, position the microphone approximately 1-2 inches from your mouth.



Image: The retractable microphone, demonstrating its flexibility and precision pickup for clear communication.

Customizing Speaker Tags

The SOMIC GS510 comes with two pairs of magnetic speaker tags that can be easily interchanged.

- To change a speaker tag, gently pull the current tag off the earcup. It is held in place by magnets.
- Align the new speaker tag with the magnetic points on the earcup and allow it to snap into place.



Image: The headset with its DIY magnetic face covers, illustrating how they can be detached and swapped to change the headset's appearance.

MAINTENANCE

Proper care will extend the life of your SOMIC GS510 Gaming Headset.

- **Cleaning:** Use a soft, dry cloth to wipe down the headset. Do not use abrasive cleaners or solvents. For ear pads, a slightly damp cloth can be used, but ensure they are completely dry before use.

- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures. Avoid placing heavy objects on the headset.
- **Cable Care:** Avoid sharp bends or kinks in the cables. Do not pull on the cable to disconnect the headset; always grasp the plug.
- **Microphone:** When not in use, retract the microphone to protect it from damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from headset	Volume too low or muted. Incorrect audio output device selected. Cable not fully connected. Headset not compatible with device (e.g., old Xbox One without adapter).	Increase volume on headset and device. Check mute switch. Verify audio settings on your device and select the headset as the output. Ensure 3.5mm jack is fully inserted. For older Xbox One controllers, a Microsoft adapter is required.
Microphone not working	Microphone muted. Incorrect audio input device selected. Microphone not extended. Splitter cable issue (for PC).	Unmute microphone using the switch on the headset. Check device sound settings and select the headset microphone as the input. Ensure microphone is fully extended. If using a PC, ensure the splitter cable is correctly connected to both mic and headphone jacks.
LED lights not working	USB cable not connected. USB port issue.	Ensure the USB cable is securely plugged into a powered USB port. Try a different USB port on your device.

SPECIFICATIONS

Feature	Detail
Model Name	GS510-3.5MM - Pink
Connectivity Technology	Wired
Headphones Jack	3.5 mm Jack
Audio Driver Size	50 Millimeters
Frequency Range	20 Hz - 20 KHz
Noise Control	Active Noise Cancellation
Microphone Type	Retractable, Omnidirectional
Ear Placement	Over Ear

Feature	Detail
Material	Memory Foam (ear pads)
Item Weight	1.1 pounds (approx. 500 Grams)
Product Dimensions	8.66 x 4.33 x 10.24 inches
Compatible Devices	PC, Laptop, PS4, PS5, Xbox One, Mobile Phone, Nintendo Switch
Control Type	On Ear Button Control (Volume, Mic Mute)

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official SOMIC website or contact SOMIC customer service.

An official User Manual (PDF) is also available for download:[Download User Manual \(PDF\)](#).

For additional product information and support, visit the SOMIC Store:[SOMIC Official Store](#).

© 2024 SOMIC. All rights reserved.