

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Jensen](#) /

> [Jensen SMPS-628BK Under Cabinet Bluetooth Music System Instruction Manual](#)

Jensen SMPS-628BK - Black

Instruction Manual

JENSEN MODERN WIRELESS UNDER CABINET KITCHEN UNIVERSAL BLUETOOTH MUSIC SYSTEM

Model: SMPS-628BK

Introduction

The JENSEN SMPS-628 is a versatile Bluetooth Music System designed for space-saving under-cabinet installation. This unit combines an FM stereo receiver, digital clock with timer, and a built-in hands-free speakerphone with microphone, making it ideal for multitasking in the kitchen or any area where space is at a premium. It also features a built-in 4x LED work area light and an auxiliary input for connecting external audio devices.

Safety Information

- Read all instructions carefully before operating the unit.
- Keep this manual for future reference.
- Do not expose the unit to rain or moisture to prevent fire or shock hazards.
- Ensure proper ventilation; do not block any ventilation openings.
- Use only attachments/accessories specified by the manufacturer.
- Unplug the unit during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

Package Contents

Verify that all items listed below are included in your package:

- Jensen SMPS-628BLK Under Cabinet Kitchen Universal Bluetooth Music System
- Mounting Hardware
- 120V AC Adaptor

Features

- Supports A2DP, NFC for Easy Pairing
- FM Stereo Receiver with Presets and PLL Digital Tuning

- Auxiliary Input Jack for Connecting Your iPod, MP3 or other Digital Audio Players
- Bluetooth/NFC Enabled Phone Hands-free Speakerphone with Built-in Microphone
- Multi-function LCD Display
- Digital Volume Control
- Clock with Timer
- Space-Saving Under Cabinet Design
- Built-in 4x LED Work Area Light
- Power: 120V AC Adaptor (included)
- Battery Back-up: 2 x "AAA" Batteries (not included)

Setup

Mounting the Unit

The Jensen SMPS-628BK is designed for easy installation under kitchen cabinets or shelves. Use the included mounting hardware to securely attach the unit. Ensure the mounting surface is sturdy enough to support the unit's weight (approximately 2.09 pounds).



Image: The Jensen SMPS-628BK unit mounted discreetly under a kitchen cabinet, showcasing its compact design and integrated work light.

Power Connection

Connect the provided 120V AC adaptor to the unit's power input and then to a standard wall outlet. For battery backup of the clock and timer settings during power outages, insert 2 x "AAA" batteries (not included) into the battery compartment.

Operating Instructions

Controls Overview



Image: A detailed front view of the Jensen SMPS-628BK, highlighting the power, light, source, timer, memory/clock, pair, tune/skip, volume, and play/pause/M+ buttons, along with the LCD display and microphone.

Power On/Off

Press the **POWER** button (🔌) located on the left side of the unit to turn the system on or off.

Setting the Clock and Timer

Press the **MEM/CLK** button to enter clock setting mode. Use the **TUNE/SKIP** buttons to adjust the hour and minute. Press **MEM/CLK** again to confirm. The timer function allows you to set a countdown for various kitchen tasks.

FM Radio Operation

Press the **SOURCE** button until "FM" appears on the LCD display. Use the **TUNE/SKIP** buttons to manually tune to your desired FM frequency. To automatically scan and store presets, press and hold the **MEM/CLK** button. To recall presets, press the **PLAY/PAUSE/M+** button.

Bluetooth Pairing and NFC

To pair a Bluetooth device, press the **PAIR** button. The unit will enter pairing mode. Enable Bluetooth on your device and select "JENSEN SMPS-628" from the list. For NFC-enabled devices, simply tap your device to the NFC logo on the unit for quick pairing.

Auxiliary Input

Connect your iPod, MP3 player, or other digital audio players to the **AUX IN** jack using a 3.5mm audio cable (not included). Press the **SOURCE** button until "AUX" is displayed.

Hands-Free Speakerphone

When a Bluetooth-enabled phone is paired, you can use the built-in microphone and speakers for hands-free calls. Incoming calls will automatically pause audio playback. Press the **PLAY/PAUSE/M+** button to answer or end a call.

Work Area Light

Press the **LIGHT** button to turn the integrated 4x LED work area light on or off. This provides convenient illumination for your countertop.

Volume Control

Adjust the audio volume using the **VOL+** and **VOL-** buttons.



Image: A top-down view of the Jensen SMPS-628BK, illustrating the mounting points for secure under-cabinet installation.

Maintenance

To ensure the longevity and optimal performance of your Jensen Music System, follow these maintenance guidelines:

- **Cleaning:** Wipe the unit with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents.
- **Ventilation:** Keep the ventilation openings clear of dust and debris.
- **Battery Replacement:** Replace "AAA" backup batteries annually or when the clock display becomes dim or inaccurate during power outages.

Troubleshooting

Problem	Possible Cause / Solution
No Power	Ensure AC adaptor is securely plugged into the unit and a working wall outlet. Check if the wall outlet has power.
Poor FM Reception	Adjust the position of the unit or the antenna for better signal. Interference from other electronic devices may be present.
Bluetooth Device Not Pairing	Ensure the unit is in pairing mode (LED flashing). Make sure Bluetooth is enabled on your device and it's within range. Forget the device on your phone and try pairing again.
No Sound from Auxiliary Input	Ensure the source is set to "AUX". Check the audio cable connection to both the unit and the external device. Increase volume on both the unit and the external device.

Specifications

Feature	Detail
Model Number	SMPS-628BK


Feature	Detail
Brand	Jensen
Connectivity Technology	Auxiliary, Bluetooth, NFC
Color	Black
Speaker Type	Stereo
Power Source	Corded Electric (120V AC Adaptor included)
Battery Backup	2 x "AAA" Batteries (not included)
Item Weight	2.09 pounds
Package Dimensions	11.5 x 8.27 x 3.66 inches
Manufacturer	Jensen

Warranty and Support

For warranty information, technical support, or service inquiries, please refer to the contact details provided on the product packaging or visit the official Jensen website. Keep your proof of purchase for warranty claims.

© 2025 Jensen. All rights reserved.

Related Documents - SMPS-628BK - Black

	<p>JENSEN SMPS-560 Bluetooth Speaker with Color Changing LED Lamp: User Manual</p> <p>A comprehensive guide for the JENSEN SMPS-560 Bluetooth wireless speaker, covering setup, operation of Bluetooth and the color-changing LED lamp, safety precautions, specifications, and maintenance.</p>
	<p>Jensen JMC-1250 Bluetooth 3-Speed Stereo Turntable System User Manual</p> <p>Comprehensive user manual for the Jensen JMC-1250 Bluetooth 3-Speed Stereo Turntable Music System with Dual Cassette Deck. Learn about setup, operation, features, safety instructions, and troubleshooting.</p>

	<p>Jensen JAS-725 Amazon Alexa-Enabled Bluetooth/Wi-Fi Under Cabinet Smart Music System User Manual</p> <p>User manual for the Jensen JAS-725, an Amazon Alexa-enabled Bluetooth/Wi-Fi under cabinet smart music system. Provides setup, operation, safety, and troubleshooting instructions.</p>
	<p>Jensen SMPS-650 Bluetooth Wireless Stereo Speaker User Manual</p> <p>Comprehensive user manual for the Jensen SMPS-650 portable Bluetooth stereo speaker, covering setup, operation, safety, troubleshooting, and warranty information.</p>
	<p>Jensen SMPS-626 Waterproof Bluetooth Shower Speaker User Manual</p> <p>User manual for the Jensen SMPS-626 Waterproof Bluetooth Shower Speaker, covering setup, operation, features like multi-color lighting, Bluetooth pairing, TWS, and warranty information.</p>
	<p>Jensen JA Series Power Amplifier User Manual</p> <p>Comprehensive user manual for Jensen JA Series JA1CH, JA2CH, JA4CH, and JA5CH power amplifiers, covering installation, setup, troubleshooting, specifications, and connections.</p>