

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

### MEEDEN AFE-6059-YM

## MEEDEN Large Studio Artist Easel Instruction Manual

Brand: MEEDEN | Model: AFE-6059-YM

### INTRODUCTION

Thank you for choosing the MEEDEN Large Studio Artist Easel. This easel is designed to provide a stable and versatile platform for various artistic endeavors, from oil and acrylic painting to watercolor and pour painting. Constructed from solid German beechwood, it offers durability and adjustability to suit your creative needs. This manual provides essential information for the proper assembly, operation, maintenance, and troubleshooting of your easel.

### PRODUCT OVERVIEW

The MEEDEN Large Studio Artist Easel is an H-frame design, known for its stability and robust construction. Key features include:

- High-Quality Construction:** Made from solid German beechwood, hand-sanded and oil-finished for durability and aesthetic appeal.
- Sturdy Design:** Features a stable H-frame structure with rigid floor surface grip rubber feet to prevent toppling.
- Adjustable Tilt:** Allows for various painting angles, from vertical for oils/acrylics to forward for pastels, or a completely horizontal position for watercolors and pour painting. Quick-release hinges facilitate easy conversion.
- Multi-Purpose:** Includes a spacious artist's platform shelf for art supplies, suitable for students and professional artists.
- Foldable Design:** Can be folded for convenient storage when not in use.



**MEEDEN**



MEEDEN IS FOR ART



Figure 1: The MEEDEN Large Studio Artist Easel, showcasing its H-frame design and natural beechwood finish.




Figure 2: Detailed view of easel components, including the adjustable easel slide, premium metal hardware, solid German beechwood construction, and foldable art supplies plate.

## SETUP INSTRUCTIONS

The MEEDEN Large Studio Artist Easel is designed for straightforward assembly. Each wooden piece is labeled to assist with the process. Please follow these general steps:

1. Unpack all components and verify against the parts list (refer to your product packaging for a complete list).
2. Identify the main H-frame sections and connect them according to the provided diagrams.
3. Attach the canvas support trays and mast head, ensuring all adjustment knobs are accessible and functional.
4. Secure all fasteners firmly, but avoid over-tightening to prevent damage to the wood.
5. Ensure the easel is stable on a flat surface before use.

*Note: While assembly is generally easy, some users have reported needing to pay close attention to the orientation of parts and the length of screws. Ensure all parts are correctly aligned before tightening.*

# Adjustable Angles

The easel angle can be adjusted from horizontal to vertical, available for various painting needs




Figure 3: Illustration of the easel's adjustable angles, demonstrating how the canvas support can be tilted for various painting techniques.

## OPERATING INSTRUCTIONS

Your MEEDEN easel offers versatile adjustments for different artistic applications:

- **Adjusting Canvas Height:** Loosen the knobs on the canvas support trays and slide them up or down the main mast to the desired height. Tighten the knobs securely to lock the position.
- **Adjusting Easel Angle:** The easel features quick-release hinges that allow the main mast to tilt. Loosen the relevant fasteners and adjust the easel to your preferred angle. This allows for vertical painting (oil, acrylic), forward tilt (pastel), or a completely horizontal position (watercolor, pour painting). Secure all fasteners once the desired angle is achieved.
- **Using the Storage Shelf:** The spacious platform shelf at the bottom provides convenient storage for paints, brushes, and other art supplies.
- **Folding for Storage:** When not in use, the easel can be folded to save space. Loosen the necessary adjustment points and carefully fold the easel as demonstrated in the assembly instructions.



Figure 4: The easel configured in a horizontal position, ideal for watercolor or pour painting, demonstrating its convertible functionality.



## Foldable for Easy Storage

Figure 5: The easel folded into a compact form, illustrating its space-saving design for easy storage.

## MAINTENANCE

Proper maintenance will extend the life and functionality of your easel:

- **Cleaning:** Wipe down wooden surfaces with a soft, dry cloth. For stubborn paint marks, use a slightly damp cloth with mild soap, then dry immediately. Avoid harsh chemicals that can damage the wood finish.
- **Hardware Check:** Periodically inspect all screws, bolts, and adjustment knobs to ensure they are tight. Re-tighten as necessary, but do not over-tighten.
- **Wood Care:** As the easel is made of beechwood, avoid prolonged exposure to direct sunlight or extreme humidity, which can cause warping or cracking. An occasional application of wood oil can help maintain the finish.
- **Storage:** When storing the easel for extended periods, ensure it is clean, dry, and stored in a stable environment.

## TROUBLESHOOTING

If you encounter issues with your easel, consider the following common solutions:

- **Easel Feels Unstable:**

- Ensure all assembly screws and fasteners are securely tightened.
- Verify the easel is placed on a flat, level surface.
- Check that the rubber feet are intact and providing adequate grip.

- **Difficulty Adjusting Height/Angle:**

- Confirm that all adjustment knobs are fully loosened before attempting to move components.
- Inspect for any obstructions or debris in the sliding mechanisms.
- Ensure components are aligned correctly within their tracks.

- **Canvas Support Trays Are Loose:**

- Tighten the knobs on the canvas support trays. If they continue to loosen, inspect the internal mechanism for wear.
- If the wooden blocks or metal guides attached to the canvas supports appear damaged or detached, contact customer support for assistance.

## SPECIFICATIONS

<b>Brand</b>	MEEDEN
<b>Model Number</b>	AFE-6059-YM
<b>Material</b>	Beechwood
<b>Color</b>	Natural
<b>Easel Type</b>	H Frame Easel
<b>Max Canvas Height</b>	Up to 59 inches (149.9 cm)
<b>Max Easel Height</b>	Up to 88 inches (223.5 cm)
<b>Item Weight</b>	23.9 pounds (10.8 kg)
<b>Package Dimensions</b>	42.6 x 10.16 x 5.83 inches
<b>Assembly Required</b>	Yes

# Max Loading Capacity 33 lbs (15 Kg)




Figure 6: Key dimensions of the MEEDEN Large Studio Artist Easel, including maximum canvas height and overall easel height.

## WARRANTY AND SUPPORT



For warranty information, product support, or to inquire about replacement parts, please contact MEEDEN customer service directly. Refer to the contact information provided with your purchase or visit the official MEEDEN website.

*Note: This manual does not contain specific warranty terms. Please consult your purchase documentation for details.*

## OFFICIAL PRODUCT VIDEOS

No official product videos from the seller are available for embedding in this manual. For additional visual guides or demonstrations, please check the MEEDEN brand store or product page on Amazon.

## Related Documents

	<p><b><a href="#">MEEDEN WJ-7 Art Easel Assembly Instructions</a></b></p> <p>Step-by-step guide for assembling the MEEDEN WJ-7 art easel, including parts, hardware, and detailed instructions for a secure and stable setup.</p>
	<p><b><a href="#">MEEDEN W10B Art Easel Assembly Instructions and Warranty</a></b></p> <p>Detailed assembly instructions and limited lifetime warranty information for the MEEDEN W10B Art Easel. Includes a parts list, step-by-step assembly guide, and warranty terms for original purchasers.</p>