## TOZO A1

# TOZO A1 Wireless Earbuds User Manual

Model: A1 | Brand: TOZO

## Introduction

Thank you for choosing the TOZO A1 Wireless Earbuds. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before use.

## What's in the Box

- TOZO A1 Mini Wireless Earbuds
- Charging Case
- 5 pairs of Eartips (XS/S/M/XL/XXL)
- USB-C (A to C) cable (20cm)
- Quick Guide & User Manual

## Product Overview

The TOZO A1 earbuds are designed for comfort and high-quality audio. Below are key components and features.




Image: TOZO A1 Wireless Earbuds and their charging case, showcasing the compact design.





Image: A woman wearing the TOZO A1 earbuds, demonstrating their ergonomic and comfortable fit in the ear.




Image: Close-up of the TOZO A1 earbuds and case, highlighting the breathing light indicator for status updates.





Image: An exploded view illustrating the internal acoustic components of the TOZO A1 earbuds, emphasizing the Hi-Fi technology.

## Setup

### Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C cable to the charging case and a power source. The breathing light indicator on the earbuds will show charging status.

### Pairing with Your Device

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for "TOZO-A1" in the list of available Bluetooth devices and select it to connect.
4. Once connected, a voice prompt will confirm successful pairing.




Image: A visual representation of the one-step Bluetooth pairing process with a smartphone, showing the "connection successful" message.

## TOZO App Installation

For enhanced features and customization, download the TOZO App from your device's app store. The app allows for 32 preset EQ modes and access to user-shared EQ settings.





Image: Screenshots of the TOZO App interface, demonstrating the 32 preset EQ modes, white noise tracks, and user-shared EQs.

## Operating Your Earbuds

### Touch Controls

The TOZO A1 earbuds feature smart touch controls for various functions:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Volume Up:** Triple tap on the right earbud.
- **Volume Down:** Triple tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.
- **Activate Voice Assistant:** Press and hold either earbud for 3 seconds.

### Audio Features

The 6mm diameter speaker delivers a powerful and wide sound range with enhanced bass. Utilize the TOZO App to customize your audio experience with 32 preset EQ modes.

### Call Features

Equipped with two microphones for AI calls, the earbuds provide clear communication during phone calls.

### Wearing the Earbuds

Select the appropriate eartip size for a comfortable and secure fit. The ergonomic design ensures the earbuds remain discreet and comfortable, even during extended use or physical activity.




Image: The TOZO A1 earbuds depicted with feathers, illustrating their ultra-lightweight design (3.7g per earbud).

## Maintenance

### Cleaning

Regularly clean the earbuds and charging case with a soft, dry cloth. Avoid using abrasive materials or harsh chemicals. Ensure charging contacts are free of debris.

### Water Resistance

The TOZO A1 earbuds are IPX5 waterproof, meaning they are resistant to splashing water from any direction. They are suitable

for workouts and light rain, but should not be submerged in water.

### Battery Care

To maximize battery lifespan, avoid fully discharging the earbuds and case frequently. Store them in a cool, dry place when not in use. The earbuds provide 7 hours of listening time, and the charging case extends total playtime to 32 hours.




Image: The TOZO A1 earbuds and case, highlighting the 7 hours of listening time and 32 hours of total playtime with the charging case.

## Troubleshooting

| Problem | Possible Solution |
|---|---|
| Earbuds not pairing/connecting. | Ensure Bluetooth is enabled on your device. Place earbuds back in the case, close, then reopen to re-enter pairing mode. Forget "TOZO-A1" from your device's Bluetooth list and re-pair. |
| Only one earbud working. | Ensure both earbuds are charged. Place both earbuds back in the charging case, close the lid for 5 seconds, then open again. This often re-syncs them. |

| Problem | Possible Solution |
|---|---|
| No sound or low volume. | Check device volume and earbud volume. Ensure earbuds are properly seated in your ears. Clean any debris from the earbud speakers. |
| Charging issues. | Ensure the charging cable is securely connected. Clean the charging contacts on both the earbuds and the case. Try a different USB port or power adapter. |
| Touch controls unresponsive. | Ensure your fingers are clean and dry. Restart the earbuds by placing them in the case and taking them out. |

## Specifications

| Feature | Detail |
|---|---|
| Model Name | TOZO A1 |
| Connectivity Technology | Wireless (Bluetooth 5.3) |
| Bluetooth Range | 12 Meters |
| Earbud Weight | 3.7 Grams (each) |
| Water Resistance Level | IPX5 Waterproof |
| Battery Life (Earbuds) | 7 Hours (normal use) |
| Total Playtime (with Case) | 32 Hours |
| Charging Case Capacity | 400mAh |
| Audio Driver Size | 6 Millimeters |
| Frequency Response | 20Hz - 20kHz |
| Control Type | APP / Smart Touch Control / Volume Control |
| Included Components | Charging Case, 5 pairs of Eartips (XS/S/M/XL/XXL), USB-C (A to C) cable (20cm), TOZO A1 Mini Wireless Earbuds, Quick Guide & User Manual |

## Warranty and Support

For warranty information and customer support, please refer to the official TOZO website or the contact information provided in your product packaging. A digital version of the user guide is also available for download: User Guide (PDF).

© 2024 TOZO. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**