

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [beFree Sound](#) /
- › [beFree Sound BFS-2.1 Surround Sound Speaker System Instruction Manual](#)

beFree Sound BFS-2.1 Surround Sound Speaker System

beFree Sound 2.1 Channel Bluetooth Surround Sound Speaker System

Model: BFS-2.1 Surround Sound Speaker System

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your beFree Sound 2.1 Channel Bluetooth Surround Sound Speaker System. Designed for a sophisticated look and smooth sound, this system offers versatile listening options including Bluetooth, USB, SD, and FM radio capabilities. Please read this manual thoroughly before using the product to ensure proper function and longevity.



Image: The beFree Sound 2.1 Channel Bluetooth Surround Sound Speaker System, featuring a central subwoofer with blue LED lighting, two satellite speakers, and a remote control. Icons for Bluetooth, SD, USB, and FM radio are displayed below.

WHAT'S IN THE Box

- One 5.25" Amplifier (Subwoofer)
- Two 3" Satellite Speakers
- Remote Control
- 1 Audio Cable (RCA to 3.5mm)
- 1 FM Antenna

SETUP

1. Physical Connection

1. **Place the Subwoofer:** Position the subwoofer on a stable, flat surface, ideally near your audio source.
2. **Connect Satellite Speakers:** Connect the two satellite speakers to the corresponding output ports

on the back of the subwoofer. Ensure a secure connection for optimal sound.

3. **Power Connection:** Plug the power cord from the subwoofer into a standard electrical outlet.

2. Audio Input Connections

The system supports multiple audio input methods:

- **RCA Input:** Use the included audio cable (RCA to 3.5mm) to connect devices with RCA output (e.g., DVD player, TV) or 3.5mm output (e.g., smartphone, PC). Connect the red and white RCA plugs to the 'INPUT' ports on the subwoofer.
- **USB Drive:** Insert a USB flash drive into the USB port on the front panel of the subwoofer. The system will automatically detect and play compatible audio files.
- **SD Card:** Insert an SD card into the SD card slot on the front panel of the subwoofer. The system will automatically detect and play compatible audio files.
- **FM Antenna:** Connect the FM antenna to the designated port on the back of the subwoofer for improved radio reception. Extend the antenna for best results.

3. Bluetooth Pairing

1. **Activate Bluetooth Mode:** Press the 'SOURCE' button on the front panel or remote control until 'BT' appears on the display. The system will enter pairing mode, indicated by a flashing Bluetooth icon or indicator light.
2. **Enable Bluetooth on Your Device:** On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings and turn on Bluetooth.
3. **Select Speaker System:** Search for available devices and select "beFree Sound" or a similar name from the list.
4. **Confirm Pairing:** Once connected, the system will indicate successful pairing (e.g., a solid Bluetooth icon or a confirmation sound). You can now play audio from your device through the speaker system.

OPERATING INSTRUCTIONS

1. Power On/Off

Press the 'ST-BY/M' (Standby/Mode) button on the front panel or the power button on the remote control to turn the system on or off.

2. Selecting Input Mode

Press the 'SOURCE' button on the front panel or remote control repeatedly to cycle through available input modes: Bluetooth (BT), USB, SD, FM Radio, and AUX (Audio Input).

3. Volume Control

Adjust the master volume using the large rotary knob on the front panel of the subwoofer or the 'VOL+' and 'VOL-' buttons on the remote control.

4. FM Radio Operation

- **Auto Scan:** In FM mode, press and hold the 'PLAY/PAUSE' button on the remote or front panel to automatically scan and save available radio stations.
- **Manual Tuning:** Use the 'PREV' and 'NEXT' buttons to manually tune to specific frequencies or navigate through saved stations.

5. USB/SD Card Playback

When a USB drive or SD card is inserted, the system will automatically switch to the respective mode and begin playback. Use the 'PLAY/PAUSE', 'PREV', and 'NEXT' buttons on the front panel or remote control to manage playback.

6. Remote Control Functions

The full-function remote control allows for convenient operation of all system features, including power, mode selection, volume, track control, FM tuning, and bass boost.

FEATURES

- 2.1 Channel Surround Sound Configuration
- Bluetooth Wireless Connectivity (Range: 10 Meters)
- USB and SD Card Inputs for direct media playback
- Integrated FM Radio
- Audio Input and Output options
- Enhanced Bass Boost Ported Design
- Illuminated Display with Front Panel Controls
- Full-Function Remote Control
- Frequency Response: 40Hz-20KHz
- Signal-to-Noise Ratio (S/N Ratio): >75dB
- Separation: >50dB



Image: The beFree Sound 2.1 Channel Bluetooth Surround Sound Speaker System, highlighting its connectivity options including Bluetooth, SD card, USB, and FM radio.

SPECIFICATIONS

Model Name	BFS-2.1 Surround Sound Speaker System
Brand	beFree Sound
Speaker Type	Surround Sound
Surround Sound Channel Configuration	2.1
Connectivity Technology	Bluetooth, USB
Wireless Communication Technology	Bluetooth
Bluetooth Range	10 Meters
Subwoofer Diameter	5.25 Inches
Speaker Size (Satellite)	3 Inches
Speaker Maximum Output Power	60 Watts
Frequency Response	40Hz-20KHz
Signal-to-Noise Ratio	>75dB

Separation	>50dB
Power Source	Corded Electric
Control Method	Remote
Product Dimensions	13.22"D x 13.22"W x 13"H
Item Weight	18.46 pounds (8.39 Kilograms)
UPC	840191201196

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior surfaces of the speakers and subwoofer. Do not use liquid cleaners or abrasive materials.
- **Ventilation:** Ensure that the subwoofer and speakers have adequate ventilation. Do not block any ventilation openings.
- **Placement:** Avoid placing the system in direct sunlight, near heat sources, or in areas with high humidity or dust.
- **Power Off:** Always turn off and unplug the system before cleaning or if it will be unused for an extended period.

Troubleshooting

- **No Power:** Check if the power cord is securely plugged into both the subwoofer and the electrical outlet. Ensure the outlet is functional.
- **No Sound:**
 - Verify the system is powered on and the volume is turned up.
 - Ensure the correct input mode (Bluetooth, USB, SD, FM, AUX) is selected.
 - Check all audio cables for secure connections.
 - If using Bluetooth, ensure your device is paired and connected.
- **Bluetooth Not Connecting:**
 - Make sure the speaker system is in Bluetooth pairing mode.
 - Ensure your device's Bluetooth is enabled and within range (10 meters).
 - Try unpairing and re-pairing the device.
 - Restart both the speaker system and your Bluetooth device.
- **Poor FM Reception:** Extend and adjust the position of the FM antenna. Try moving the system to a different location.
- **USB/SD Card Not Playing:** Ensure the USB drive or SD card is inserted correctly and contains compatible audio files (e.g., MP3). Try a different USB drive or SD card.

Warranty and Support

This beFree Sound speaker system comes with a Limited Warranty. Please refer to the warranty card

included with your product for specific terms and conditions. For technical support or warranty claims, please contact beFree Sound customer service through their official website or the retailer where the product was purchased.