

[Manuals.plus](#) /

› [beFree Sound](#) /

› beFree Sound Portable Bluetooth Speaker with Dual 12-inch Subwoofers User Manual

beFree Sound Speaker with Subwoofer

beFree Sound Portable Bluetooth Speaker with Dual 12-inch Subwoofers User Manual

Model: Speaker with Subwoofer

1. INTRODUCTION

Thank you for choosing the beFree Sound Portable Bluetooth Speaker. This powerful audio system features dual 12-inch subwoofers, reactive party lights, and multiple connectivity options including Bluetooth, USB, SD, TF, AUX, and FM radio. This manual provides essential information for safe operation, setup, and maintenance of your speaker.

2. PACKAGE CONTENTS

Please check the box for the following items:

- beFree Sound Portable Bluetooth Speaker
- Wireless Microphone
- Remote Control
- Charging Power Cord
- User Manual (this document)

3. SAFETY INFORMATION

To ensure safe operation and prevent damage, please read and follow these safety guidelines:

- Do not expose the speaker to water, moisture, or extreme temperatures.
- Do not open the speaker casing. Refer all servicing to qualified personnel.
- Use only the provided charging power cord.
- Keep the speaker away from heat sources and direct sunlight.
- Ensure proper ventilation around the speaker during operation.

- Avoid placing heavy objects on the speaker.

4. SETUP

4.1 Powering On and Charging

1. Connect the provided charging power cord to the speaker's power input and then to a standard electrical outlet.
2. The speaker contains an internal rechargeable Lithium Ion battery. Allow sufficient time for the battery to fully charge before first use.
3. To power on the speaker, locate the power switch, typically on the rear or control panel, and switch it to the 'ON' position.

4.2 Connecting Microphones

The speaker supports both wired and wireless microphones.

- **Wireless Microphone:** The included wireless microphone will automatically pair with the speaker when both are powered on. Ensure the microphone has fresh batteries.
- **Wired Microphone:** Connect a wired microphone (not included) to the designated Microphone Input jack on the control panel.
- Use the 'Mic Priority Switch' if available, to prioritize microphone audio over music playback.





Figure 1: Front view of the beFree Sound Portable Bluetooth Speaker, showcasing the dual 12-inch subwoofers with reactive LED lights and the overall design. A wireless microphone and remote control are shown alongside the speaker.

5. OPERATING INSTRUCTIONS

5.1 Bluetooth Connectivity

1. Power on the speaker.
2. Press the 'Mode' button on the control panel or remote control until 'Bluetooth' mode is selected. The speaker will indicate it is ready for pairing.
3. On your mobile device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select 'beFree Sound' (or similar name) from the list of devices.
5. Once paired, the speaker will confirm the connection, and you can begin playing audio from your device.

5.2 USB/SD/TF Card Playback

1. Insert a USB flash drive, SD card, or TF card (with compatible audio files) into the corresponding slot on the speaker's control panel.
2. The speaker should automatically switch to USB/SD/TF mode and begin playing audio. If not, press the 'Mode' button to select the correct input.

3. Use the 'Play/Pause', 'Next Track', and 'Previous Track' buttons on the speaker or remote control to manage playback.

5.3 AUX Input

1. Connect an external audio device (e.g., MP3 player, laptop) to the speaker's AUX input jack using a 3.5mm audio cable (not included).
2. Press the 'Mode' button until 'AUX' mode is selected.
3. Control audio playback and volume from your connected device.

5.4 FM Radio

1. Press the 'Mode' button until 'FM Radio' mode is selected.
2. Extend the antenna for better reception.
3. Use the 'Scan' button (if available) to automatically search and save available radio stations.
4. Use the 'Next Track' and 'Previous Track' buttons to navigate between saved stations or manually tune.

5.5 Dual Layer Reactive Party Lights

The speaker features dual-layer reactive LED lights that respond to the audio. These lights can be turned on or off using a dedicated button on the control panel or remote control, allowing you to customize the visual experience.

5.6 Sound Control Knobs

Adjust the overall volume, bass, and treble using the dedicated sound control knobs on the speaker's control panel to fine-tune your audio experience.



Figure 2: The beFree Sound Portable Bluetooth Speaker with visual indicators for USB, Bluetooth, SD card, and FM radio connectivity options, highlighting its versatile input capabilities.

6. MAINTENANCE

Proper maintenance ensures the longevity of your speaker:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the speaker. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Battery Care:** If storing for an extended period, charge the battery periodically to maintain its health.

7. TROUBLESHOOTING

If you encounter issues with your speaker, refer to the following common problems and solutions:

Problem	Possible Solution
No power	Ensure the power cord is securely connected and the power switch is 'ON'. Check if the battery is charged.
No sound	Check the volume levels on both the speaker and the connected device. Ensure the correct input mode is selected.
Bluetooth not connecting	Ensure the speaker is in Bluetooth pairing mode. Disable and re-enable Bluetooth on your device. Move closer to the speaker.
Microphone not working	Check microphone batteries (for wireless). Ensure the microphone is properly connected (for wired). Adjust microphone volume.
Lights not working	Ensure the light feature is turned on.

8. SPECIFICATIONS

Feature	Detail
Brand	beFree Sound
Model Number	Speaker with Subwoofer
Mounting Type	Freestanding, Plug Mount
Power Source	Corded Electric
Audio Inputs	Bluetooth, USB, SD, TF, AUX, Wired Microphone, Wireless Microphone
Number of Channels	2
Item Weight	54 Pounds
Product Dimensions (L x W x H)	40 x 40 x 50 inches
Batteries	1 Lithium Ion battery required (included)
UPC	840191201189

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official beFree Sound website. Keep your proof of purchase for warranty claims.

