Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

S-Link IP-G10RW

S-link IP-G10RW 10000mAh Wireless Portable Power Bank User Manual

Model: IP-G10RW

Introduction Safety Information Product Overview Setup Operating Instructions Maintenance Troubleshooting Specifications Warranty Support

1. Introduction

This manual provides detailed instructions for the safe and efficient use of your S-link IP-G10RW 10000mAh Wireless Portable Power Bank. Please read this manual thoroughly before using the product and retain it for future reference. This power bank is designed to provide portable charging for various electronic devices, including smartphones and tablets, via wired (USB, Type-C, Micro USB) and wireless charging capabilities.

2. Safety Information

To ensure safe operation and prevent damage, please observe the following precautions:

- Do not expose the power bank to extreme temperatures, direct sunlight, or fire.
- Avoid dropping, impacting, or disassembling the device.
- Keep the power bank away from water, moisture, and corrosive materials.
- Do not use the power bank if it is damaged, swollen, or leaking.
- Keep out of reach of children.
- Use only certified charging cables and adapters.
- Do not attempt to charge the power bank and another device simultaneously using the same port.
- Dispose of the power bank according to local regulations for electronic waste.

3. Product Overview

The S-link IP-G10RW power bank features multiple charging options and an LCD screen for battery status.




Figure 1: Front view of the S-link IP-G10RW power bank, showing the textured black surface, power button, USB-A output port, and Type-C input/output port. A small loop for a lanyard is also visible.

3.1 Components

- **Power Button:** Activates the power bank and displays battery level.
- **LCD Screen:** Shows current battery percentage and charging status.
- **USB-A Output Port:** For charging devices via standard USB cable.
- **Type-C Input/Output Port:** For charging the power bank or charging devices.
- **Micro USB Input Port:** For charging the power bank.
- **Wireless Charging Pad:** For wireless charging compatible devices.

4. Setup

4.1 Initial Charging of the Power Bank

Before first use, fully charge your S-link IP-G10RW power bank.

1. Connect a compatible USB cable (Type-C or Micro USB) to the corresponding input port on the power bank.
2. Connect the other end of the cable to a USB wall adapter (not included) or a computer's USB port.
3. The LCD screen will display the charging progress. Charge until the screen shows 100%.
4. Once fully charged, disconnect the cable.

Note: A full charge may take several hours depending on the power source.

5. Operating Instructions

5.1 Checking Battery Level

Press the power button once to activate the LCD screen and view the current battery percentage.

5.2 Charging Devices via Cable

1. Connect your device's charging cable to the USB-A output port or the Type-C input/output port on the power bank.
2. Connect the other end of the cable to your device.
3. The power bank will automatically begin charging your device. If not, press the power button once.
4. The LCD screen will indicate that a device is being charged.
5. Disconnect your device once charging is complete.

5.3 Charging Devices Wirelessly

This feature is compatible with Qi-enabled devices.

1. Press the power button once to activate the wireless charging function.
2. Place your Qi-enabled device directly onto the wireless charging pad area of the power bank. Ensure the device is centered for optimal charging.
3. The LCD screen may indicate wireless charging activity. Your device should also show that it is charging.
4. Remove your device once charging is complete.

Note: Remove any metallic objects or thick cases from your device before wireless charging to ensure proper function.

6. Maintenance

6.1 Cleaning

Wipe the power bank with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.

6.2 Storage

Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures. If storing for extended periods, charge the power bank to approximately 50-70% every three months to maintain battery health.

7. Troubleshooting

- **Power bank not charging:**
  - Ensure the charging cable is securely connected to both the power bank and the power source.
  - Try a different charging cable or wall adapter.

- Check if the power source is active.

- **Device not charging from power bank:**
  - Press the power button on the power bank to activate output.
  - Ensure your device's charging cable is securely connected to both the power bank and your device.
  - Try a different charging cable.
  - Check if your device is compatible with the power bank's output specifications.
  - For wireless charging, ensure your device is Qi-enabled and properly centered on the charging pad. Remove any thick cases or metallic objects.

- **LCD screen not turning on:**
  - The power bank battery might be completely depleted. Charge the power bank.
  - Press the power button firmly.

8. Specifications

Feature	Detail
Model Number	IP-G10RW
Brand	S-Link
Battery Capacity	10000 mAh
Battery Cell Composition	Lithium Polymer
Connector Type	USB, Type-C, Micro USB (for input)
Power Source	Battery Powered
Number of Ports	2 (USB-A output, Type-C input/output)
Compatible Devices	Mobile Phones (Universal Compatibility)
Reusability	Rechargeable
Recommended Use	Charging
Color	Black
Item Weight	300 Grams
Product Dimensions (L x W x H)	13.3 x 6.5 x 1.5 cm

9. Warranty Information

The S-link IP-G10RW power bank comes with a 2-year warranty from the date of purchase. This warranty covers manufacturing defects. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

10. Customer Support

For technical assistance, warranty claims, or further inquiries, please contact S-link customer support. Refer to the product packaging or the official S-link website for the most up-to-date contact information.
S-link Official Website: www.s-link.com.tr (Example link, actual link may vary)

© 2023 S-Link. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09FZGQM91

More documents and user manuals: **https://manuals.plus/**