

[manuals.plus](#) /

› [Motorola](#) /

› [Motorola Edge \(2021\) Smartphone User Manual](#)

Motorola Motorola Edge (2021)

Motorola Edge (2021) Smartphone User Manual

Model: Motorola Edge (2021)

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Motorola Edge (2021) smartphone. Please read this guide thoroughly before operating your device.



The Motorola Edge (2021) smartphone in Nebula Blue, showcasing its sleek design from both the front and rear.

2. SETUP

2.1. Powering On/Off

To power on your device, press and hold the Power button located on the side until the Motorola logo appears. To power off, press and hold the Power button, then select 'Power off' from the on-screen options.

2.2. SIM Card and MicroSD Card Installation

Locate the SIM tray on the side of your device. Use the provided SIM tray ejector tool to open the tray. Insert your Nano-SIM card(s) and/or a microSD card into the designated slots. Ensure the cards are correctly oriented before reinserting the tray into the device.



A detailed side view of the Motorola Edge (2021) smartphone, illustrating the placement of its physical buttons and ports.

3. OPERATING INSTRUCTIONS

3.1. Basic Navigation

Your Motorola Edge (2021) runs on the Android operating system. Navigate through the interface using touch gestures: tap to select, swipe to scroll, pinch to zoom.

3.2. Fingerprint Sensor

The fingerprint sensor is integrated into the Power button. To unlock your device, simply place your registered finger on the Power button. For initial setup, go to Settings > Security > Fingerprint to register your fingerprints.

3.3. Camera Usage

The device features a 108MP main camera. Open the Camera app from your home screen or lock screen. Tap the shutter button to take a photo. Use the on-screen controls to switch between different modes (e.g., Portrait, Night Vision) and lenses (e.g., wide-angle, macro).



The back of the Motorola Edge (2021) smartphone, featuring its prominent triple camera system and Motorola logo.

4. MAINTENANCE

4.1. Battery Care

The Motorola Edge (2021) is equipped with a 5000 mAh battery, providing extended usage. For optimal battery longevity, avoid extreme temperatures and do not leave the device fully discharged for prolonged periods. Charging from 0% to 100% typically takes approximately 85 minutes.

4.2. Software Updates

Ensure your device's software is up-to-date for the best performance and security. Go to Settings > System

> System updates to check for and install available updates.

5. TROUBLESHOOTING

5.1. Common Issues

If your device is unresponsive, try a force restart by pressing and holding the Power button for about 10-15 seconds until the device restarts.

5.2. Factory Reset

If you experience persistent issues, a factory reset may be necessary. **Warning: This will erase all data on your device.** Back up important data before proceeding. Go to Settings > System > Reset options > Erase all data (factory reset).

6. SPECIFICATIONS

- **Model Name:** Motorola Edge (2021)
 - **Dimensions:** 6.65 x 2.98 x 0.35 inches
 - **Weight:** 7 ounces (0.44 Pounds)
 - **Screen Size:** 6.8 Inches
 - **Resolution:** 1080 x 2460 pixels
 - **Operating System:** Android
 - **CPU Model:** Snapdragon
 - **CPU Speed:** 1.9 GHz
 - **RAM:** 8 GB
 - **Storage:** 256 GB
 - **Battery Capacity:** 5000 Milliamp Hours
 - **Charging Time:** Approximately 85 minutes (0-100%)
 - **Wireless Carrier:** Unlocked for All Carriers
-

7. WHAT'S IN THE BOX

Your Motorola Edge (2021) package includes:

- Motorola Edge (2021) Smartphone
 - USB Cable
 - SIM Tray Ejector
-

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your device or visit the official Motorola support website. Keep your proof of purchase for warranty claims.
