

SUPACOOOL SPC3201

SUPACOOOL Casual Laptop Backpack Instruction Manual

Model: SPC3201

PRODUCT OVERVIEW

The SUPACOOOL Casual Laptop Backpack is designed for versatility and comfort, suitable for daily use, school, college, business trips, and travel. It features a durable, waterproof oxford 900D fabric construction, ample storage capacity, and a convenient built-in USB charging port.



Image: The SUPACOOOL Casual Laptop Backpack in its full black design, showcasing its sleek and minimalist appearance.

SETUP

Adjusting Shoulder Straps

The backpack features adjustable shoulder straps designed to prevent slipping and ensure a comfortable fit. To adjust, simply pull the loose ends of the straps to tighten or loosen them until the backpack rests comfortably on your back and shoulders.

Utilizing the USB Charging Port

The backpack includes a built-in USB charging port on the exterior and a charging cable inside. To use this feature:

1. Locate the internal charging cable within the main compartment.
2. Connect your portable power bank (not included) to the internal charging cable.
3. Connect your mobile phone or other USB-powered device to the external USB port using your own USB cable.

Note: The backpack itself does not power devices; the USB port provides convenient access to your own power bank.



Image: A visual guide demonstrating how to connect a power bank inside the backpack to the external USB charging port for convenient device charging.

OPERATING THE BACKPACK

Storage and Organization

The SUPACOOOL backpack offers multiple compartments for efficient organization:

- **Main Compartment:** Spacious enough to hold up to 15.6-inch laptops, iPads, books, and other large items.
- **Front Zipped Pockets:** Ideal for smaller items requiring quick access, such as pens, notebooks, or personal accessories.
- **Flexible Side Pockets:** Designed to securely hold water bottles or umbrellas.




Image: An illustration of the backpack's interior, highlighting its large capacity and various pockets for organized storage of school supplies, work files, and travel accessories.

PRACTICAL SCHOOL BACKPACK



Water Resistant



Extra Long Pullers



Flexible Side Pockets



Front Zipped Pockets

Image: Close-up views of the backpack's practical features, including its water-resistant material, extra-long zipper pullers, flexible side pockets, and front zipped pockets.

MAINTENANCE

Cleaning Instructions

To maintain the quality and appearance of your SUPACOOL backpack:

- For minor spills or dirt, wipe the surface with a damp cloth and mild soap.
- Do not machine wash, bleach, or tumble dry.
- Air dry the backpack completely before storing to prevent mildew.

Care for Zippers and Fabric

The backpack is made from waterproof oxford 900D fabric, which is wearing-resistant. To ensure longevity:

- Regularly check zippers for any debris and clear them to ensure smooth operation.
- Avoid overpacking the backpack, as this can strain zippers and seams.

TROUBLESHOOTING

USB Charging Port Not Working

- Ensure your power bank is fully charged and properly connected to the internal cable.
- Verify that your external USB cable is functioning correctly and securely connected to both your device and the backpack's external port.
- Remember, the backpack does not contain a battery; it only facilitates the connection to your own power bank.

Zipper Sticking or Breaking

- Check for any fabric caught in the zipper teeth and gently pull it free.
- Apply a small amount of zipper lubricant (e.g., wax, graphite from a pencil) to the teeth to improve smoothness.
- Avoid forcing the zipper if it's stuck, as this can cause damage.

SPECIFICATIONS

Feature	Detail
Product Dimensions	5.1 x 12.6 x 16.9 inches
Item Weight	1.17 pounds (0.53 kg)
Capacity Total	20 Liters
Material	Waterproof Oxford 900D Fabric
Model Number	SPC3201
Laptop Compatibility	Up to 15.6 inches

DIMENSION



Image: A detailed diagram illustrating the dimensions of the SUPACOOOL backpack and its compatibility with a 15.6-inch laptop.

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or additional support, please refer to the official SUPACOOOL store on Amazon or contact their customer service directly. Specific warranty details were not provided in this manual.

[Visit the SUPACOOOL Store](#)