



[Manuals.plus](#) /

> [CURECURE](#) /

> CURECURE Heated Electric Blanket HLB-TF User Manual

## CURECURE HLB-TF

# CURECURE Heated Electric Blanket HLB-TF User Manual

Model: HLB-TF | Size: 62" x 84" Twin

---

## 1. INTRODUCTION

Thank you for choosing the CURECURE Heated Electric Blanket. This manual provides essential information for the safe and effective use of your new electric blanket. Please read all instructions carefully before use and retain this manual for future reference.

This electric blanket is designed to provide warmth and comfort with its soft flannel material, adjustable heating levels, and automatic shut-off feature. It is suitable for home and office use.



Image 1.1: The CURECURE Heated Electric Blanket, folded, showcasing its soft flannel texture and the attached digital controller.

## 2. IMPORTANT SAFETY INSTRUCTIONS

**WARNING:** To reduce the risk of burns, electric shock, fire, or injury, this product must be used in accordance with the following instructions.

- Read all instructions before using this blanket.
- Do not use with an infant, a child, an invalid, or any person insensitive to heat, such as a person with poor blood circulation.
- Do not use on a person who cannot operate the controls properly.
- Do not use with a damaged cord or plug. If the cord or plug is damaged, do not use the blanket. Contact customer support for assistance.
- Do not use this blanket in conjunction with another heating pad or blanket.
- Do not tuck in the blanket, pinch it, or fold it tightly. Avoid placing heavy objects on the blanket when in use.
- Do not use for pet warming.
- Do not dry clean this product. Cleaning solvents may damage the insulation of the heating element.
- Always unplug the blanket from the electrical outlet when not in use.
- The blanket features a built-in overheating protection mechanism to prevent risks. However, always ensure proper ventilation and avoid covering the controller.
- This product is for household use only.



Image 2.1: The CURECURE Electric Blanket is FCC and ETL certified, indicating adherence to safety standards.

### 3. PACKAGE CONTENTS

Upon opening your package, please ensure all items are present and in good condition:

- 1 x CURECURE Heated Electric Blanket (62" x 84" Twin Size)
- 1 x Digital Controller with Power Cord
- 1 x User Manual

### 4. SETUP

1. **Unpack:** Carefully remove the electric blanket and controller from its packaging.
2. **Inspect:** Check the blanket and power cord for any signs of damage. Do not use if damaged.
3. **Connect Controller:** Locate the connector on the blanket and firmly plug the controller's cord into it. Ensure a secure connection.
4. **Position Blanket:** Lay the blanket flat on your bed or desired surface. Ensure it is not folded, bunched, or tucked in tightly, as this can cause overheating in specific areas.
5. **Plug In:** Plug the power cord into a standard 120V AC electrical outlet.

## 5. OPERATING INSTRUCTIONS

The CURECURE Heated Electric Blanket features a user-friendly digital controller for easy operation.



Image 5.1: The digital controller for the CURECURE Heated Electric Blanket, highlighting its 6 heating levels and 10-hour auto-off timer.

### 5.1 Controller Functions

- **Power Button (SET):** Press to turn the blanket ON or OFF.
- **'+' Button:** Increases the heating level.
- **'-' Button:** Decreases the heating level.

### 5.2 Adjusting Heat Levels

The blanket offers 6 heating levels, ranging from approximately 89°F to 113°F (31.6°C to 45°C).

1. Press the **SET** button to turn on the blanket. The display will show the current heat setting.
2. Use the '+' or '-' buttons to select your desired heat level (1-6).
3. The blanket will begin to heat up. Allow a few minutes for the blanket to reach the selected temperature.

## Simple Control Fast Heating



Image 5.2: The CURECURE Electric Blanket provides 6 heating levels for personalized comfort, with temperatures ranging from 89°F to 113°F.

### 5.3 Automatic Shut-Off

For safety and energy conservation, the blanket is equipped with a 10-hour automatic shut-off timer. After 10 hours of continuous operation, the blanket will automatically turn off. To resume heating, simply press the **SET** button to turn it back on.

## 6. MAINTENANCE AND CLEANING

Proper care ensures the longevity and performance of your electric blanket. Always follow these instructions carefully.

### 6.1 Before Cleaning

- Always unplug the power cord from the wall outlet.
- Disconnect the controller from the blanket by gently pulling the connector. Do not force it.
- Ensure the controller and power cord do not get wet.

### 6.2 Machine Washing

The blanket is machine washable. Follow these steps:

1. Pre-soak the blanket for 15 minutes in mild soap and lukewarm water.
2. Wash on the gentle or delicate cycle in a washing machine for 2 minutes.
3. Rinse thoroughly in fresh, cool water.
4. Spin dry in the washing machine for 5 minutes to remove excess water.



Image 6.1: The CURECURE Electric Blanket is machine washable after detaching the controller.

### 6.3 Drying

- **Tumble Dry:** Tumble dry on a low heat setting for approximately 5-10 minutes. Remove while still damp.
- **Line Dry:** Drape the blanket over a clothesline or shower rod. Do not use clothespins on the heating wires.
- Ensure the blanket is completely dry before reconnecting the controller and plugging it in.
- Do not iron the blanket.

## 7. TROUBLESHOOTING

If you encounter any issues with your CURECURE Heated Electric Blanket, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blanket not heating.	Not plugged in; controller not connected; power outage; auto-off activated.	Ensure power cord is securely plugged into outlet and controller is firmly connected to blanket. Check household circuit breaker. Press SET button to reactivate after auto-off.
Blanket heating unevenly.	Blanket is folded or bunched.	Lay the blanket flat and smooth out any folds or bunches. Ensure no heavy objects are on top.
Controller display is off or flashing.	Loose connection; internal error.	Unplug the blanket from the wall, disconnect the controller, wait 5 minutes, then reconnect everything securely. Plug back into the wall. If the issue persists, contact customer support.
Blanket feels too hot or not warm enough.	Heat level setting.	Adjust the heat level using the '+' or '-' buttons on the controller to your desired comfort.

If the problem persists after attempting these solutions, please contact CURECURE customer support.

## 8. SPECIFICATIONS

- **Brand:** CURECURE
- **Model:** HLB-TF
- **Size:** 62" x 84" (Twin)
- **Material:** Flannel
- **Color:** Blue
- **Heating Levels:** 6 (Approx. 89°F - 113°F / 31.6°C - 45°C)
- **Auto-Off Timer:** 10 Hours
- **Power Input:** 120V AC (Standard US Outlet)
- **Care Instructions:** Machine Washable (Controller Detachable)
- **Certifications:** FCC, ETL
- **UPC:** 650380559065

## 9. WARRANTY AND SUPPORT

For information regarding warranty coverage, product registration, or technical support, please refer to the warranty card included with your purchase or visit the official CURECURE website. You may also contact CURECURE customer service directly for assistance.

**Manufacturer:** CURECURE

**Note on Videos:** No official product videos from the seller were available for embedding in this manual.

