

[Manuals.plus](#) /

› [Midea](#) /

› Midea 6 Kg Fully Automatic Front Load Washing Machine MF100W60/T-IN User Manual

Midea MF100W60/T-IN

Midea 6 Kg Fully Automatic Front Load Washing Machine MF100W60/T-IN User Manual

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Midea 6 Kg Fully Automatic Front Load Washing Machine, model MF100W60/T-IN. Please read these instructions carefully before installation and use, and retain them for future reference. This appliance is designed for household use only.

IMPORTANT SAFETY INFORMATION

To reduce the risk of fire, electric shock, or injury when using your appliance, follow basic precautions, including the following:

- Ensure the appliance is properly grounded.
- Do not operate any appliance with a damaged cord or plug.
- Keep flammable materials away from the appliance.
- Supervise children when the appliance is in use.
- Do not wash articles that have been previously cleaned in, washed in, soaked in, or spotted with gasoline, dry-cleaning solvents, or other flammable or explosive substances.

SETUP AND INSTALLATION

Unpacking

Carefully remove all packaging materials. The package includes: 1 Washing Machine, 1 Inlet Pipe, 1 Rat Protection Cover, 1 Screw, 4 Transport Bolt Covers, and 1 Instruction Manual. Ensure all transport bolts are removed from the rear of the machine before operation. Failure to do so may cause severe vibration and damage.

Placement

Place the washing machine on a firm, level surface. Adjust the leveling feet to ensure stability. The appliance dimensions are 59.5 cm (Width) x 44 cm (Depth) x 85 cm (Height).



Steam care



Child Lock



Color Protection



Drum Clean



Anti Tangle

Image: Front view of the Midea washing machine with dimensions indicated: 85 cm height, 44 cm depth, and 59.5 cm width.

Water and Power Connection

Connect the inlet pipe to a cold water tap. Ensure the drain hose is properly installed to prevent leaks. Plug the power cord into a grounded 230 Volts AC outlet. The appliance operates at 2050 Watts.

OPERATING INSTRUCTIONS

Control Panel Overview

The washing machine features a Lunar Dial with a Digital Display for program selection and status indication. Programs are selected via the push-button controls.



15 Wash Programs



**Health Guard
Wash technology**



Digital Display



Image: Close-up of the Midea washing machine's control panel, featuring a central Lunar Dial with a digital display and surrounding push-button controls for various wash settings.

Loading Laundry

Open the front load door and place laundry loosely into the stainless steel drum. Do not overload the machine; the maximum capacity is 6 Kilograms.



Image: A four-panel image showing the washing machine's 6KG capacity, a close-up of the stainless steel drum, an illustration of the inbuilt water heater, and a graphic indicating a 2-year comprehensive warranty.

Detergent Dispensing

Add appropriate detergent and fabric softener to the designated compartments in the dispenser drawer.

Wash Programs and Features

Your washing machine offers 15 wash cycles and several special features to cater to different fabric types and washing needs.



Image: An overview of the Midea washing machine's features, highlighting 15 wash programs, Health Guard wash technology, and a digital display.

- **Cold Wash:** For delicate items or to save energy.
- **Quick Wash:** A rapid cycle for lightly soiled clothes, available in 15 or 45-minute options.
- **Steam Care:** Utilizes steam for enhanced cleaning and hygiene, including Allergy Care.

- **Hygiene 90°C:** A high-temperature wash for deep sanitization.
- **Extra Rinse:** Adds an additional rinse cycle for thorough detergent removal.
- **Child Lock:** Prevents accidental changes to settings during operation.
- **Delay Start:** Allows you to set a delayed start time for your wash cycle.
- **Color Protection:** Designed to maintain fabric colors.
- **Drum Clean:** A self-cleaning cycle for the washing machine drum.
- **Anti Tangle:** Reduces tangling of clothes during the wash cycle.



Image: Illustration of the Steam Care feature, showing steam at 90°C for Allergy Care.



Image: Graphic illustrating the Quick Wash feature with options for 15 or 45 minutes, next to the washing machine in operation.



Image: Graphic illustrating the Extra Rinse feature, showing a clean white shirt in bubbling water.



Image: Graphic illustrating the Cold Wash feature, showing a rack of colorful clothes with a temperature scale indicating 'COLD' at 0°C.

MAINTENANCE

Cleaning the Drum

Regularly use the 'Drum Clean' cycle to prevent odor and residue buildup in the stainless steel drum.

Exterior Cleaning

Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or solvents.

TROUBLESHOOTING

If you encounter issues with your washing machine, refer to the following common problems and solutions:

- **Machine does not start:** Check if the power cord is securely plugged in and the door is fully closed. Ensure a wash program is selected and the 'Start' button is pressed.
- **Excessive vibration:** Verify that all transport bolts have been removed and the machine is level. Adjust the leveling feet if necessary.
- **Water leakage:** Check all hose connections for tightness. Ensure the drain hose is correctly positioned.
- **Poor washing results:** Ensure you are not overloading the machine and using the correct amount and type of detergent for the selected program.

For persistent issues, please contact Midea customer support.

SPECIFICATIONS

Feature	Detail
Brand	Midea
Model	MF100W60/T-IN
Capacity	6 Kilograms
Type	Fully Automatic Front Load
Drum Material	Stainless Steel
Dimensions (LxWxH)	59.5 x 44 x 85 Centimeters
Item Weight	52 kg
Wattage	2050 Watts
Voltage	230 Volts
Number of Wash Cycles	15
Special Features	Child Lock, Delay Start, Steam Care, Quick Wash, Extra Rinse
Controls Type	Push Button
Material	ABS

WARRANTY AND SUPPORT

Warranty Information

Your Midea washing machine comes with a 2-year comprehensive warranty from the date of purchase. Please retain your purchase receipt for warranty claims.

Customer Support

For any assistance, service requests, or inquiries, please contact Midea customer support:

- **Toll-Free Number:** 18005725533
- **Email:** mideacare@midea.co.in

