

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Amoroso](#) /

› [Amoroso Single Umbrella Stroller Model 12104R Instruction Manual](#)

Amoroso 12104R

Amoroso Single Umbrella Stroller Model 12104R Instruction Manual

INTRODUCTION

This manual provides essential information for the safe and proper use, assembly, maintenance, and care of your Amoroso Single Umbrella Stroller Model 12104R. Please read all instructions carefully before use and retain this manual for future reference.

SAFETY GUIDELINES

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Always secure your child with the 3-point harness.
- Never leave your child unattended in the stroller.
- Do not overload the stroller or attach items that could cause instability.
- Ensure the stroller is fully open and locked before placing a child inside.
- Always engage the brakes when the stroller is stationary.
- Do not use the stroller on stairs or escalators.
- Maximum weight recommendation: 33 pounds (15 kg).
- This stroller is designed for infants and toddlers.

PRODUCT COMPONENTS & FEATURES

What's in the Box

- Amoroso Single Umbrella Stroller Frame
- Stroller Seat Fabric (Pre-attached)
- Round Canopy
- Sun Shade

Key Features

- Lightweight and travel-ready design.

- Durable metal frame with nylon fabric.
- EVA wheel tires and PP plastic wheel frames for smooth movement.
- 3-point safety harness for child security.
- Easy-fold system for compact storage.
- Adjustable round canopy for sun protection.
- Rear wheel brakes for stability.



Figure 1: Close-up of the 3-point safety harness.

The stroller features a secure 3-point harness to keep your child safely in place during use.




Figure 2: Rear view of the stroller, highlighting the easy-grip handles.

Ergonomic handles provide comfortable pushing, and the lightweight design ensures easy maneuverability.

SETUP INSTRUCTIONS

1. Unfolding the Stroller

1. Place the folded stroller on a flat surface with the handles facing upwards.
2. Release any locking mechanisms that keep the stroller folded (if applicable).
3. Pull the handles upwards and outwards until the frame clicks into place, indicating it is fully open.

4. Ensure all locking mechanisms are securely engaged before use.

2. Attaching the Canopy

- The round canopy is typically pre-attached. If not, align the canopy's attachment points with the corresponding slots on the stroller frame near the handles and secure them.
- Adjust the canopy to the desired position for sun protection.

3. Securing the Harness

- Place your child in the stroller seat.
- Bring the shoulder straps over your child's shoulders and the waist straps around their waist.
- Connect the buckles of the shoulder and waist straps into the central buckle until you hear a click.
- Adjust the straps to ensure a snug, secure fit without being too tight.

OPERATING THE STROLLER

1. Folding the Stroller

1. Ensure your child is removed from the stroller.
2. Disengage the canopy by pushing it back.
3. Locate the folding mechanism (usually a lever or button near the handles or on the side of the frame).
4. Follow the specific folding steps for your model, typically involving lifting a lever and pushing the handles forward and down until the stroller collapses.
5. Secure any auto-lock mechanisms to keep the stroller folded.

Video 1: Demonstration of the Amoroso Single Umbrella Stroller's folding and unfolding mechanism.

This video illustrates the simple steps to fold and unfold the stroller for convenient storage and transport.

2. Using the Brakes

- To engage the brakes, press down firmly on the brake levers located on the rear wheels with your foot.
- To release the brakes, lift the levers upwards.
- Always check that the brakes are fully engaged when the stroller is stationary.



Figure 3: Rear wheels showing the brake mechanism.

The stroller is equipped with easy-to-use rear wheel brakes for secure parking.

3. Adjusting the Canopy

- The round canopy can be adjusted forward or backward to provide optimal shade for your child.

CARE AND MAINTENANCE

Cleaning Instructions

- **Fabric:** The nylon fabric can be spot cleaned with mild soap and warm water. Do not use bleach. Air dry thoroughly.
- **Frame:** Wipe the metal frame with a soft, damp cloth. Dry completely to prevent rust.
- **Wheels:** Regularly clean the wheels to remove dirt and debris. Lubricate moving parts with a silicone-based lubricant if needed.

Storage

- Store the stroller in a clean, dry place away from direct sunlight and extreme temperatures.
- Ensure the stroller is completely dry before storing to prevent mold or mildew.
- When folded, the compact design allows for easy storage in small spaces.

TROUBLESHOOTING GUIDE

Problem	Possible Cause	Solution
Stroller does not unfold/fold easily.	Locking mechanisms engaged; debris in hinges.	Ensure all locks are disengaged. Check hinges for obstructions and clean if necessary. Apply lubricant to moving parts.
Wheels are stiff or squeaky.	Dirt/debris in wheel axles; lack of lubrication.	Clean wheels and axles. Apply silicone-based lubricant to axles.
Brakes are not engaging/disengaging properly.	Debris in brake mechanism; worn brake pads.	Clean the brake mechanism. If worn, contact customer support for replacement parts.
Harness is difficult to buckle/unbuckle.	Debris in buckle; misaligned straps.	Clean the buckle mechanism. Ensure straps are not twisted or misaligned.

TECHNICAL SPECIFICATIONS

Attribute	Detail
Model Number	12104R
Brand	Amoroso
Color	Pink
Material Type	Nylon
Frame Material	Metal
Seat Material	Nylon
Wheel Material	EVA (tire), PP Plastic (frame)
Item Weight	7.2 Pounds (3.26 kg)
Maximum Weight Recommendation	33 Pounds (15 kg)
Unfolded Dimensions (L x W x H)	22.83" x 15.75" x 35.43" (58 x 40 x 90 CM)

Attribute	Detail
Folded Dimensions (L x W x H)	13" x 11.2" x 42.1" (31.5 x 4.2 x 104.5 CM)
Harness Type	3 Point
Stroller Type	Umbrella Stroller
UPC	850031822023



Figure 4: The Amoroso Single Umbrella Stroller in its unfolded state.

The main product image showcasing the stroller's design and color.

WARRANTY INFORMATION

Amoroso products are manufactured with quality and durability in mind. This product comes with a 1-year limited warranty against manufacturing defects. Please retain your proof of purchase for warranty claims. The warranty does not cover normal wear and tear, misuse, or damage caused by accidents.

CUSTOMER SUPPORT

For any questions, concerns, or assistance with your Amoroso Single Umbrella Stroller, please contact our customer support team:

- **Online:** Visit the [Amoroso Store on Amazon](#)
- **Email:** Refer to your product packaging for direct email support.
- **Phone:** Refer to your product packaging for direct phone support.

Please have your model number (12104R) and proof of purchase ready when contacting support.