

Apple MM0Y3ZM/A

Apple Leather Wallet with MagSafe for iPhone

Model: MM0Y3ZM/A

INTRODUCTION

The Apple Leather Wallet with MagSafe is designed to securely hold your identification and credit cards while seamlessly attaching to your iPhone. Crafted from specially tanned European leather, this wallet integrates strong built-in magnets for effortless attachment and detachment. It also features Find My support, providing notifications for its last known location if separated from your iPhone.

This wallet is shielded to protect up to three credit cards and includes a convenient back slot for easy card removal.

COMPATIBILITY

The Apple Leather Wallet with MagSafe is compatible with the following iPhone models:

- iPhone 14 Pro Max, iPhone 14 Pro, iPhone 14 Plus, iPhone 14
- iPhone 13 Pro Max, iPhone 13 Pro, iPhone 13, iPhone 13 mini
- iPhone 12 Pro Max, iPhone 12 Pro, iPhone 12, iPhone 12 mini

SETUP

1. **Attaching the Wallet:** Align the Apple Leather Wallet with MagSafe to the back of your compatible iPhone. The built-in magnets will automatically snap the wallet into place. You can also attach it over a MagSafe-compatible iPhone case.
2. **Setting up Find My:** Once attached to your iPhone, the wallet will automatically pair with your device. Follow the on-screen prompts to enable Find My support for your wallet. This allows your iPhone to notify you of the wallet's last known location if it becomes separated.



Image: The Apple Leather Wallet with MagSafe securely attached to the back of an iPhone.

OPERATING INSTRUCTIONS

Inserting and Removing Cards

- **Card Capacity:** The wallet is designed to securely hold up to three credit cards or similar-sized cards.
- **Inserting Cards:** Gently slide your cards into the main compartment of the wallet. Ensure they are fully seated.
- **Removing Cards:** Use the thumb slot located on the back of the wallet to push cards out. For easier removal, especially with cards that have raised numbers, position the raised numbers to align with the thumb slot.

Using Find My Feature

When the wallet is separated from your iPhone, the Find My feature will record its last known location. You will receive a notification on your iPhone, helping you to retrace your steps to find the wallet.



Image: Detail of the wallet's leather texture and card slot.

MAINTENANCE

Cleaning

- To clean the leather wallet, gently wipe it with a soft, lint-free cloth.
- If necessary, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive materials, or excessive moisture, as these can damage the leather.
- Allow the wallet to air dry completely before reattaching it to your iPhone or inserting cards.

Care for Leather

- Leather is a natural material and may develop a patina over time, which is a natural aging process.
- Avoid prolonged exposure to direct sunlight, extreme heat, or moisture to preserve the leather's quality.
- Minor scratches or scuffs can often be buffed out gently with a soft cloth.

TROUBLESHOOTING

- **Wallet Detaches Easily:** The MagSafe connection is strong but can detach under certain conditions, such as when placing the phone in tight pockets, dropping the device, or during vigorous movement in a bag. Be mindful of how you handle your phone with the wallet attached.
- **Difficulty Removing Cards:** If cards are difficult to slide out, try positioning a card with raised numbers so that the numbers align with the thumb slot on the back. This can provide better grip for removal. The leather may also soften slightly with use, making card access easier over time.
- **Find My Location Inaccurate:** The Find My feature for the wallet provides the last known location at the time it separated from your iPhone. It does not offer real-time tracking like an AirTag or iPhone. If the wallet was detached and then moved, its reported location will still be where it last disconnected from your phone.
- **Card Interference with Magnets:** If you experience issues with a card's chip functionality, try placing that card in the front or middle slot of the wallet to minimize potential interference from the MagSafe magnets.

SPECIFICATIONS

Brand	Apple
Model Number	MM0Y3ZM/A
ASIN	B09G8TPS3V
Color	Midnight
Material	Leather
Product Dimensions	4.54 x 3.24 x 0.59 inches
Item Weight	2.57 ounces
Card Capacity	Up to 3 cards
Special Features	MagSafe compatible, Find My support, RFID shielded

Image: The Apple Leather Wallet with MagSafe shown alongside other MagSafe accessories.

WARRANTY AND SUPPORT

Return Policy

This product is eligible for a refund or replacement within 15 days of purchase, subject to the retailer's return policy.

Product Warranty

For detailed information regarding the product warranty, please refer to the official Apple website or contact Apple Support directly. Warranty terms and conditions may vary by region.

Customer Support

For further assistance, technical support, or service inquiries, please visit the official Apple Support website: support.apple.com