

## Apple MM313ZM/A

# Apple iPhone 13 Pro Max Clear Polycarbonate Case with MagSafe User Manual

Model: MM313ZM/A

## INTRODUCTION

This manual provides comprehensive instructions for the installation, usage, and care of your Apple iPhone 13 Pro Max Clear Polycarbonate Case with MagSafe. This case is designed to protect your iPhone 13 Pro Max while maintaining its aesthetic and supporting MagSafe functionality.

Key features include:

- **Thin and Lightweight Design:** Engineered to be thin, light, and easy to grip, showcasing the iPhone's original finish.
- **MagSafe Compatibility:** Features built-in magnets for perfect alignment with iPhone 13 Pro Max, enabling faster wireless charging and compatibility with MagSafe accessories.
- **Enhanced Protection:** Designed to protect your iPhone from scratches and drops through rigorous testing.
- **Precise Fit:** Specifically designed for the iPhone 13 Pro Max.

## SETUP: INSTALLING THE CASE

Follow these steps to properly install the clear case on your iPhone 13 Pro Max:

1. Ensure your iPhone 13 Pro Max is clean and free of dust or debris.
2. Hold the case with the camera cutout facing upwards.
3. Gently insert the iPhone into the case, starting with the top edge (where the camera is located).
4. Press the remaining edges of the iPhone into the case until it snaps securely into place. Ensure all corners are fully seated within the case.



*Image 1: Front view of iPhone 13 Pro Max with the clear case installed, highlighting the precise fit around the screen and buttons.*



*Image 2: Rear view close-up of the iPhone 13 Pro Max camera module, demonstrating how the clear case provides protection around the camera lenses.*

## OPERATING INSTRUCTIONS

### MagSafe Functionality

The clear case is designed with integrated magnets that align perfectly with your iPhone 13 Pro Max, enabling seamless use of MagSafe technology.

- **MagSafe Charging:** To charge your iPhone wirelessly, simply place your MagSafe charger onto the back of the case. The magnets will automatically align the charger for optimal charging efficiency.
- **Qi-Certified Charging:** The case also supports standard Qi-certified wireless chargers. Place your iPhone (with the case on) onto a compatible Qi charger.
- **MagSafe Accessories:** Attach any MagSafe-compatible accessories, such as wallets or stands, directly to the back of the case. The magnets will ensure a secure connection.

# MagSafe accessories



Image 3: Illustration of MagSafe accessories, including a MagSafe wallet, charger, and battery pack, securely attached to iPhones with clear cases.

## Button and Port Access

The case features precise cutouts for all ports, speakers, and the camera, ensuring full access and functionality. Integrated button covers provide protection while maintaining tactile feedback for volume and power buttons.

## MAINTENANCE AND CARE

To keep your clear case in optimal condition and ensure its longevity:

- **Cleaning:** Regularly wipe the case with a soft, damp, lint-free cloth. For stubborn marks, a small amount of mild soap and water can be used. Avoid harsh chemicals, abrasive cleaners, or solvents, as these can damage the case material.
- **Storage:** When not in use, store the case in a clean, dry environment away from direct sunlight or extreme temperatures.
- **Inspection:** Periodically inspect the case for any signs of wear or damage. If the case is significantly damaged, consider replacing it to ensure continued protection for your iPhone.

## TROUBLESHOOTING

If you encounter any issues with your clear case, consider the following:

- **Case Not Fitting Properly:** Ensure you have the correct case model for your iPhone 13 Pro Max. Verify that no foreign objects are obstructing the fit between the iPhone and the case.
- **MagSafe Accessories Not Attaching Securely:** Confirm that the accessory is genuinely MagSafe compatible. Ensure there is no debris or obstruction between the case and the accessory that might interfere with the magnetic connection.
- **Wireless Charging Issues:** If wireless charging is not working, ensure the MagSafe charger or Qi-certified charger is properly connected to its power source. Reposition the iPhone on the charger to ensure correct alignment.
- **Buttons Stiff or Unresponsive:** Ensure the case is fully seated on the iPhone and not misaligned. The buttons on new cases may require a few uses to soften slightly.

## SPECIFICATIONS

|                         |                          |
|-------------------------|--------------------------|
| Product Dimensions      | 7.07 x 3.8 x 0.61 inches |
| Item Weight             | 3.03 ounces              |
| Material                | Polycarbonate            |
| Compatible Phone Models | iPhone 13 Pro Max        |
| Brand                   | Apple                    |
| Model Number            | MM313ZM/A                |
| ASIN                    | B09G8YSGPR               |

## WARRANTY INFORMATION

Specific warranty details for this Apple product are typically provided with the product packaging or can be found on the official Apple website. Please refer to the documentation included with your purchase or visit [Apple's Warranty Information page](#) for the most current and detailed warranty terms and conditions.

## CUSTOMER SUPPORT

For further assistance, technical support, or service inquiries regarding your Apple iPhone 13 Pro Max Clear Polycarbonate Case with MagSafe, please contact Apple Support directly.

- **Online Support:** Visit the official Apple Support website at [support.apple.com](https://support.apple.com).
- **Contact by Phone:** Refer to the Apple Support website for local contact numbers.
- **In-Store Support:** Visit an authorized Apple Store or Apple Authorized Service Provider.