Apple MM2H3ZM/A

Apple iPhone 13 Pro Silicone Case with MagSafe - User Manual

Brand: Apple | **Model:** MM2H3ZM/A

1. INTRODUCTION AND OVERVIEW

This manual provides instructions for the proper use and care of your Apple iPhone 13 Pro Silicone Case with MagSafe. Designed specifically for the iPhone 13 Pro, this case offers protection and enhances functionality with its integrated MagSafe technology. The silky, soft-touch silicone exterior provides a comfortable grip, while a soft microfiber lining on the interior offers additional protection against scratches.
The case is engineered to protect your iPhone 13 Pro from daily wear, scratches, and drops, undergoing extensive testing to ensure durability and a precise fit.

2. WHAT'S IN THE BOX

- One (1) Apple iPhone 13 Pro Silicone Case with MagSafe - Chalk Pink

3. SETUP AND INSTALLATION

To install the silicone case on your iPhone 13 Pro, follow these steps:

1. Ensure your iPhone 13 Pro is clean and free of dust or debris.

2. Align the top edge of your iPhone with the top opening of the case.

3. Gently push the iPhone into the case, ensuring all corners and edges are securely seated within the case's protective frame. The case is designed for a snug fit.

4. Verify that all buttons (volume, side button) and ports (charging port, speakers) are accessible and functional through the case's cutouts.

Figure 3.1: Front view of the iPhone 13 Pro securely fitted within the Chalk Pink Silicone Case, showing the display and side buttons.

Figure 3.2: Rear view of the iPhone 13 Pro in the Chalk Pink Silicone Case, illustrating the precise cutout and protection for the camera system.

4. OPERATING INSTRUCTIONS

4.1 MagSafe Functionality

The Apple iPhone 13 Pro Silicone Case features built-in magnets that align perfectly with your iPhone 13 Pro. This enables a secure attachment for MagSafe accessories and facilitates faster wireless charging.

- **Attaching MagSafe Accessories:** Simply bring a compatible MagSafe accessory (e.g., MagSafe Charger, MagSafe Wallet) close to the back of your cased iPhone. The magnets will automatically align and secure the accessory in place.
- **Wireless Charging:** For wireless charging, leave the case on your iPhone and snap on a MagSafe charger. The case also supports charging with Qi-certified wireless chargers.

MagSafe accessories

Figure 4.1: Illustration of various MagSafe accessories, including a MagSafe Charger and MagSafe Wallet, demonstrating compatibility with iPhone cases.

5. MAINTENANCE AND CARE

To maintain the appearance and integrity of your silicone case, follow these care guidelines:

- **Cleaning:** Wipe the exterior of the case with a soft, damp, lint-free cloth. Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the silicone material.
- **Protection:** While the case is designed to protect against scratches and drops, avoid exposing it to extreme temperatures, direct sunlight for prolonged periods, or sharp objects that could puncture or tear the silicone.
- **Interior Lining:** Periodically remove your iPhone from the case and gently wipe the interior microfiber lining to remove any accumulated dust or debris that could potentially scratch your device.

6. TROUBLESHOOTING

If you encounter any issues with your Apple iPhone 13 Pro Silicone Case, consider the following:

- **Case Not Fitting Correctly:** Ensure you have the correct case model for your iPhone 13 Pro. The case is specifically designed for the iPhone 13 Pro and may not fit other iPhone models.
- **MagSafe Accessories Not Attaching:** Verify that the MagSafe accessory is compatible and that there are no

obstructions between the accessory and the case. Ensure the accessory is properly aligned with the magnetic ring on the case.

- **Wireless Charging Issues:** Confirm that your MagSafe or Qi-certified charger is functioning correctly and is properly aligned with the center of the back of the cased iPhone. Remove any foreign objects between the phone and the charger.

7. SPECIFICATIONS

Product Name	Apple iPhone 13 Pro Silicone Case with MagSafe
Model Number	MM2H3ZM/A
Brand	Apple
Compatible Phone Models	iPhone 13 Pro
Material	Silicone
Color	Chalk Pink
Product Dimensions	6.49 x 3.53 x 0.71 inches
Item Weight	2.92 ounces
Manufacturer	Apple

8. WARRANTY AND SUPPORT

This Apple product is covered by Apple's standard warranty. For detailed warranty information, please refer to the documentation included with your iPhone or visit the official Apple Support website. For technical assistance or support, please contact Apple Support directly.
Apple Support Website: support.apple.com