

Rulefiss i30

Rulefiss Wireless Earbuds i30 User Manual

Model: i30

1. INTRODUCTION

Thank you for choosing the Rulefiss Wireless Earbuds i30. These earbuds are designed to provide a high-quality audio experience with features tailored for active lifestyles, including secure earhooks, IP7 waterproofing, and intuitive touch controls. This manual will guide you through the setup, operation, and maintenance of your new earbuds to ensure optimal performance and longevity.

2. PACKAGE CONTENTS

- Rulefiss Wireless Earbuds (L/R)
- Charging Case
- USB-C Charging Cable
- Ear Tips (S/M/L)
- User Manual

3. PRODUCT OVERVIEW

The Rulefiss i30 earbuds feature an ergonomic earhook design for a secure fit during physical activity, along with a compact charging case that provides extended battery life.



Image: The Rulefiss Wireless Earbuds i30, showcasing both earbuds with their earhooks and the open charging case. The earbuds feature green LED indicators, and the case has battery indicator lights.

4. KEY FEATURES

- **Superior Hi-Fi Stereo Sound Quality:** Experience rich bass, clear tenor, and ethereal treble with CVC 8.0 noise cancellation for balanced and natural sound. The built-in microphone ensures clear call quality without interruptions.

SUPERIOR HI-FI STEREO & DEEP BASS



Image: An exploded diagram illustrating the internal components of the earbud, highlighting the speaker and sound-producing elements to demonstrate Hi-Fi stereo and deep bass capabilities.

- **Comfortable Earhook Design For Sports:** Adjustable and secure-fit silicone earhooks ensure the earbuds remain firmly in place during sports, running, and other activities. Includes three pairs of spare ear caps (L/M/S) for a customized, comfortable fit during extended wear.
- **One Step Pairing and Wide Compatibility:** Earbuds automatically pair with your smart device after the initial connection when removed from the charging case. Compatible with smartphones running iOS 9.0/Android 5.0 or above, and all Bluetooth 4.0 or above devices, including mobile phones, tablets, PCs, and laptops.
- **Bluetooth 5.1 and Smart Touch Control:** Equipped with the latest Bluetooth 5.1 chip for a clearer, faster, and smoother connection. High-sensitivity touch sensors allow for easy control of calls (answer/hang up), music playback (play/pause, adjust volume, switch songs), and voice assistant activation (Siri).



Image: A man wearing the Rulefiss i30 earbud, with overlaid icons illustrating various smart touch control functions such as modulation, switching songs, answering calls, and activating Siri.

- **40H Playtime and IP7 Waterproof:** Enjoy 6-8 hours of playtime on a single charge, extended to 40 hours with the 400mAh compact Type-C charging case. Constructed with an IP7 waterproof standard, these sport headphones are resistant to sweat and rain, making them suitable for gym, running, and daily exercise.



Image: The Rulefiss Wireless Earbuds i30 in their charging case, with text indicating '8H Earbud Playtime', '32H With Charging Case', and '1H Earbud Charging Time', emphasizing the extended battery life.

IP7 WATERPROOF AND SWEATPROOF



Image: Two Rulefiss Wireless Earbuds i30, covered in water droplets, illustrating their IP7 waterproof and sweatproof capabilities against a dark background.

5. SETUP GUIDE

5.1 Initial Charging

1. Before first use, ensure to remove the protective plastic film from the charging contacts on both earbuds.
2. Place both earbuds into the charging case.
3. Connect the USB-C charging cable to the charging port on the case and plug the other end into a USB power adapter (not included).
4. The indicator lights on the charging case will illuminate to show charging status. Allow the earbuds and case to fully charge before first use.

5.2 Pairing with Your Device

1. Ensure Bluetooth is enabled on your smartphone or other device.
2. Open the charging case and take out both earbuds. They will automatically power on and enter pairing mode.
3. On your device, search for Bluetooth devices and select "Rulefiss i30" from the list.

- Once connected, you will hear a confirmation prompt, and the earbud indicator lights will turn off or flash slowly.
- For subsequent uses, the earbuds will automatically connect to the last paired device when removed from the case.

6. OPERATING INSTRUCTIONS

6.1 Wearing the Earbuds

Identify the left (L) and right (R) earbuds. Gently insert each earbud into your ear canal and rotate it slightly to ensure the earhook sits comfortably and securely over your ear. Adjust the earhook for a snug fit.

6.2 Touch Control Functions

The Rulefiss i30 earbuds feature sensitive touch controls on the outer surface of each earbud.

Function	Action
Play/Pause Music	Single tap on either earbud
Volume Up	Tap and hold right earbud
Volume Down	Tap and hold left earbud
Next Song	Double tap right earbud
Previous Song	Double tap left earbud
Answer/End Call	Single tap on either earbud
Reject Call	Tap and hold on either earbud
Activate Voice Assistant (Siri/Google Assistant)	Triple tap on either earbud

7. MAINTENANCE AND CARE

7.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Clean the charging contacts on both the earbuds and the case to ensure proper charging.

7.2 Water Resistance (IP7)

The Rulefiss i30 earbuds are IP7 waterproof, meaning they can withstand immersion in water up to 1 meter for 30 minutes. They are resistant to sweat and rain. However, they are not designed for swimming or prolonged submersion. Ensure earbuds are dry before placing them back into the charging case to prevent damage.

7.3 Storage

When not in use, store the earbuds in their charging case to protect them from dust and physical damage. Store in a cool, dry place away from extreme temperatures.

8. TROUBLESHOOTING

Problem	Possible Solution
Earbuds not pairing with device	<p>Ensure earbuds are charged.</p> <p>Turn off and on Bluetooth on your device.</p> <p>Forget "Rulefiss i30" from your device's Bluetooth list and re-pair.</p> <p>Place earbuds back in case, close, then reopen and try again.</p>
Only one earbud working	<p>Ensure both earbuds are charged.</p> <p>Place both earbuds back in the charging case, close the lid for 5 seconds, then open and take them out simultaneously.</p> <p>If issues persist, reset the earbuds (refer to manufacturer's website for specific reset instructions if not in manual).</p>
Earbuds not charging	<p>Ensure protective plastic film is removed from earbud charging contacts.</p> <p>Clean the charging contacts on both earbuds and the case.</p> <p>Try a different USB-C cable and power adapter.</p>
Low volume or poor sound quality	<p>Adjust volume on both the earbuds and your connected device.</p> <p>Ensure ear tips are the correct size for a good seal.</p> <p>Clean any debris from the earbud speaker mesh.</p> <p>Ensure no obstructions between earbuds and device.</p>

9. SPECIFICATIONS

Feature	Detail
Model	i30
Bluetooth Version	5.1
Wireless Range	Standard Bluetooth range (typically up to 10 meters/33 feet)
Playtime (Earbuds)	6-8 hours (single charge)
Total Playtime (with Charging Case)	Up to 40 hours
Charging Case Battery Capacity	400mAh
Charging Port	Type-C
Water Resistance Rating	IP7
Microphone	Built-In
Noise Control	CVC 8.0 Noise Cancellation
Control Method	Touch
Material	Plastic
Item Weight	62 Grams

Feature	Detail
Product Dimensions	8.38 x 5.75 x 3.25 cm

10. WARRANTY AND SUPPORT

Rulefiss products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or customer service, please refer to the contact details provided on the product packaging or visit the official Rulefiss website. Please retain your proof of purchase for warranty claims.