

MIZZEO FGREY02

MIZZEO FGREY02 Electric Throw Blanket User Manual

Model: FGREY02

1. INTRODUCTION

Thank you for choosing the MIZZEO FGREY02 Electric Throw Blanket. This luxurious double-layer flannel blanket is designed to provide ultimate comfort and warmth. Made of 100% polyester velvet, it gently wraps you in warmth during cold nights. This manual provides essential information for safe and effective use of your electric throw blanket.

2. SAFETY INFORMATION

Please read all safety instructions carefully before using your electric throw blanket. Failure to follow these instructions may result in fire, electric shock, or injury.

- **Do not use with infants, children, incapacitated persons, or anyone insensitive to heat.**
- **Do not use if wet.**
- **Do not use with damaged cords or plugs.** If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard.
- **Do not use with pets.**
- **Do not fold, bunch, or crease the blanket while in use.** This can cause overheating.
- **Do not insert pins or other metallic objects into the blanket.**
- **Always disconnect the power cord from the wall outlet and the blanket connector before cleaning.**
- This product is ETL certified and features a built-in overheat protection system to avoid overheating and ensure safer use.

3. SETUP

1. **Unpack the Blanket:** Carefully remove the electric throw blanket and its controller from the packaging.
2. **Inspect for Damage:** Before first use, inspect the blanket and controller for any signs of damage. Do not use if damaged.
3. **Connect the Controller:** Locate the connector on the blanket. Align the controller's plug with the blanket's connector and push firmly until it clicks into place. Ensure a secure connection.



Image: Detachable controller connector for easy washing.

4. **Plug into Power Outlet:** Plug the power cord into a standard 120V AC electrical wall outlet. Ensure the cord is not pinched or covered by the blanket.

4. OPERATING INSTRUCTIONS

Your MIZZEEO electric throw blanket features an easy-to-use single controller with 4 heating levels and a selectable timer.

4 HEATING LEVELS

To Meet Your Perfect Warmth

82°F



125°F

Auto-Off Setting



Image: MIZZEEO Electric Blanket Controller with display.

1. **Power On/Off:** Press the power button (**U**) to turn the blanket on or off. The display will illuminate when powered on.
2. **Adjust Heat Level:** Use the '+' and '-' buttons to cycle through the 4 available heating levels. Start with a lower setting and increase as desired for your comfort.
3. **Set Timer:** Press the timer button (clock icon) to select the desired auto-off duration. You can choose from 1 to 12 hours. The blanket will automatically shut off after the selected time for safety and energy saving. The default auto-off is 4 hours if no specific time is set.
4. **Enjoy Warmth:** Once your desired settings are selected, relax and enjoy the consistent warmth provided by your MIZZEEO electric throw blanket.

5. MAINTENANCE

Proper care ensures the longevity and performance of your electric throw blanket. Always follow these instructions carefully.

- 1. Disconnect Power:** Before cleaning, always ensure the power cord is disconnected from the wall outlet and the controller is detached from the blanket.
- 2. Machine Washable:** The MIZZEEO heated throw blanket is machine washable. Use a gentle cycle with cold water. Do not bleach.
- 3. Drying:** Tumble dry on low heat or air dry. Do not iron. Ensure the blanket is completely dry before reconnecting the controller and using it again.
- 4. Storage:** When not in use, store the blanket in a cool, dry place. Avoid folding it tightly or placing heavy objects on it, which could damage the internal heating elements.

6. TROUBLESHOOTING

If you encounter any issues with your electric throw blanket, please refer to the following common solutions:

- Blanket Not Heating:**
 - Ensure the power cord is securely plugged into both the wall outlet and the blanket connector.
 - Check if the wall outlet is functional by plugging in another appliance.
 - Verify the controller is powered on and a heat level is selected.
- Controller Flashing Blue Light:**
 - If the controller flashes a blue light, it may indicate an improper connection or a temporary error. Disconnect the power cord from the wall outlet, then detach and reattach the controller to the blanket. Plug the power cord back into the wall outlet.
- Uneven Heating:**
 - Ensure the blanket is spread out flat and not folded or bunched during use.
 - Allow sufficient time for the blanket to reach its set temperature, as heating elements distribute warmth gradually.

If the problem persists after trying these steps, please contact MIZZEEO customer support.

7. SPECIFICATIONS

Feature	Detail
---------	--------

Brand	MIZZEO
Model Name	FGREY02
Material	Flannel (100% Polyester Velvet)
Color	Gray
Size	50 x 60 inches
Heating Levels	4
Auto-Off Timer	1-12 hours (default 4 hours)
Special Feature	Washable, Overheat Protection, ETL Certified
Item Weight	3.32 pounds
UPC	631851857040



Double Layer Flannel

Ultra-soft texture for extra warmth



Japanese Resistance Wire

Fast heating to wrap your all body in warmth
10 Hours Auto off for overheat protection

WARM & SAFE

Image: Construction details highlighting safety and material.

8. WARRANTY AND SUPPORT

MIZZEO stands behind the quality of its products. For warranty information, please refer to the documentation included with your purchase or visit the official MIZZEEEO website. If you have any questions, concerns, or require technical assistance, please contact MIZZEEEO customer support through the contact information provided on our website or product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question