

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Asani](#) /

› [Asani 5-in-1 Electric Razor User Manual](#)

## Asani B09GKPPFJ9

# Asani 5-in-1 Electric Razor User Manual

Model: B09GKPPFJ9



## INTRODUCTION

The Asani 5-in-1 Electric Razor is a versatile grooming tool designed for both men and women, offering multiple functions for various hair removal and facial care needs. This device combines a rotary shaver, nose hair trimmer, hair clipper, silicone brush, and facial cleansing brush into one compact, rechargeable, and waterproof unit. This manual provides detailed instructions for safe operation, effective use, and proper maintenance of your Asani Electric Razor.

## SAFETY INFORMATION

**Warning: This electric shaver is waterproof but not submersible. Use caution to avoid cuts from sharp blades. Do not submerge the shaver in water for extended periods. Rinse under the skin and leave to dry after use.**

- Keep the device out of reach of children.
- Do not disassemble or attempt to repair the device yourself. Contact customer support for assistance.
- Ensure the charging port is dry before connecting the charging cable.
- Avoid using the shaver on irritated, damaged, or infected skin.
- Store the device in a cool, dry place when not in use.

## PACKAGE CONTENTS

Please check the package to ensure all components are present:

- Asani Electric Razor Main Body
- Rotary Shaver Head (5D)
- Nose Hair Trimmer Head
- Hair Clipper Head

- 3 Guide Combs (for Hair Clipper)
- Silicone Facial Massager Brush Head
- Facial Cleansing Brush Head
- USB Charging Cable
- Cleaning Brush
- Protective Cap (for shaver head)



Image: The Asani 5-in-1 Electric Razor main unit displayed with all its interchangeable heads and guide combs.

## PRODUCT FEATURES

The Asani 5-in-1 Electric Razor is engineered for performance and convenience:

- **5-in-1 Versatility:** This single device replaces multiple grooming tools, offering a rotary shaver, nose hair trimmer, hair clipper with three guide combs, a silicone brush, and a facial cleansing brush.
- **5D Pivoting Rotary Shaver:** The shaver head features five flexible rotary blades that adapt to the contours of your face, neck, or legs, ensuring a close and comfortable shave.

- **Wet & Dry Shaving:** Rated IPX5 water-resistant, the shaver can be used with or without shaving cream, and is safe for use in the shower. It is also fully washable for easy cleaning.
- **Cordless Design & Long Battery Life:** Enjoy up to 90 minutes of wireless operation on a full charge. The device features an LED display to monitor battery percentage.
- **Fast Charging:** A full charge takes approximately 2 hours via USB, allowing convenient charging from various sources like laptops, power banks, or AC adapters.
- **Durable German-Imported Blades:** Constructed with high-quality blades for long-lasting sharpness and reliability.

## SLEEK DESIGN SUPERIOR PERFORMANCE



Image: Diagram highlighting key features: Cordless Design, Super Fast Charging, 5 in 1 Grooming Kit, IPX5 Waterproof, Safety Lock & Clean Indicators, Digital Display Timer.

# ONE RAZOR, ENDLESS POSSIBILITIES

## Electric Shaver



## Silicone Facial Massager



## Hair Clipper Head with 3 Different Length Guide Combs



## Facial Cleaning Brush



## Nose Hair Trimmer



Image: Visual representation of the electric shaver, silicone facial massager, hair clipper, facial cleaning brush, and nose hair trimmer attachments.

## SETUP

### Initial Charging

1. Before first use, fully charge the shaver.
2. Connect the USB charging cable to the shaver's charging port.
3. Plug the other end of the USB cable into a compatible USB power source (e.g., laptop, power bank, or AC adapter).
4. The LED display will show the charging progress. A full charge typically takes 2 hours and provides up to 90 minutes of use.

# ***SUPER FAST CHARGING LONG BATTERY LIFE***

**120  
mins**

Fully Charge  
From Empty

**600  
mAh**

Battery  
Capacity

**90  
mins**

Use with Full  
Charge



Charges  
via MicroUSB



Image: Illustrates the charging process and battery life: 120 mins for full charge, 600 mAh battery capacity, 90 mins use from full charge, and charging via MicroUSB.

## **Attaching and Detaching Heads**

1. To attach a head, align the head with the main body and gently push until it clicks into place.
2. To detach a head, firmly grasp the head and pull it away from the main body. Some heads may require a slight twist.

# SIMPLIFY YOUR ROUTINE AMPLIFY YOUR STYLE



Image: Diagram pointing out the 5D Pivoting Dual-Rotary Shavers, Power Button, Digital Display Timer, and Safety, Lock and Clean Indicators on the shaver.

## OPERATING INSTRUCTIONS

### General Operation

- Press the power button to turn the shaver on or off.
- The LED display will show the remaining battery percentage and other indicators.

### Using the Rotary Shaver Head

- Attach the 5D rotary shaver head to the main unit.
- For dry shaving, ensure your skin is clean and dry. For wet shaving, apply shaving cream or gel.
- Gently press the shaver against your skin and move it in small, circular motions.
- The flexible heads will contour to your face or body for an efficient shave.

# 5 DIRECTION FLOATING SHAVING HEAD




Image: Demonstrates the effectiveness of the 5-direction floating shaving head with a 'Before Haircut' and 'After Haircut' comparison showing a bald head.

## Using the Nose Hair Trimmer Head

- Attach the nose hair trimmer head.
- Gently insert the trimmer tip into your nostril or ear canal.
- Move the trimmer slowly to remove unwanted hair. Do not insert too deeply.

## Using the Hair Clipper Head with Guide Combs

- Attach the hair clipper head.
- Select one of the three guide combs (5mm, 7mm, or other available sizes) and attach it to the clipper head for desired hair length.
- Turn on the clipper and move it against the direction of hair growth for trimming beards, sideburns, or other body hair.

## Using the Silicone Facial Massager Brush Head

- Attach the silicone brush head.

- Apply your favorite facial cleanser to your face or directly onto the brush head.
- Gently move the brush in circular motions across your face for a relaxing massage and to help improve circulation.

## Using the Facial Cleansing Brush Head

- Attach the facial cleansing brush head.
- Wet your face and apply a small amount of facial cleanser to the brush head.
- Gently move the brush in circular motions over your face to deep clean pores and exfoliate the skin.

## MAINTENANCE AND CLEANING

---

Regular cleaning ensures optimal performance and extends the lifespan of your shaver.

1. **After Each Use:** Turn off the shaver and detach the head.
2. **Cleaning Shaver Head:** Open the four outer rotary heads by gently prying them open. Twist the center head counter-clockwise to remove it. Rinse all parts of the shaver head under running water.
3. **Cleaning Other Heads:** Rinse the nose hair trimmer, hair clipper, silicone brush, and facial cleansing brush heads under running water.
4. **Drying:** Shake off excess water and allow all components to air dry completely before reassembling or storing. Do not use cloths or abrasive materials that could damage the blades.
5. **Main Body:** Wipe the main body with a damp cloth. Do not submerge the main body in water.
6. **Lubrication (Optional):** For the rotary shaver and hair clipper blades, a drop of light machine oil (not included) can be applied periodically to maintain smooth operation.

# IPX5 WATERPROOF AND EASY TO CLEAN

**Step 1**



Open the 4 Outer Heads.

**Step 3**



The shaver is now ready to wash.

**Step 2**



Twist the center head counter-clockwise to remove.



Image: Step-by-step guide on how to open the shaver heads for cleaning and rinsing them under water.

## TROUBLESHOOTING

If you encounter any issues with your Asani Electric Razor, please refer to the following common problems and solutions:

- **Shaver not turning on:**

- Check if the battery is charged. Recharge the device if the battery is low.
- Ensure the power button is pressed firmly.

- **Poor shaving performance / pulling hair:**

- The blades may be dull or clogged. Clean the shaver head thoroughly.
- Ensure the shaver is fully charged for optimal power.
- Apply light pressure and move in circular motions.

- **Battery not charging:**

- Verify the USB cable is properly connected to both the shaver and the power source.
- Try a different USB port or power adapter.
- Ensure the charging port on the shaver is clean and dry.

- Excessive noise or vibration:**

- Clean the shaver head thoroughly, as trapped hair can cause noise.
- Ensure the shaver head is correctly attached and securely locked in place.

If the problem persists after trying these solutions, please contact Asani customer support.

## SPECIFICATIONS

Feature	Detail
Product Dimensions	2 x 4 x 3 inches
Weight	7 ounces
Power Source	Battery Powered (Rechargeable Lithium-ion)
Charging Time	Approx. 2 hours
Operating Time	Up to 90 minutes (on full charge)
Water Resistance Rating	IPX5
Blade Material	German-imported blades
Included Components	Hair Clipper, Nose Trimmer, Combs, Facial Cleansing Brush, Charging Cable
Model Number (ASIN)	B09GKPPFJ9
UPC / GTIN	610395675327

## WARRANTY AND SUPPORT

Asani stands behind the quality of its products. The Asani 5-in-1 Electric Razor comes with **lifetime warranty**, ensuring your satisfaction and peace of mind.

For any questions, concerns, or support needs, please refer to the contact information provided with your purchase or visit the official Asani website. Please have your model number (B09GKPPFJ9) ready when contacting support.