

[Manuals.plus](#) /

› [Unicoff](#) /

› Unicoff Milk Frother (Model EP-460A) Instruction Manual

Unicoff EP-460A

Unicoff Milk Frother (Model EP-460A) Instruction Manual

Brand: Unicoff

Model: EP-460A

1. PRODUCT OVERVIEW

The Unicoff Milk Frother is a handheld electric whisk designed to create rich, creamy foam for various beverages. Its modern and minimalist design, combined with powerful performance, makes it a versatile tool for your kitchen. This device is ideal for enhancing coffees, teas, hot chocolates, and for mixing powdered supplements.

Key Features:

- **Modern & Minimalist Design:** Ergonomic shape with a sleek stand for convenient storage.
- **Ultra-Simple & Fast System:** High-speed rotation (19000 RPM) for quick frothing.
- **Easy Handling:** Lightweight design with a simple push-button operation.
- **Rich & Creamy Foam:** Whips up cold milk in 20-30 seconds.
- **Versatile Use:** Suitable for cappuccinos, lattes, macchiatos, milkshakes, and mixing powders.
- **Durable Construction:** Made with high-quality stainless steel.

2. SETUP

2.1 Unpacking and Components

Carefully remove all components from the packaging. Ensure you have the following:

- Unicoff Milk Frother unit
- Stainless Steel Stand
- User Manual (this document)



Figure 2.1: Unicoff Milk Frother with its stand and packaging.

2.2 Battery Installation

The Unicoff Milk Frother requires 2 x AA batteries (not included). To install the batteries:

1. Gently twist and pull the top cap of the frother to open the battery compartment.
2. Insert two AA batteries, ensuring correct polarity (+/-).
3. Replace the top cap, twisting it until it is securely closed.



Figure 2.2: The frother unit with its whisk and top button.

2.3 Assembling the Stand

The stainless steel stand is designed for easy storage and display. Simply place the frother unit into the designated holders on the stand when not in use.

3. OPERATING INSTRUCTIONS

3.1 Frothing Milk for Beverages

Achieve perfect frothed milk for your coffee or other drinks in four simple steps:

1. **Heat the Milk:** Warm your milk until it is warm but not boiling hot.
2. **Prepare the Frother:** Take the whisk from its stand.
3. **Insert the Whisk:** Insert the whisk diagonally into the milk at a 45-degree angle.
4. **Activate Frothing:** Push the button on the top of the frother once and let it run for 20-30 seconds until desired foam consistency is achieved.



Figure 3.1: Step-by-step guide to frothing milk for a cappuccino.

The frother's powerful 19000 RPM motor ensures quick and efficient frothing.



Figure 3.2: The Unicoff Milk Frother in action, creating creamy foam.

3.2 Mixing Powders and Supplements

The frother is also effective for mixing various powdered ingredients into liquids, such as protein

powders, collagen, or green supplements. Simply immerse the whisk into your beverage with the powder and activate the frother until thoroughly mixed.



Figure 3.3: Examples of beverages and powders suitable for mixing with the frother.

4. MAINTENANCE

4.1 Cleaning the Frother

To ensure longevity and hygiene, clean the frother after each use:

1. Remove the whisk from the frother unit.
2. Rinse the stainless steel whisk under warm running water.
3. For thorough cleaning, you can briefly activate the whisk in a glass of warm, soapy water, then rinse.
4. Wipe the main frother unit with a damp cloth. Do not submerge the main unit in water.
5. Dry all parts completely before storing.

Note: The whisk is detachable for easy cleaning. The frother unit itself is **Hand Wash Only** and should not be placed in a dishwasher.



Figure 4.1: Cleaning the whisk under running water.

5. TROUBLESHOOTING

5.1 Frother Not Turning On

- Check if the batteries are correctly installed with the proper polarity.
- Replace the batteries with fresh AA batteries.
- Ensure the top cap is securely closed after battery installation.

5.2 Ineffective Frothing/Mixing

- Ensure the whisk attachment is firmly connected to the frother unit.
- Verify that the batteries have sufficient power.
- For milk frothing, ensure the milk is warm (not boiling) and that the whisk is immersed at a 45-degree angle.

6. SPECIFICATIONS

Feature	Specification
Brand	Unicoff
Model Name	Handheld Milk Frother
Item Model Number	EP-460A
Color	White and Gold
Material	Stainless Steel
Product Dimensions	2.83"W x 9.06"H
Item Weight	5.6 ounces (0.16 Kilograms)
Power Source	Battery Powered (2 x AA batteries, not included)
Wattage	30 watts
Number of Settings	1
Special Feature	Lightweight
Product Care Instructions	Hand Wash Only

7. WARRANTY AND SUPPORT

7.1 Product Assurance

The Unicoff Milk Frother comes with a 30-day assurance. If you encounter any issues within this period, please contact customer support for assistance.

7.2 Customer Support

For further assistance, questions, or to report any issues, please contact Unicoff customer support through the retailer's platform or visit the official Unicoff website.

8. PRODUCT VIDEOS

Unicoff Milk Frother: Add Elegance & Functionality

Your browser does not support the video tag.

This video showcases the Unicoff Milk Frother's design and functionality, demonstrating how it can add elegance and utility to any kitchen. It highlights the frother's ease of use for creating various coffee drinks.

