

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Frigidaire](#) /

› [Frigidaire PureAir AF-2 Refrigerator Air Filter Instruction Manual](#)

## Frigidaire AF-2 (FRGPAAF2)

# Frigidaire PureAir AF-2 Refrigerator Air Filter Instruction Manual

**Brand:** Frigidaire | **Model:** AF-2 (FRGPAAF2)

## INTRODUCTION

---

The Frigidaire PureAir AF-2 Refrigerator Air Filter is designed to maintain fresh air within your refrigerator by effectively absorbing unwanted odors. Utilizing advanced carbon technology, this filter helps ensure a clean and odor-free environment for your food items. For optimal performance, regular replacement is recommended.

## SETUP: INSTALLATION INSTRUCTIONS

---

Installing your Frigidaire PureAir AF-2 filter is a straightforward process. Follow these steps to ensure proper installation and immediate odor absorption.

### 1. Locate the Filter Housing

The PureAir AF-2 filter is typically located in the top center of the fresh food compartment of your Frigidaire refrigerator. The exact location may vary slightly depending on your refrigerator model.



*Image: A hand demonstrates the removal of the Frigidaire PureAir AF-2 filter from its housing inside the refrigerator.*

## **2. Remove the Old Filter**

Gently pull the existing filter housing cover to detach it. Once the cover is off, remove the old filter element from its position. Dispose of the old filter responsibly.

## **3. Prepare the New Filter**

Unwrap the new Frigidaire PureAir AF-2 filter from its plastic packaging. Ensure the filter is free from any debris before installation.



*Image: The new Frigidaire PureAir AF-2 filter, ready for installation.*

#### 4. Install the New Filter

Snap the new filter element securely into the filter housing. Ensure it is seated correctly. Then, reattach the filter housing cover by pushing it firmly until it clicks into place.

#### Installation Video Guide

Your browser does not support the video tag.

*Video: Official Frigidaire guide on how to replace the PureAir AF-2 refrigerator air filter, demonstrating the steps for removal and installation.*

#### OPERATING PRINCIPLES

The Frigidaire PureAir AF-2 filter utilizes advanced carbon technology to continuously circulate and purify the air inside your refrigerator. As air passes through the filter, activated carbon particles effectively trap and neutralize

odor-causing molecules, preventing them from contaminating other food items and maintaining a consistently fresh interior environment.

## MAINTENANCE

---

To ensure optimal performance and continuous odor elimination, it is recommended to replace your Frigidaire PureAir AF-2 air filter every 6 months, or as indicated by your refrigerator's filter status indicator. Regular replacement ensures the carbon technology remains effective in trapping odors and keeping your refrigerator air fresh.

## TROUBLESHOOTING

---

If you experience persistent odors after replacing the filter, ensure the new filter is correctly installed and the housing is securely closed. If issues persist, please refer to the support section for further assistance.

## SPECIFICATIONS

---

- **Brand:** Frigidaire
- **Model Number:** FRGPAAF2 (AF-2)
- **Material:** Plastic
- **Compatible Devices:** Refrigerator
- **Air Filter Construction:** Pleated
- **Number of Items:** 1
- **Manufacturer:** Electrolux
- **UPC:** 012505469565

## WARRANTY

---

This product comes with a Limited Warranty. For specific details regarding coverage and terms, please refer to the warranty documentation included with your original appliance or visit the official Frigidaire website.

## SUPPORT

---

For further assistance, product information, or to purchase genuine replacement filters, please contact Frigidaire customer support or visit their official website:

**Website:** [www.frigidaire.com](http://www.frigidaire.com)

**Customer Service (US):** (800) 374-4432

**Customer Service (CA):** (800) 265-8352