

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VirtuFit](#) /

› [VirtuFit Football Goal Pro with Target - Instruction Manual \(Model VF06049\)](#)

VirtuFit VF06049

VirtuFit Football Goal Pro with Target - Instruction Manual

Model: VF06049

1. INTRODUCTION

Thank you for choosing the VirtuFit Football Goal Pro with Target. This manual provides essential information for the safe and correct assembly, operation, and maintenance of your new football goal. Please read these instructions carefully before use and retain them for future reference.

The VirtuFit Football Goal Pro is designed for both young and adult players, offering a stable yet lightweight structure for easy relocation. Its generous dimensions of 220 x 170 cm make it suitable for various playing environments, from your garden to a nearby field.

2. SAFETY INFORMATION

- Always supervise children during play.
- Ensure all components are securely assembled before use.
- Use the provided ground anchors to secure the goal, especially in windy conditions, to prevent tipping.
- Regularly inspect the goal for any signs of wear, damage, or loose parts. Do not use if damaged.
- Keep hands and feet clear of moving parts during assembly and disassembly.
- This product is intended for recreational use.

3. PACKAGE CONTENTS

Please check that all the following components are present in your package:

- Metal Frame Components
- Polyester Net
- Target Sheet (with holes for shooting practice)
- 4 Ground Anchors
- Assembly Instructions (this manual)



Figure 1: Overview of VirtuFit Football Goal Pro components. This image displays the disassembled metal frame, the polyester net, the black target sheet with two circular cutouts, and four ground anchors, all laid out on a grassy surface next to an assembled goal.

4. SETUP INSTRUCTIONS

Follow these steps to assemble your VirtuFit Football Goal Pro:

- 1. Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify all components listed in Section 3 are present.
- 2. Assemble the Frame:** Connect the metal frame components according to the design. The frame is designed for easy assembly. Ensure all connections are secure and stable.



Figure 2: Detail of the stable steel frame. This image shows a close-up of a corner joint of the black metal frame, highlighting the robust construction and secure connection points.

3. **Attach the Net:** Drape the polyester net over the assembled frame. Secure the net to the frame using the integrated loops or ties provided. Ensure the net is taut and covers the entire goal opening.



Figure 3: Detail of the polyester net. This image provides a close-up view of the black polyester net material, showing its mesh pattern and durability.

4. **Install the Target Sheet (Optional):** If desired, attach the target sheet to the front of the goal frame. This sheet typically has cutouts for shooting accuracy practice. Secure it firmly to prevent it from flapping during play.



Figure 4: Assembled goal with target sheet. A child is shown kicking a football towards the VirtuFit goal, which has the black target sheet with two circular holes attached to its front.

5. **Secure with Ground Anchors:** Place the goal in your desired location. Use the four provided ground anchors to firmly secure the goal to the ground. Push the anchors through the designated loops at the base of the goal frame and into the soil. This prevents the goal from moving or tipping over during use.



**LEICHT ZU
MONTIEREN**

Figure 5: Fully assembled VirtuFit Football Goal Pro. This image shows the goal set up in a grassy outdoor area, ready for use, demonstrating its ease of assembly.

5. OPERATING INSTRUCTIONS

Once assembled and secured, the VirtuFit Football Goal Pro is ready for use.

- **Standard Play:** Use the goal for regular football practice or games. The robust metal frame and durable polyester net are designed to withstand repeated impacts from footballs.
- **Target Practice:** If the target sheet is installed, use the circular cutouts to practice shooting accuracy. This feature helps improve precision and control.




Figure 6: Target practice in action. An adult male is shown kicking a football towards the VirtuFit goal with the target sheet installed, demonstrating its use for accuracy training.

- **Relocation:** Due to its lightweight design, the goal can be easily moved to different locations in your garden or field. Always lift the goal rather than dragging it to prevent damage to the frame or ground. Ensure ground anchors are removed before moving.

6. MAINTENANCE

Proper maintenance will extend the life of your VirtuFit Football Goal Pro.

- **Cleaning:** Wipe the metal frame with a damp cloth to remove dirt and debris. The polyester net can be rinsed with water if necessary. Avoid harsh chemicals that may damage the materials.
- **Inspection:** Regularly check all frame connections, the net, and the target sheet for any signs of wear, tears, or damage. Ensure ground anchors are not bent or broken.
- **Storage:** For prolonged periods of non-use or during harsh weather conditions, it is recommended to disassemble the goal and store it in a dry, protected area. This will prevent rust on metal parts and degradation of the net material.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Goal is unstable or wobbly.	Frame connections are not fully secured; ground anchors are not properly installed or are loose.	Ensure all frame parts are clicked into place and tightened. Re-insert ground anchors firmly into the soil.
Net is sagging or has holes.	Net not properly attached to the frame; wear and tear; damage from sharp objects.	Re-attach the net securely to the frame. Inspect for damage; replace net if significant tears are present.
Target sheet is loose or torn.	Improper attachment; excessive force; wear and tear.	Ensure the target sheet is securely fastened to the frame. Replace if torn beyond repair.

8. SPECIFICATIONS

Feature	Detail
Model Number	VF06049
Dimensions (L x D x H)	220 x 85 x 170 cm (86.6 x 33.5 x 66.9 inches)
Weight	10.33 kg (22.77 lbs)
Frame Material	Metal
Net Material	Polyester
Color	Black
Included Accessories	Target Sheet, 4 Ground Anchors



Figure 7: Product dimensions. This image illustrates the width (220 cm) and height (170 cm) of the VirtuFit Football Goal Pro.

9. WARRANTY AND SUPPORT

The VirtuFit Football Goal Pro comes with a **2-year warranty**, ensuring lasting quality. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims. For technical support, replacement parts, or warranty inquiries, please contact VirtuFit customer service through the retailer where you purchased the product.

