Rii RKM709 FR

Rii RKM709 Wireless Keyboard and Mouse Combo User Manual

Model: RKM709 FR

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Rii RKM709 Wireless Keyboard and Mouse Combo. This combo offers a reliable and efficient wireless solution for various operating systems and devices.



Figure 1: Rii RKM709 Wireless Keyboard and Mouse Combo.

Package Contents

Please verify that all items are present in your package:

- 1 x Rii RKM709 Wireless Keyboard (AZERTY French Layout)
- 1 x Rii Wireless Optical Mouse
- 1 x 2.4 GHz Unifying USB Receiver
- 1 x User Manual (this document)

Setup

1. Battery Installation

The keyboard and mouse require AAA batteries (not included). Ensure correct polarity when inserting batteries.

- **Keyboard:** Open the battery compartment on the underside of the keyboard and insert 2 AAA batteries. The USB receiver is typically stored within this compartment.
- **Mouse:** Open the battery compartment on the underside of the mouse and insert 2 AAA batteries.



Figure 2: Location of battery compartments for keyboard and mouse, and the USB receiver storage.

2. Connecting the USB Receiver

Locate the 2.4 GHz Unifying USB receiver from the keyboard's battery compartment. Plug the receiver into an available USB port on your computer, laptop, or compatible device. The system should automatically detect and install the necessary drivers.

3. Pairing Method (If Connection is Lost)

If the keyboard or mouse does not respond after inserting the receiver, you may need to re-pair them. For the keyboard, press and hold the **K** key and the **ESC** key simultaneously for approximately 2 seconds. The indicator light on the keyboard should remain steadily lit, indicating successful pairing.



Figure 3: Keyboard pairing instruction: Press K + ESC for 2 seconds.

Operating Instructions

Keyboard Features

- **Layout:** French AZERTY multimedia keyboard.
- **Silent Keys:** Designed for quiet typing, minimizing disturbance.
- **Adjustable Height:** Features anti-slip feet with adjustable height for comfortable typing.

- **Multimedia Functions:** Access various functions using the F-keys (F7-F12) for volume control (Vol+, Vol-, Mute), standard mode/sleep, and power switch.



Figure 4: The RKM709 keyboard features a robust and durable design.

Mouse Features

- **Ergonomic Design:** The optical mouse is designed for comfort, fitting well in the palm with rubber side grips.
- **Adjustable DPI:** Sensitivity can be adjusted between 1600, 2400, and 3200 DPI to suit different screen sizes and user preferences.
- **Buttons:** Includes standard left/right click, scroll wheel, and dedicated forward/backward buttons for enhanced navigation.



Figure 5: The RKM709 mouse with adjustable DPI settings (1600/2400/3200) and navigation buttons.

System Compatibility

The Rii RKM709 combo is compatible with a wide range of operating systems and devices:

- **Windows:** Windows 2000, XP, Vista, Win 7, Win 8, Win 10.
- **Linux:** Tested on Ubuntu 11.04 and later versions.
- **Android:** Version 2.3 and later versions.
- **Smart TV:** Refer to your Smart TV's FAQ for specific compatibility information.
- **Raspbian:** Compatible with Raspberry Pi.
- **PlayStation:** PlayStation 3, PlayStation 4.
- **Xbox:** Xbox 360, Xbox One.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the keyboard and mouse. For stubborn dirt, a slightly damp cloth with mild soap can be used, ensuring no liquid enters the device.
- **Battery Replacement:** Replace batteries when performance degrades or the device stops responding. Dispose of used batteries responsibly according to local regulations.
- **Storage:** When not in use for extended periods, remove batteries to prevent leakage. Store the combo in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

If you encounter issues with your Rii RKM709 combo, please refer to the following common problems and solutions:

- **Device Not Responding:**
  - Ensure the USB receiver is securely plugged into a working USB port.
  - Check if the batteries in both the keyboard and mouse are correctly inserted and have sufficient charge. Replace if necessary.
  - Try re-pairing the keyboard and mouse as described in the "Setup" section (K + ESC for keyboard).
  - Test the combo on a different USB port or another compatible device to rule out port or device issues.
- **Lagging or Intermittent Connection:**
  - Ensure the keyboard and mouse are within the effective operating range (up to 10 meters) of the USB receiver.
  - Minimize obstacles between the devices and the receiver, especially metal objects.
  - Avoid placing the receiver near other wireless devices that might cause interference (e.g., Wi-Fi routers, cordless phones).
  - Check battery levels; low batteries can affect wireless performance.
- **Mouse Tracking Issues / Inaccurate Cursor:**
  - Ensure the mouse is used on a clean, non-reflective surface.
  - Adjust the DPI sensitivity of the mouse using the dedicated button (if applicable) or through your operating system's mouse settings.
  - Clean the optical sensor on the underside of the mouse with a soft cloth.

Specifications

Feature	Detail
Model Number	RKM709 FR
Brand	Rii
Color	Black
Connection Type	2.4 GHz Wireless USB
Keyboard Layout	AZERTY French
Keyboard Dimensions (L x W x H)	29.5 x 13.7 x 1.9 cm

Feature	Detail
Mouse Dimensions (L x W x H)	11.2 x 6.3 x 3.9 cm
Mouse DPI Settings	1600 / 2400 / 3200 DPI
Operating Distance	Up to 10 meters (33 feet)
Keyboard Battery Life	Up to 12 months (approx.)
Mouse Battery Life	Up to 8 months (approx.)
Power Source	2 x AAA batteries (Keyboard), 2 x AAA batteries (Mouse) - Not included
Compatible Operating Systems	Windows (2000, XP, Vista, 7, 8, 10), Linux, Android, Smart TV, Raspbian, PlayStation, Xbox

Warranty and Support

For information regarding warranty coverage and technical support, please refer to the warranty card included with your product or visit the official Rii website. If you require further assistance or have questions not covered in this manual, please contact Rii customer support.

Manufacturer: Riitek

© 2024 Rii. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question