

## labebe B09GLMGLND

# labebe 2-in-1 Wooden Fire Truck Walker and Toy Cart

Model: B09GLMGLND

## 1. INTRODUCTION

This manual provides instructions for the safe assembly, operation, and maintenance of your labebe 2-in-1 Wooden Fire Truck Walker and Toy Cart. This product is designed to assist children aged 1-3 years in developing walking skills and provides a fun toy storage solution.

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

## 2. SAFETY INFORMATION

**WARNING:** Adult supervision is required at all times. Never leave a child unattended with the walker.

- Ensure all parts are securely fastened before each use.
- Do not use near stairs, steps, swimming pools, or uneven surfaces.
- This product is intended for children aged 1-3 years.
- Maximum weight capacity: 35 lbs (approximately 15.8 kg).
- Regularly inspect the product for any damage or loose parts. Discontinue use if any damage is found.
- Keep packaging materials away from children to prevent suffocation hazards.



Image: Safety certifications (CE, ASTM, CPC) displayed on a product image with a child and the walker.

### 3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. Refer to the assembly instructions for a detailed list of parts.



Image: The labebe 2-in-1 Wooden Fire Truck Walker and Toy Cart, fully assembled.

### 4. ASSEMBLY INSTRUCTIONS

The labebe 2-in-1 Wooden Fire Truck Walker is designed for easy assembly. A screwdriver is required (not included).

1. Unpack all components and lay them out on a clean, flat surface.
2. Identify the main body of the fire truck and the handle components.
3. Attach the handle to the main body using the provided screws. Ensure the handle is oriented correctly as per the illustrated instructions included in the package.
4. Securely fasten all wheels to the axle points. The wheels are designed for easy maneuverability and durability.
5. Verify that all screws are tightened and all parts are stable before allowing a child to use the product.

## More Details



Image: Detailed view of the walker highlighting features like storage space, rounded edges, and decorative patterns, which are relevant during assembly to understand component placement.

## 5. OPERATING INSTRUCTIONS

### 5.1. Walker Mode (Stand to Walk)

The walker mode is designed to assist children in their first steps. The wide base provides stability, helping children gain confidence while walking.

- Ensure the child can stand independently and reach the handle comfortably.
- Encourage the child to push the walker forward. The noiseless rubber wheels are designed for smooth movement on various surfaces, including carpets.
- Always supervise the child to prevent falls, especially during initial use.



Image: A child holding onto the walker's handle and pushing it forward, demonstrating its use as a walking aid.

## 5.2. Toy Cart Mode (Sit to Play)

The integrated storage compartment allows the product to function as a toy cart, encouraging independent play and organization.

- Children can sit on the floor and place their favorite toys, books, or other items into the cart.
- The cart can be pushed or pulled around, allowing children to transport their belongings.
- The weight of items placed in the cart can be adjusted to provide additional resistance for children who require more stability during walking practice.





Image: A close-up view of the storage compartment within the fire truck walker, illustrating its capacity for toys.

## 6. MAINTENANCE

- Clean the wooden surfaces with a damp cloth and mild soap. Avoid abrasive cleaners.
- Do not immerse the product in water.
- Store the walker in a dry place away from direct sunlight and extreme temperatures.
- Periodically check all screws and fasteners to ensure they are tight. Tighten if necessary.
- Inspect wheels for wear and tear. The wheels are designed to be wear-resistant.



Image: Close-up of the walker's wheels, showing their noiseless rubber and wear-resistant design, important for maintenance checks.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Walker is unstable or wobbly.	Loose screws or uneven assembly.	Check all screws and tighten them securely. Ensure all parts are correctly assembled according to the instructions.

Problem	Possible Cause	Solution
Wheels do not roll smoothly.	Debris in wheels or tight axle.	Inspect wheels for any trapped debris and remove. Ensure axles are not overtightened during assembly.
Missing parts upon arrival.	Packaging error.	Contact labebe customer support immediately for assistance.

## 8. SPECIFICATIONS

Feature	Detail
Model	B09GLMGLND
Material	Wood
Color	Red (Fire Truck Design)
Product Dimensions	44.79 x 34 x 14.4 cm (17.7 x 13.8 x 14.8 inches)
Item Weight	4.34 kg (9.57 lbs)
Maximum Recommended Weight	35 lbs (approximately 15.8 kg)
Recommended Age	1-3 Years
Style	Foldable

# Size Chart | Product Size

17.7in X 13.8in X 14.8in



Image: A size chart illustrating the product dimensions (length, width, height) in both centimeters and inches.

## 9. WARRANTY AND SUPPORT

labebe products are manufactured to high-quality standards. This product comes with a quality guarantee, ensuring compliance with European toy safety standards EN-71 CE.

If you encounter any issues or are not 100% satisfied with your purchase, please contact labebe customer support for assistance. We are committed to providing free replacements for any defects or issues that do not meet your expectations.

For support, please visit the official labebe store or contact your retailer.

**labebe Official Store:** [Visit Store](#)